


# CHECKFIRE 210-D DETECTION AND ACTUATION SYSTEM



## PLANNING, INSTALLATION, PROGRAMMING, OPERATION, AND MAINTENANCE MANUAL



011772



This manual is intended for use with the ANSUL® CHECKFIRE 210-D Detection and Actuation System. This system is specifically engineered for monitoring and release of vehicle/equipment fire suppression systems. Planning, installation, programming, operation, and maintenance of the system must conform to the limitations detailed in this manual. Installation and maintenance shall be performed by an individual holding current ANSUL® Certification from an ANSUL® CHECKFIRE 210-D Training Program with training to plan, install, recharge, and maintain the CHECKFIRE 210-D Systems. Individuals must also hold current ANSUL® Certification for applicable vehicle suppression systems being installed.

Those who plan, install, program, operate, reset, inspect, or maintain these systems should read this entire manual. Specific sections will be of particular interest depending upon one's responsibilities.

As with all electro-mechanical-pneumatic equipment, the system needs periodic care to provide maximum assurance that it will operate effectively and safely. Inspection frequency shall be performed consistently, depending on operating and/or environmental conditions. Maintenance shall be performed semi-annually, or more frequently, depending on operating and/or environmental conditions.

The application and use of the CHECKFIRE 210-D System is limited to the applications and uses described in this manual. For other applications, contact your Authorized ANSUL® Distributor, Territory Manager, or Johnson Controls – Technical Services Department, Marinette, Wisconsin 54143-2542, USA.

**Note:** The converted metric values in this manual are provided for dimensional reference only and do not reflect an actual measurement.

#### **DISCLAIMER:**

Johnson Controls does not make any representations, warranties or guarantees, expressed or implied, as to the accuracy or completeness of the manual. Users must be aware that updates and amendments will be made from time to time to the manual. It is the user's responsibility to determine whether there have been any such updates or amendments. Neither Johnson Controls nor any of its directors, officers, employees, or agents shall be liable in contract, tort, or in any other manner to any person for any loss, damage, injury, liability, cost, or expense of any nature, including without limitation incidental, special, direct, or consequential damages arising out of or in connection with the use of the manual.

All instructions contained herein relate to a typical installation.

Part Number: A16381NWJ9

Date: 2023--JUN-22

ANSUL®, CHECKFIRE, and the product names listed in this material are marks and/or registered marks. Unauthorized use is strictly prohibited.

 **DANGER**

Indicates a hazardous situation in which a person **will experience serious personal injury or death** if the situation is not avoided.

---

 **WARNING**

Indicates a hazardous situation in which a person **could experience serious personal injury or death** if the situation is not avoided.

---

 **CAUTION**

Indicates a hazardous situation in which a person **could experience minor or moderate personal injury** if the situation is not avoided.

---

**CAUTION**

Addresses practices not related to personal injury, such as a system part malfunctioning, property damage, or system failure.

---

**NOTICE**

Addresses general practices or observations related to system function that are *not* related to personal injury.

---

**REVISION RECORD**

PAGE e REV. 01 2024-MAY-17

*CHECKFIRE 210-D Detection  
and Actuation System  
(Part No. A16381NWJ9)*

**NOTES:**

<u>SECTION</u>	<u>PAGE</u>	<u>SECTION</u>	<u>PAGE</u>
<b>1 SYSTEM DESCRIPTION</b>	<b>1-1 – 1-2</b>	<b>5 INSTALLATION AND PROGRAMMING</b>	<b>5-1 – 5-38</b>
System Description	1-1	Installation	5-1
<b>2 COMPONENTS</b>	<b>2-1 – 2-10</b>	Mounting Interface Control Module	5-1
CHECKFIRE 210-D Interface Control Module	2-1	Cable Connectivity	5-1
CHECKFIRE 210-D Display Module	2-2	Display Circuit	5-2
Circuit Cables	2-3	CHECKFIRE 210-D Display Module	5-3
Display Circuit	2-3	Detection Circuit	5-6
Detection Circuit	2-4	Linear Detector	5-7
Relay Circuit	2-6	Electric Manual Actuator (EMA)	5-11
Release Circuit	2-7	CHECKFIRE 210-D Remote Activation	5-12
Power Circuits	2-8	Discharge Pressure Switch	5-13
Required Labels	2-9	Relay Circuit	5-14
Testing Equipment	2-10	Release Circuit	5-15
<b>3 USER INTERFACE</b>	<b>3-1 – 3-6</b>	Power Circuit Cable	5-16
User Interface	3-1	Auxiliary Output Cable	5-17
Field Connectivity	3-1	Label Package	5-17
Display Module Front Panel Buttons	3-1	Final Component Connections	5-18
Display Module Front Panel Indicators	3-2	<b>Programming</b>	5-18
Power	3-4	Table 5-1: Manual ICM Programming Summary	5-19
Interface Control Module	3-4	Table 5-2: Preparation – ICM Manual Programming Mode	5-20
<b>4 SYSTEM PLANNING</b>	<b>4-1 – 4-8</b>	Table 5-3: Manual Programming Options	5-23
Hazard Identification Basic Planning	4-1	Table 5-4: Download Event History Log	5-28
Specific Planning Information	4-2	Table 5-5: Personal Computer (PC) Options	5-30
Planning Checklist	4-7	Event History Log – Programming	5-36
		Equipment ID Feature	5-38

<u>SECTION</u>	<u>PAGE</u>	<u>SECTION</u>	<u>PAGE</u>
<b>6 OPERATIONAL TEST AND PLACE IN SERVICE</b>	<b>6-1 – 6-20</b>	<b>9 TROUBLESHOOTING</b>	<b>9-1 – 9-12</b>
Table 6-1: Preparation – Operational Test	6-1	Troubleshooting	9-1
Table 6-2: Isolation Feature – Operational Test	6-4	Table 9-1: Power LED Indications	9-1
Table 6-3: Operational Test	6-6	Table 9-2: Release LED Indications	9-3
Table 6-4: Secondary Power – Operational Test	6-15	Table 9-3: Detection LED Indications	9-4
Table 6-5: Placing CHECKFIRE 210-D System in Service	6-16	Table 9-4: Isolate Mode	9-5
CHECKFIRE 210-D Operational Test Checklist	6-19	Table 9-5: Multiple Amber LED Indications	9-5
		Table 9-6: No LED Indications	9-6
		Table 9-7: Specific Circuit Testing Procedures	9-7
<b>7 IN CASE OF FIRE</b>	<b>7-1 – 7-2</b>	<b>10 APPENDIX</b>	<b>10-1 – 10-4</b>
In Case of Fire	7-1	Component Index	10-1
CHECKFIRE 210-D Owners' Guide	7-2	Torque Specifications	10-3
<b>8 INSPECTION, MAINTENANCE, AND RECHARGE</b>	<b>8-1 – 8-6</b>		
Inspection and Maintenance	8-1		
Daily Inspections	8-1		
Maintenance	8-1		
Recharge	8-4		

## SYSTEM DESCRIPTION

The CHECKFIRE 210-D Detection and Actuation System is typically used with an ANSUL® A-101 or LVS Vehicle Fire Suppression System for 24-hour protection of equipment. The system is designed for vehicles/equipment in extreme environmental and physical conditions.

Typical types of equipment for the ANSUL® CHECKFIRE 210-D Systems:

- Forestry
- Agriculture
- Construction
- Public transportation
- Public utilities
- Land fills
- Waste disposal
- Mining

The automatic detection and actuation system provides two monitored input circuits and one monitored output circuit to activate an ANSUL® fire suppression system. On detecting a fire condition, the system activates the release circuit resulting in the discharge of an expellant gas cartridge initiating fire suppression system operation. Optional pneumatic actuation is available.

## CHECKFIRE 210-D System Features

- Supervised power, detection, release, and communication circuits
- System can be independently powered by utilizing either the primary power input or secondary power input.  
**Note:** Both primary and secondary power supplies must be utilized to maintain FM 5970 approval.
- Two time delays programmable to 0, 5, 10 or 15 seconds
- “DELAY/Reset/Silence” button
- “PUSH To Activate / Alarm When Lit” electric manual activation button and LED
- Minimum 75 dB internal sounder
- Dust and water tight connectors (IP68 rated)
- Manual programming button
- Computer programmable via mini USB port
- Two analog detection circuits, detection circuit #2 may be programmed for pressure switch feedback
- Detection circuits are programmable for independent detection and release, cross-zone detection and release or detection only
- Quad Infra-Red Detection
- Auxiliary Power output available when external power is connected
- Two internal programmable SPDT Form “C” relays (6A @ 30 VDC resistive, 3A @ 30 VDC Inductive)
- Isolate function via Display Module
- Downloadable 4000+ Event History Log

## CHECKFIRE 210-D System Specifications

### SYSTEM POWER (24 HOUR OPERATION)

- Connection for 12/24 VDC primary power source
- Supervised internal 3.6 VDC secondary power source

### SYSTEM CURRENT DRAW\*

- Nominal 8 mA @ 10.2 VDC
- Maximum Alarm/Fault 120 mA @ 10.2 VDC
- Nominal 5 mA @ 28.0 VDC
- Maximum Alarm/Fault 50 mA @ 28.0 VDC

\* **Note:** Does not include AUX OUTPUT load of up to 1.5 A

### OPERATING TEMPERATURE LIMITS

- – 40 °F to 185 °F (– 40 °C to 85 °C)

### APPROVALS

FM 5970 Approved and CE Marked

The CHECKFIRE 210-D System also offers Quad Infra-Red Detection as a high-speed means of flame detection. Refer to the Quad Infra-Red (QIR) Detection System Manual for more detailed information.

## CHECKFIRE 210-D System Connectivity

The CHECKFIRE 210-D Display Module (see Figure 1-1) communicates with the CHECKFIRE 210-D Interface Control Module (ICM) through the Display Circuit Cable.




FIGURE 1-1  
CHECKFIRE 210-D DISPLAY MODULE  
011770

**SYSTEM DESCRIPTION (Continued)**

**CHECKFIRE 210-D System Connectivity (Continued)**

TYPICAL SYSTEM CONNECTIONS

See Figure 1-2.

The Display Module continually exhibits system status.

**Display Module Circuit:** Permits connection between the Display Module and the ICM.

**Detection Circuit (#1 and #2):** Permits multiple-detection options using detection circuit cables, and Detection Circuit “h” Cables.


- Electric Manual Actuators (EMA)
- Linear Detectors
- Pressure Switch

**Release Circuit:** Connects up to a maximum of 8 Electric-Pneumatic Actuators installed on agent tank expellant gas cartridges using Release Circuit Cables, Release Circuit “h” Cables, and Release Circuit Drop Cables.

**Power Circuit:** Provides a direct connection to the primary power source using Power Circuit Cables and a single Fused Power Circuit Cable.

**Auxiliary Output Circuit:** Provides auxiliary power output to additional devices from the primary power source.

**Relay #1 and #2 Circuit:** Provides connection for two internal Relays with SPDT Form “C” (6 A @ 30 VDC resistive, 3 A @ 30 VDC inductive) automotive contacts.



**FIGURE 1-2**  
**SYSTEM CONNECTIONS**  
 011772

**CHECKFIRE 210-D INTERFACE CONTROL MODULE**  
**Part No. A16381C9PL**


The CHECKFIRE 210-D Interface Control Module (ICM) communicates with the CHECKFIRE 210-D Display Module and is the central connection point for input/output circuits. See Figure 2-1.

The accessible battery compartment contains the secondary power supply, a USB Mini B connection port, and the programming interface. See Figure 2-3.

- Dimensions for ICM base, see Figure 2-2



**FIGURE 2-1**  
**INTERFACE CONTROL MODULE (ICM) – FRONT VIEW**  
011771




**FIGURE 2-3**  
**ICM BATTERY COMPARTMENT – TOP VIEW**  
011773

**CHECKFIRE 210-D ICM Battery Module**  
**Part No. 440352**

A supervised non-rechargeable 3.6 VDC lithium battery provides secondary power for the CHECKFIRE 210-D System. See Figure 2-4.



**FIGURE 2-4**  
**BATTERY MODULE**  
009278




**FIGURE 2-2**  
**BASE MOUNTING**  
009312a

**CHECKFIRE 210-D DISPLAY MODULE**  
**Part No. A16381C9PK**

Provides communication with the Interface Control Module (ICM) and indicates system status. See Figure 2-5.


- UL94 flame rated durable high-strength glass-filled nylon material
- Surface or bracket mounted
- LED indicators provide visual notification of system status.
- Internal Sounder provides audible notification of system status.
- “PUSH To Activate / Alarm When Lit” manual-activation button and LED
  - Provides manual operation (immediate release)
  - Indicates alarm condition
- Guard door with visual seal to protect manual-activation button
- “DELAY/Reset/Silence” button
  - Restarts Time Delay #1 (TD1) period before TD1 expires
  - Resets CHECKFIRE 210-D System (during non-alarm status)
  - Silences internal sounder during fault conditions
  - Activate/Deactivate ISOLATE mode



**FIGURE 2-5**  
**CHECKFIRE 210-D DISPLAY MODULE**  
 009275a

**Display Cable (See Figure 2-6)**

- 24 in. (610 mm) Cable



**FIGURE 2-6**  
**DISPLAY MODULE**  
 011770

**Display Module Mounting**

Two types of mounting options are available.

- SURFACE MOUNT – Display Module includes integral index pins, foam gasket, rubber washer and securing nut to fasten the display module in place without a bracket. The foam gasket minimizes moisture and dust ingress through the opening.
- BRACKET MOUNT - The optional Mounting Bracket is constructed of durable high-strength glass-filled nylon material. The pivot and secure feature accommodates easy operator visual identification and access to the CHECKFIRE 210-D Display Module for status indications and manual operation. See Figure 2-7.

**NOTICE**


The display module should never be mounted in an area subject to pressure washing or steam cleaning.

**CHECKFIRE 210-D DISPLAY MODULE (Continued)**


**CHECKFIRE Mounting Bracket  
Part No. 439564**

Provides flexible bracket mounting for Display Module at various viewing angles. See Figure 2-7.

- Constructed with high-strength glass-filled nylon material
- Multi-position bracket for securing module in a variety of configurations
- Dimensions for bracket base, see Figure 2-8



**FIGURE 2-7  
FLEXIBLE MOUNTING BRACKET**  
009152/ 009181



**FIGURE 2-8  
BRACKET BASE FRONT VIEW**  
009113

**CIRCUIT CABLES**

Provide the pathways for communication between system modules, detectors, PADs and EMAs. The cables include the following:

- Temperature rating: 221 °F (105 °C)
- Multiple lengths for versatility
- Jacketed cable minimum bend radius: 2 1/2 in. (64 mm)

**DISPLAY CIRCUIT**

Connects the CHECKFIRE 210-D Interface Control Module with Display Module for input/output communications. See Figures 2-9 and 2-10.

- Maximum circuit length 200 ft (60.96 m)

**Display/Communication Circuit Bulk Cable**

Part No.	Description
A16381EW4C	100 ft (30.5 m) Bulk Display/Communication Circuit Cable Box
A16381EW48	200 ft (60.9 m) Bulk Display/Communication Circuit Cable Spool
A16381TK1Y	6-Pin Connector Kit*

\* Connector kit includes equipment to make one complete connection. Both plug and receptacle items as needed.



**FIGURE 2-9  
PLUG AND RECEPTACLE FROM CONNECTOR KIT**  
011832

**Display/Communication Circuit Cable with Connectors**

Part No.	Length:	ft	(m)
A16381CBC1	2	(0.61)	
A16381CBC2	3	(0.91)	
A16381CBC3	5	(1.53)	
A16381CBC4	10	(3.05)	
A16381CD2V	20	(6.10)	
A16381CD2W	30	(9.15)	
A16381CD30	50	(15.24)	



**FIGURE 2-10  
DISPLAY CIRCUIT CABLE WITH CONNECTORS**  
011776

**DETECTION CIRCUIT**

Connects the CHECKFIRE 210-D Interface Control Module to the detection circuit input components. See Figures 2-11 and 2-12.

- Maximum total length of detection circuit cable plus Linear Detector is 750 ft (228.6 m).
- Detection Circuit Single Conductors are 18 gauge wire.

**Detection/Relay Circuit Bulk Cable**

Part No.	Description
A16381EW49	100 ft (30.5 m) Bulk Detection/Relay Circuit Cable Box
A16381EW45	500 ft (152.4 m) Bulk Detection/Relay Circuit Cable Spool
A16381TK1Y	6-Pin Connector Kit*

\* Connector kit includes equipment to make one complete connection. Both plug and receptacle items as needed.



**FIGURE 2-11**  
**PLUG AND RECEPTACLE FROM CONNECTOR KIT**  
 011832

**Detection Circuit Cable with Connectors**

Part No.	Length:	ft	(m)
A16381C9PN		2	(0.61)
A16381CB0F		3	(0.91)
A16381CB0G		5	(1.53)
A16381CB62		10	(3.05)
A16381CB63		20	(6.10)
A16381CB64		30	(9.15)
A16381CB65		50	(15.24)



**FIGURE 2-12**  
**DETECTION CIRCUIT CABLE WITH CONNECTORS**  
 011777

**Detection Circuit “h” Cable**  
**Part No. A16381CD32**

Provides a connection for a branch detection circuit. See Figure 2-13.

- 15 in. (0.38 m) leads with connectors
- 3/8 in. (10 mm) Crush Sleeve for mounting.
- Overall length: 33 3/4 in. (0.86 m)



**FIGURE 2-13**  
**DETECTION CIRCUIT “h” CABLE**  
 011778

**Linear Detector**  
**Part No. See table**

Provides fire detection in the protected area with a choice of two temperature ratings.

- Two twisted spring steel conductors separated by a heat-sensitive insulator


Activation temperature ratings		Maximum installed continuous operating temperature
Red	356 °F (180 °C)	250 °F (121 °C)
White	220 °F (105 °C)	175 °F (79 °C)

**Bulk Linear Detector**

Part No.	Description
071230	100 ft (30.5 m) Red Bulk Linear Detection Wire, 356 °F (180 °C)
A16381ULBP	100 ft (30.5 m) White Bulk Linear Detection Wire, 220 °F (105 °C)

**In-Line Splice Kit**  
**Part No. 428375**

Provides the connection between the Detection Circuit Cable and the Linear Detector or between separate sections of the Linear Detector. The kit contains enough components to create 10 assemblies. See Figure 2-14.




**FIGURE 2-14**  
**IN-LINE SPLICE KIT ASSEMBLY**  
 007045a

**Part No. A163828M45**

The CHECKFIRE In-Line Splice Kit is used to make connections to the linear detection wire. The splice kit consists of a contact carrier, a plastic housing, sealing caps, a large grommet sized for the detection cable, two small, sealed grommets sized for the linear detection wire, and a 4.7k Ω resistor. See Figure 2-15 (next page).

**DETECTION CIRCUIT (CONTINUED)**

**In-Line Splice Kit (Continued)**



A	Sealing cap
B	Large grommet
C	Connector body
D	Contact carrier
E	Sealing ring
F	Adapter
G	Small sealed grommet
H	Sealing cap
I	Resistor

**FIGURE 2-15**  
**IN-LINE SPLICE KIT**  
012088/012097

**Electric Manual Actuator (EMA)**  
**Part No. A16381C9PM**

Provides manual electrical activation of the fire suppression system; typically accessible from ground level and/or in a path of egress. See Figure 2-16.


- Electronic signal sent to Interface Control Module that activates the fire suppression system after a 2 second delay
- Temperature range: -40 °F to 185 °F (-40 °C to 85 °C)
- Flexible 24 in. (610 mm) Detection Cable



**FIGURE 2-16**  
**ELECTRIC MANUAL ACTUATOR (EMA)**  
011781

**Electric Manual Actuator Bracket**  
**Part No. 440537**

Constructed of 3/16 in. (4.8 mm) painted steel. Weld or bolt with appropriate fasteners. See Figure 2-17.



**FIGURE 2-17**  
**ELECTRIC MANUAL ACTUATOR BRACKET**  
009154

**DETECTION CIRCUIT (Continued)**

**Detection Circuit EOL (End-of-Line) Device (DT Style)  
 Part No. A16381CB66**

Provides circuit supervision and termination point for main detection circuit trunk. See Figure 2-18.




**FIGURE 2-18  
 DETECTION CIRCUIT EOL**  
 011807

**End-of-Line Resistor (EOL) (Field Wireable Option)  
 Part No. 426520**

Provides field wireable circuit supervision and termination point for main detection circuit trunk.

- Each package consists of the required components to assemble the resistor assemblies. See Figure 2-19.



**FIGURE 2-19  
 END-OF-LINE RESISTOR**  
 002774

**Detection Circuit Branch Terminator  
 Part No. A16381CB6Y**

Terminates detection circuit branch line. See Figure 2-20.




**FIGURE 2-20  
 BRANCH TERMINATOR**  
 011783

**Discharge Pressure Switch  
 Part No. A16381TK26**

Provides pressure switch feedback to the ICM through Detection Circuit #2. See Figure 2-21.

- One integral cable, sealed to switch housing
- Manually resettable SPDT switch
- Rated for 6A with 12/36 VDC nominal
- Temperature range: – 40 °F to 175 °F  
 (– 40 °C to 79 °C)
- Includes 1/4 in. brass tee and nipple



**FIGURE 2-21  
 DISCHARGE PRESSURE SWITCH CONNECTIONS**  
 011833

**RELAY CIRCUIT**

Connects the CHECKFIRE 210-D Interface Control Module to relay circuits provided by others. See Figure 2-22.

- Bulk part numbers are in the table for Detection/Relay Circuit Bulk Cable on page 2-4. See Figure 2-11.
- Contact Rating for both relays: 6A @ 30VDC resistive, 3A @ 30VDC inductive

**Relay Circuit Cable with Connectors**

Part No.	Length:	ft	(m)
A16381CB9R	2		(0.61)
A16381CB9T	5		(1.53)
A16381CB9U	10		(3.05)
A16381CB9Y	20		(6.10)



**FIGURE 2-22  
 RELAY CIRCUIT CABLE**  
 011791

### RELEASE CIRCUIT

Connects the CHECKFIRE 210-D Interface Control Module to release circuit cables, Release Circuit “h” Cables, and Release Circuit Drop Cables. See Figures 2-23 and 2-24.

- Maximum circuit length: 250 ft (76.4 m)
- Release Circuit Single Conductors are 16 gauge wire

#### Release/Power Circuit Bulk Cable

Part No.	Description
A16381EW4B	100 ft (30.5 m) Bulk Release/Power Circuit Cable Box
A16381EW47	500 ft (152.4 m) Bulk Release/Power Circuit Cable, Spool
A16381TK21	2-Pin Connector Kit*

\* Connector kit includes equipment to make one complete connection. Both plug and receptacle items as needed.



**FIGURE 2-23**  
**PLUG AND RECEPTACLE FROM CONNECTOR KIT**  
011834

#### Release Circuit Cable with Connectors

Part No.	Length:	ft	(m)
A16381CB70	2	(0.61)	
A16381CB71	3	(0.91)	
A16381CB72	5	(1.53)	
A16381CB73	10	(3.05)	
A16381CB74	20	(6.10)	
A16381CB7D	30	(9.15)	
A16381CB7E	50	(15.24)	



**FIGURE 2-24**  
**RELEASE CIRCUIT CABLE**  
011788

#### Release Circuit “h” Cable Part No. A16381CD33

Provides connections for multiple release circuit drop cables. See Figure 2-25.

- 19 3/4 in. (0.5 m) leads with connectors
- 3/8 in. (10 mm) Crush Sleeve for mounting
- Overall length: 43 1/8 in. (1.09 m)



**FIGURE 2-25**  
**RELEASE CIRCUIT “H” CABLE**  
011785

#### Release Circuit Drop Cable Part No. A16381CB7H

Provides connectivity between release circuit cable and Electric-Pneumatic Actuator. See Figure 2-26.

- Overall length: 38 in. (0.96 m)



**FIGURE 2-26**  
**RELEASE CIRCUIT DROP CABLE**  
011786


#### Protracting Actuation Device (PAD) Part No. 439448

Provides electrical activation of the fire suppression system. See Figure 2-27.

### CAUTION

When handling the PAD, always point the actuating end away from yourself and others. On electrical initiation, the PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and/or the detaching disk.

- Generates force to drive the Electric-Pneumatic Actuator puncture pin through an expellant gas cartridge seal, allowing the expellant gas to flow into agent tank.
- Integral spade connectors easily field install into the Release Circuit Drop Cable. See Figure 2-27.



**FIGURE 2-27**  
**PAD**  
009169

**RELEASE CIRCUIT (Continued)**

**Release Circuit Terminator**  
**Part No. A16381CB7J**

Identifies termination point in the release circuit. See Figure 2-28.



**FIGURE 2-28**  
**RELEASE CIRCUIT TERMINATOR**  
 011787

**Electric-Pneumatic Actuator**  
**Part No. 439569**


Installs on expellant gas cartridge and provides release of gas into agent tank. See Figure 2-29.

- Brass and stainless steel construction
- Includes preventor to reduce possibility of installing actuator with puncture pin not completely retracted

**NOTICE**

Do not bend or remove the preventor; it is required for correct operation of the actuator.

- Activate with electric and/or pneumatic connections
- Punctures seal in cartridge allowing expellant gas to flow into agent tank



**FIGURE 2-29**  
**ELECTRIC-PNEUMATIC ACTUATOR**  
 009168

**POWER CIRCUITS**

Connects the CHECKFIRE 210-D Interface Control Module to Power Circuit Cables and Fused Power Circuit Cable. See Figure 2-30.

- Bulk part numbers are in the table for Release/Power Circuit Bulk Cable on page 2-6. See Figure 2-23.
- Maximum circuit length: 50 ft (15.24 m): Excludes 3 ft (10.9 m) Fused Power Circuit Cable
- Power Circuit Single Conductors are 16 gauge wire.

**Power Circuit Cable with Connectors**

Part No.	Length:	ft	(m)
A16381CB7K		2	(0.61)
A16381CB7L		3	(0.91)
A16381CB7M		5	(1.53)
A16381CB7P		10	(3.05)
A16381CB7T		20	(6.10)
A16381CB8K		30	(9.15)
A16381CB8M		50	(15.24)



**FIGURE 2-30**  
**POWER CIRCUIT CABLE**  
 011788

**Fused Power Circuit Cable**  
**Part No. A16381CB9P**

Connects Power Circuit Cable to the 12/24 VDC external power source. See Figure 2-31.

- 3 amp in-line ATO/ATC blade style automotive fuse



**FIGURE 2-31**  
**FUSED POWER CIRCUIT CABLE**  
 011789


**REQUIRED LABELS**

**CHECKFIRE Label Package  
Part No. 440798**

Provides instructions for vehicle/equipment operators and service personnel on system operation and protection.

Attach appropriate labels as needed in the specified locations. See Figures 2-32 through 2-35.

If automatic vehicle/equipment shutdown is part of the CHECKFIRE System, install the Engine Shutdown Label near the operator's line of vision. Cut out the correct time delay value from the Time Delay Label, remove backing to expose adhesive, and attach to the Engine Shutdown Label in the space provided. See Figure 2-32.



**FIGURE 2-32  
LABEL FOR ENGINE SHUTDOWN AND TIME DELAY**  
009174

If automatic vehicle/equipment shutdown is **NOT** part of the CHECKFIRE System, install the Stop Vehicle and Exit Label near the operator's line of vision. See Figure 2-33.



**FIGURE 2-33  
LABEL TO STOP VEHICLE AND EXIT**  
009175

As a reminder to service and maintenance personnel, install this CAUTION in the area protected by the Linear Detector. See Figure 2-34.



**FIGURE 2-34  
LABEL FOR PROTECTING LINEAR DETECTOR**  
011941

Install the In Case of Fire Label next to every Electric Manual Actuator (EMA). See Figure 2-35.



**FIGURE 2-35  
INSTRUCTION LABEL FOR EMA**  
009324a

TESTING EQUIPMENT

**Detection Circuit Tester**  
Part No. A16381TK27

Simulates normal, fault, and alarm conditions for testing the CHECKFIRE 210-D System performance. See Figure 2-36.

Switch settings:

- Normal
- Fault
- Alarm



**FIGURE 2-36**  
**DETECTION CIRCUIT TESTER**  
011826

**Release Circuit Tester**  
Part No. 441021


Indicates a successful release energy pulse to fire the PAD (pass or fail). See Figure 2-37.



**FIGURE 2-37**  
**RELEASE CIRCUIT TESTER**  
009288

**Release Circuit Test Plug**  
Part No. A16381V3R6

Replaces a PAD for testing the CHECKFIRE 210-D System. See Figure 2-38.



**FIGURE 2-38**  
**RELEASE CIRCUIT TEST PLUG**  
012163

## USER INTERFACE

This section provides the user with overall information on features and operation of the CHECKFIRE 210-D Display Module and Interface Control Module (ICM).

### FIELD CONNECTIVITY – Cables and Devices

The CHECKFIRE 210-D ICM communicates with the Display Module and other devices through cable assemblies.

### DISPLAY MODULE FRONT PANEL BUTTONS

#### “DELAY/Reset/Silence” Button

Manage fault and/or alarm conditions by pressing the “DELAY/Reset/Silence” button (see Figure 3-1) for the following results:

- **Audible Fault Silence**
  - Silence an audible notification during a fault condition. Fault LED indicators continue pulsing until the fault condition has been cleared. Exception: Silencing a Primary Power Fault changes the sounder pulse rate from 1 x 10 sec to 1 x 30 sec.
  - During a post release condition the button will silence the sounder.
  - Any new alarm or fault conditions will reactivate the audible notification.
- **Restart Time Delay Sequence**

Restart the time delay cycle during an alarm condition; must be initiated before Time Delay #1 (TD1) period expires.
- **System Reset**

Press and hold (3 seconds) to reset the system.
- **Activate/Deactivate ISOLATE Mode**

Press and hold for two consecutive resets (approximately 8 seconds).

#### Red “PUSH To Activate / Alarm When Lit” Button and LED Indicator (See Figure 3-1)

- Combination button and LED indicator
- **MANUAL ACTIVATION** - Pressing the red “PUSH To Activate / Alarm When Lit” Button immediately activates the release circuit and illuminates the red LED for 10 seconds.

**Note:** No time delay occurs when red “PUSH To Activate / Alarm When Lit” Button is pressed.

After 10 seconds, the system enters Post Release Activated mode.

- **DETECTOR INITIATION** - The “PUSH To Activate / Alarm When Lit” LED indicator displays the conditions listed in Table 3-1.

#### PRE-ALARM CONDITION (Previous to TD1)

LED pulses RED 1 x 1 second during an alarm only or first alarm condition with Cross-Zone programming or alarm condition in Isolate Mode.

#### ALARM CONDITION:

##### Time Delay #1 (TD1)

LED pulses RED 2 x 1 second until last 5 seconds of Time Delay #1 (TD1) period (sounder matches pulse rate).

In last 5 seconds of TD1, LED pulses RED 4 x 1 second for 4 seconds; in the final second LED is off (sounder matches shutdown LED pulse rate).

##### Time Delay #2 (TD2)

LED pulses RED 4 x 1 second until Time Delay #2 (TD2) period expires (sounder matches pulse rate).

#### Release Activated

LED illuminates RED and remains steady-on for 10 seconds (release circuit active) (sounder remains steady-on).

#### Post Release Activated

No LED indication (sounder matches other LED indications).




FIGURE 3-1  
DISPLAY MODULE FRONT PANEL BUTTONS

009290a

DISPLAY MODULE FRONT PANEL INDICATORS  
 TABLE 3-1: ALARM CONDITION LED INDICATORS

		DETECTION #1 and/or #2 LEDs*	CIRCUIT	"PUSH To Activate / Alarm When Lit" LED*	DISCHARGE LED*	SHUTDOWN LED*	
<b>Manual Action (Immediate Release Circuit Activation)</b>		1 x 1 sec.					
		2 x 1 sec.					
Push the "PUSH To Activate/Alarm When Lit" button, Release Activated		4 x 1 sec.	Steady-on for 10 sec.	1 x 10 sec. until cleared & reset**	Steady-on for 10 sec.	1 x 10 sec. until cleared & reset**	
Post Release Activated							
Pull ring pin and strike button on EMA***							
Release Activated							
Post Release Activated							
<b>Automatic Action (Detector Activation) (Detection Circuit #1 and/or #2 Input - Alarm Condition)</b>							
Alarm Only Programming or Isolate Mode							
Time Delay #1 (TD1) Programmed for:	0 seconds	Immediately Enters Time Delay 2					
	10 or 15 seconds						
	5, 10 or 15 seconds (Starting the last five seconds of TD1)						
	5, 10 or 15 seconds (Last second of TD1)						
Time Delay #2 (TD2) Programmed for:	0 seconds	Immediately Activates Release Circuit When TD1 Expires					
	5, 10 or 15 seconds						
	Release Activated (TD2 Expired - Release Circuit Activation)						
Post Release Activated							
Cross-Zone Programming	One Detection Circuit in Alarm (Pre-Alarm Condition)						
	Both Detection Circuits in Alarm	Time Delay #1 (TD1) Programmed for:	0 seconds	Immediately Enters Time Delay 2			
			10 or 15 seconds				
			5, 10 or 15 seconds (Starting the last five seconds of TD1)				
			5, 10 or 15 seconds (Last second of TD1)				
	Both Detection Circuits in Alarm	Time Delay #2 (TD2) Programmed for:	0 seconds	Immediately Activates Release Circuit When TD1 Expires			
			5, 10 or 15 seconds				
			Release Activated (TD2 Expired - Release Circuit Activation)				
Post Release Activated							
Detection Circuit #2 Only	Pressure Switch Feedback Programming****						
	Post Release Activated						

\* Sounder pulses at same rate as LED.  
 \*\* Release LED also pulses Amber at this rate.  
 \*\*\* Detection Circuit 1 or 2 LED indicates; matching the circuit where EMA is installed. EMA activation may take up to 2 seconds after EMA pushbutton is depressed.  
 \*\*\*\* Release Circuit activates, if programmed.

## DISPLAY MODULE FRONT PANEL INDICATORS (Continued)

### Power LED (See Figure 3-2)

#### NOTICE

Both Primary and Secondary power sources must be used to maintain FM Approval.

- Dual Power/Primary Power Status - Power LED illuminates GREEN and remains steady-on during normal operation
- Secondary Power Status – Power LED pulses GREEN 1 x 3 seconds during normal operation
- Power Fault Conditions
  - Primary Power Fault status – Amber Power LED pulses 1 x 3 seconds and sounder pulses 1 x 10 seconds indicating power from the external power source dropped below acceptable level causing a fault condition.
  - Secondary Power Supply Fault - Amber Power LED and sounder pulse 1 x 10 seconds indicating power from the secondary power source dropped below acceptable level causing a fault condition.
  - System Powered Down – Amber Power LED and sounder pulse 1 x 1 for 10 seconds when secondary power is depleted and system is powering down (**Note:** occurs when the system is only being powered by the secondary power source).
  - Fault conditions will continue pulsing AMBER as long as fault exists or until system powers down.

### Release Circuit LED (See Figure 3-2)

- Pulsed AMBER 1 x 10 seconds (sounder matches pulse rate) during a fault condition
- Returns to normal (no indication) when fault is cleared

### Discharge LED (See Figure 3-2)

This LED is only active when Pressure Switch Feedback is programmed.

- Illuminates RED steady-on when pressure switch activates for the remainder of Release Activated period (see Table 3-1)
- Pulsed RED 1 x 10 seconds in post release activated (see Table 3-1)
- Controlled by an external pressure switch and provides indication of rising pressure in the expellant gas line




FIGURE 3-2  
DISPLAY MODULE FRONT PANEL  
009290a

### Detection Circuit #1 and #2 LED (See Figure 3-2)

- Pulsed RED in an alarm condition (see Table 3-1)
- Pulsed AMBER 1 x 10 seconds (sounder matches pulse rate) during an open-circuit fault condition
- Pulsed AMBER 2 x 10 seconds Connection Fault
- Returns to normal (no indication) when fault or alarm condition is cleared

### Isolate LED (See Figure 3-2)

- Pulsed AMBER 2 x 10 seconds to indicate the system is in Isolate Mode
- Use Isolate Mode when performing maintenance on the vehicle/equipment to inhibit automatic release of the fire suppression system

### Shutdown LED (See Figure 3-2)

- Pulsed RED 4 x 1 second in an alarm condition beginning in the last 5 seconds of TD1 (see Table 3-1)
- Illuminates RED steady-on in the last second of TD1 (see Table 3-1)
- Pulsed RED 4 x 1 second during TD2
- Indicates Release Activated and Post Release Activated conditions (see Table 3-1)

**POWER**

**FM Approved Power Configuration**

To be compliant to FM 5970, the CHECKFIRE 210-D System must utilize both primary and secondary power sources. Utilization of a single power source will void FM Approval. When both primary power and secondary power are connected, the secondary power source serves as the reserve power source.

**Primary Power**


The CHECKFIRE 210-D System uses equipment power as the primary power source. The Power LED illuminates GREEN steady-on for external power. The primary power circuit requires 12/24 VDC nominal and is supervised for low power conditions.

**Secondary Power**

The CHECKFIRE 210-D System has a secondary power source (ICM Battery Module) providing power under normal operating conditions. The Power LED pulses GREEN 1 x 3 seconds while on secondary power only. The battery module is supervised for low power conditions.

**INTERFACE CONTROL MODULE**

The CHECKFIRE 210-D Interface Control Module (ICM) includes system electronics, and receptacles for system cables. The battery compartment cover helps protect the secondary power supply, mini USB port, and programming interface. See Figures 3-3 and 3-4.



**FIGURE 3-3**  
**CHECKFIRE 210-D ICM RECEPTACLES**  
 011771

**Detection Circuit #1 Cable**

Provides connection point for detection circuit cable and devices.

**Detection Circuit #2 Cable**

Provides connection point for detection circuit cable, devices or pressure switch.

**Display Module Cable**

Provides the connection point for the display cable.

**Release Circuit Cable**

Provides the connection point for the release circuit cable to electric-pneumatic actuators.

**Relay #1 & #2 Cable**

Provides the connection point for a maximum of two internal relays to control external devices (by others). The Relay Circuit Cable with Leads component has 6 lead wires (3 wires for each relay).

**Auxiliary Output Cable**


Provides the connection point for output power (for horns, strobes, etc.) regulated to the system voltage 12/24 VDC (1.5 amps maximum). This power output is only available when using primary (vehicle/equipment) power to operate the CHECKFIRE 210-D System.

**Power Cable**

Provides the connection point for primary power.

**Battery Compartment Cover**

The battery compartment cover is located on the ICM near the embossed ANSUL® logo and can be removed by loosening the four captive screws, see Figure 3-3. The cover fits over an o-ring seal on the ICM enclosure and provides an IP67 rated seal when properly installed. See Figure 3-4.




**FIGURE 3-4**  
**ICM COVER REMOVED**  
 011773

**INTERFACE CONTROL MODULE (Continued)**

**ICM Programming Panel**

Remove the battery cover for access to the programming button and associated program indicator lights (LEDs). The mini USB port and battery cable for the internal battery module are next to the LEDs. See Figure 3-5.



**FIGURE 3-5**  
**ICM PROGRAMMING PANEL**  
009292

**System Isolate Function**

The CHECKFIRE 210-D System includes an isolation feature for end users to minimize the occurrence of a false discharge when service or maintenance is being performed on the protected vehicle/equipment (not intended for CHECKFIRE 210-D System maintenance).



**FIGURE 3-6**  
**ISOLATE MODE**  
009290a

When placed in isolate mode, an automatic detection circuit input (alarm condition) will not initiate the release circuit. However, a manual actuation by either an EMA, if the Isolate Mode EMA Activation is enabled, or the “PUSH to Activate/ Alarm When Lit” button, will bypass the isolation feature. Pressing the “PUSH to Activate/Alarm When Lit” button on the Display Module will cause immediate activation of the release circuit whereas an EMA actuation will activate the release circuit after a four second delay. This functionality can be changed with the CHECKFIRE 210 Programmer software.

**NOTES:**

## HAZARD IDENTIFICATION BASIC PLANNING

Individuals responsible for planning (or designing) a CHECKFIRE 210-D Detection and Actuation System must hold current ANSUL® Certification from an ANSUL® A-101 and/or LVS training program. In addition to the certification, planners must research:

- Known fire hazards in equipment to be protected
- Federal and local fire protection codes/standards

For easier planning obtain a general model drawing of the vehicle/equipment with accurate dimensions.

Identify hazard areas needing protection. Agent nozzles in existing fire suppression systems may point out hazard areas. For existing or new fire suppression/detection systems review and apply the following vital information to determine proper placement of discharge nozzles and detection devices.

### Fire Hazard Locations

A fire hazard is any area where an ignition source (heat, high temperature or sparks) and fuel (flammable materials) may be found in close proximity. A solid or liquid combustible or flammable material can cause fire when in contact with an ignition (heat) source. Fire hazard areas may also exist in locations where fire can propagate because of dripping or running flammable liquids.

Examples of ignition (heat) sources:

- Engines
- Exhaust manifolds and piping
- Turbochargers
- Power source compartments
- Electrical system equipment
- Torque converters
- Transmissions
- Hydraulic pumps
- Parking brakes (engaged while moving)
- Bearings, clutches or gears
- Malfunctioning components
- Friction from debris packed around parts

Examples of fuel or flammable materials (may cause rapid buildup or spreading of fire):

### CLASS B MATERIALS

- Leaking fuel (gasoline, diesel, engine oil, hydraulic oil, glycol, steering fluid, and more)
- Broken fuel lines/fittings
- Slow leaks – fuel or hydraulic fluid
- Broken hydraulic lines or pumps
- High pressure hoses
- Belly pan (fuel and debris accumulation)
- Ruptured fuel or hydraulic tank
- Greases

### CLASS A MATERIALS

- Electric wiring insulation
- Plastic parts
- Rubber
- Debris (wood chips, coal dust, landfill material, and more)

Identify every foreseeable hazard. Include the occasional danger of malfunctioning components.

### Other Considerations

The propagation of fire from one area to another may cause a hazard to be larger than originally determined. Liquid fuel may flow, spray, or splash causing the fire to spread further than anticipated. Radiation, sparks, or conduction through metal can carry heat to an area where the danger of fire would not normally exist. Hand portable fire extinguishers should be accessible to suppress residual fires or to help with providing an escape route.

Research the fire history of the equipment or of similar equipment. This information may be available through company records or equipment operators who may have firsthand experience enabling them to identify locations of previous fires as well as specific hazards such as frequent component wear, fuel leak points, or ruptures of certain hydraulic fittings or hoses.

Normal operating temperatures in excess of the detector ratings will cause the detection system to activate.

Each identified hazard has a rating, and the rating determines how the hazard is mitigated. For example: If a battery compartment has a low rating, no detection or protection is required.

### Equipment Shutdown

Plan for the shutdown of components that could add to the intensity of the fire, re-ignite the fire, or negatively impact the discharge of fire suppression agent such as:

- Fuel pumps
- Hydraulic pumps
- Engine
- Power source
- Electrical system
- Fans

Automatic pressure bleed-down and/or fuel and hydraulic tank shutoff valves should also be considered to mitigate fire propagation and/or re-flash.

Electrical interface for automatic equipment shutdown can be made utilizing either the internal relay in the ICM or the Discharge Pressure Switch. When the pressure switch alone is used, shutdown will occur simultaneously with system release. When the pressure switch is used in conjunction with Detection Circuit #2 as pressure switch feedback, and pneumatic actuation is utilized, the programmable #2 internal relay contacts will transfer, and connected equipment will become energized or de-energized depending on how the relay is wired.

Consult the vehicle/equipment manufacturer, the manufacturer's dealer, the site maintenance manager or customer for details when planning for either shutdown method.

## HAZARD IDENTIFICATION BASIC PLANNING (Continued)

### Notification – Operator Safety

Fire can occur in locations not visible to the vehicle operator. In addition, noisy vehicle operation may result in difficulty hearing the internal sounder in the CHECKFIRE 210-D Display Module. In adverse conditions such as these and others, a high decibel alarm with or without flashing strobe (provided by others) may warn the operator the CHECKFIRE 210-D System is in an alarm condition, is in a fault condition or the fire suppression system is discharging.

Options for controlling these external devices include two internal programmable relays on the CHECKFIRE 210-D ICM, and the Discharge Pressure Switch. The relays can provide indication for system fault, shutdown, and alarm conditions. Options for powering external devices include the auxiliary power output from the ICM or connecting to the vehicle/equipment power.

For safety, plan to evacuate the vehicle/equipment at the earliest possible moment.

The display module pulsing LEDs and sounder are intended to alert the operator when the unit receives a fault signal or alarm condition from a detection device (before actuating the fire suppression system).

### SPECIFIC PLANNING INFORMATION

Review the following information to plan the CHECKFIRE 210-D System layout. Create a drawing of the proposed plan showing locations of components and cable on the vehicle/equipment. This will help avoid unforeseen installation problems. Once an acceptable layout is complete; record and keep it for future reference.

### CAUTION

Verify all mounting locations and methods of proposed equipment are approved by owner of vehicle/equipment manufacturer.

### Programming Options

The versatility of the CHECKFIRE 210-D System provides multiple options such as detection, user notification, and confirmation of system discharge. Review the following sections and determine proper programming for the system. Track programming selections on the Planning Checklist, see page 4-8.

#### PRESSURE SWITCH FEEDBACK

With the Pressure Switch Feedback option enabled, Detection Circuit #2 becomes the input circuit for System pressure switches. The System monitors the circuit for both open conditions and shorted conditions.

An open condition on the circuit is indicated by a Fault condition on Detection Circuit #2.

A shorted condition on the circuit is indicated by an alarm condition on Detection Circuit #2 and could be initiated by rising pressure in the expellant gas piping. When activated, the display module Discharge LED and sounder notify the operator of the fire suppression system discharge.

A programmable option for the pressure switch feedback is sending a release signal to PADs when the switch activates. This provides redundant activation of all associated PADs.

**Note:** When Pressure Switch Feedback is programmed, the Cross-Zone option is not available.

## CROSS-ZONE DETECTION

Selecting Cross-Zone Detection requires both detection circuits (#1 and #2) to have an alarm condition before the start of Time Delay #1 (TD1) and the automatic release process.

If an alarm condition is present on one detection circuit, the System will provide audible and visual alarm indication (pulsing 1 x 1 second). TD1 will not start until an alarm condition occurs in the other detection circuit. Once both detection circuits are in alarm, the System will start TD1 (pulsing 2 x 1 second).

If one of the detection circuits clears during TD1, the system returns to indicating audible and visual alarm indication only (pulsing 1 x 1 second) clearing TD1.

If both detection circuits stay in alarm condition during TD1 the system proceeds through time delays and automatically activates the fire suppression system.

Manual activation of the System is always available to the operator by pushing the “PUSH To Activate / Alarm When Lit” button, or operating an EMA.

**Note:** EMA activation will cause activation of the release circuit after a two second delay if the circuit is programmed for EMA functionality.

**Note:** When Cross-Zone is programmed, the Pressure Switch Feedback option is not available.

## ALARM ONLY

For certain situations requiring manual actuation of the fire suppression system, the CHECKFIRE 210-D System can be programmed to provide Alarm Only notification (pulsing 1 x 1 second) of an alarm condition on Detection Circuit #1, Detection Circuit #2, or both together. The Alarm Only programming provides visual and audible indication for the operator of an alarm condition and will not start the automatic release process for the fire suppression system.

If only one circuit is programmed to Alarm Only, the other circuit can function as an independent detection/release circuit.

### CAUTION

Programming both Detection Circuit #1 and Detection Circuit #2 for Alarm Only functionality will disable all automatic release functions of the CHECKFIRE 210-D System. Manual activation of the fire suppression system is required for release. Failure to manually activate the system can result in significant property damage or personnel injury.

When manual activation is required, perform one of the following to manually operate the system:

- Open guard door on CHECKFIRE 210-D Display Module (break visual seal), and push the “PUSH To Activate / Alarm When Lit” button.
- Pull ring pin and strike red button on an Electric Manual Actuator (EMA).

**Note:** EMA activation will cause activation of the release circuit after a two second delay, if EMA functionality is enabled on the circuit.

- If an optional pneumatic actuation system is installed, pull ring pin and strike red button on the pneumatic manual actuator.

**SPECIFIC PLANNING INFORMATION (Continued)**

**Programming Options (Continued)**

**TIME DELAYS AND RESTART PROGRAMMING**

Two programmable time delays are available with the CHECKFIRE 210-D System. Time Delay #1 (TD1) starts when a detection circuit receives an alarm condition (unless programmed for Alarm Only or Cross-Zone Detection). Time Delay #1 can be restarted by the operator. Time Delay #2 (TD2) starts at the end of TD1, and cannot be restarted.

The Time Delay #1 Restarts option allows the operator to restart TD1 by pushing the “DELAY/Reset/Silence” button. This gives the operator more time, if needed, before fire suppression system release and, if included, equipment shutdown. The Time Delay Restart option is programmable to one restart or unlimited restarts.

Determine the proper time delay for the hazard, type of equipment, and operating environment. Time delay should be used for safety of operator and others nearby. Time delay duration should be as minimal as needed, because the fire suppression system should be activated as soon as possible.

**NOTICE**

Factory Mutual approved installations allow a maximum Time Delay of 30 sec. To satisfy the FM requirements, factory defaults are set at:

TD1 = 10 seconds

TD2 = 10 seconds

Time Delay Restart of TD1 = 1

The total time delay including any extensions shall not exceed 30 seconds.

Time Delay and Restart programming provides the following options: See Table 4-1 for FM 5970 Approved time delay settings.

- Time Delay #1 (TD1) is the initial time delay period and can be programmed for 0, 5, 10 (default), or 15 seconds.
- Time Delay #2 (TD2) is a second time delay period between equipment shutdown (if programmed) and system activation, which can be programmed for 0, 5, 10 (default) or 15 seconds.
- Time Delay Restart of TD1 can be programmed for either 1 restart (default) or unlimited restarts.

Planning should include a selection for each option.

**Note:** Programming Time Delay Restarts to “unlimited” voids FM Approval.

**TABLE 4-1: FM APPROVED TIME DELAYS**

TD1 sec	TD2 sec			
	0	5	10	15
0	✓	✓	✓	✓
5	✓	✓	✓	✓
10	✓	✓	✓	—
15	✓	—	—	—

**Note:** All delay settings correspond to Time Delay Restarts being programmed for '1' restart. Programming Time Delay Restarts to 'unlimited' will void FM Approval.

**CAUTION**

TD1 is the delay period between an alarm condition and equipment shutdown. If using the shutdown relay function, programming TD1 to zero seconds results in immediate equipment shutdown and immediate start of TD2 upon initiation of an alarm condition

**CAUTION**

TD2 is the delay period between TD1 and fire suppression release. If using the shutdown relay function, programming TD2 to zero seconds results in immediate fire suppression release at the same time as equipment shutdown.

**CAUTION**

Programming both Time Delay #1 and Time Delay #2 to zero seconds results in immediate System activation following an alarm condition. This situation could lead to immediate equipment shutdown (if using the shutdown relay function) or other unforeseen issues which could result in significant property damage or personal injury.

**CAUTION**

Delay of system operation may allow the fire to intensify, which could result in a more difficult fire to suppress.

**EMA FUNCTIONALITY AND PROGRAMMING**

The Electric Manual Actuator (EMA) is a device that provides an electrically-supervised manual means of activating the suppression system. Depression of the red palm button will cause all relays programmed for Alarm or Shutdown to transfer state as well as activation of the release circuit. When the CHECKFIRE 210-D system is in a normal state of operation, the time between depression of the palm button and release circuit activation is two seconds to ensure a valid EMA signal is being sent to the ICM. If the system is in ISOLATE mode, this verification time delay is four seconds.

The following programming options are only available using the CHECKFIRE 210 PC Programmer.

**Isolate Mode EMA Actuation:** This feature controls EMA operation while the CHECKFIRE 210-D system is in ISOLATE mode. The default setting for this feature is ENABLED. When enabled, this allows EMA actuation when the system is in ISOLATE mode. If this setting is set to DISABLED, EMA actuation will not occur when the system is in ISOLATE mode. Instead, if a valid EMA signal is detected while in ISOLATE mode, after the four second delay period, the Display Module will annunciate a fault on the circuit by pulsing the corresponding AMBER detection circuit LED 2 x 10 seconds.

**Note:** Disabling EMA activation while in ISOLATE mode will not allow EMA activation during ISOLATE even if a detection circuit is programmed to enable EMA activation.

## SPECIFIC PLANNING INFORMATION (Continued)

### Programming Options (Continued)

#### EMA FUNCTIONALITY AND PROGRAMMING (Continued)

**Detection Circuit #1 EMA:** The default setting for this feature is ENABLED. When enabled, this allows EMA actuation on Detection circuit #1. A delay of two seconds occurs between EMA actuation and release circuit activation. When this programming feature is set to DISABLED, a valid EMA signal will not cause EMA activation of the system. Instead, the Detection Circuit #1 AMBER LED will pulse 2 x per second every 10 seconds, indicating an EMA signal was received on a circuit that is not programmed for EMA operation.

**Detection Circuit #2 EMA:** The default setting for this feature is ENABLED. When enabled, this allows EMA actuation on Detection circuit #2. A delay of two seconds occurs between EMA actuation and release circuit activation. When this programming feature is set to DISABLED, a valid EMA signal will not cause EMA activation of the system. Instead, the Detection Circuit #2 AMBER LED will pulse 2 x per second every 10 seconds, indicating an EMA signal was received on a circuit that is not programmed for EMA operation.

#### RELAY CIRCUITS #1 AND #2

The CHECKFIRE 210-D System includes two programmable internal, Form C relays (provides normally open (NO) and normally closed (NC) contacts) that can be programmed to transfer on a System alarm, fault or shutdown condition. These relays can control external audible and/or visual signaling devices for either alarm or fault indication. If programmed, relay #2 can be directly connected to equipment shutdown circuitry providing automatic equipment shutdown.

Contact Rating for both relays: 30 VDC nominal at 6 amps (resistive).

Relay #1 programming provides the following options:

- Alarm relay (default)
- Fault relay

Relay #2 programming provides the following options:

- Shutdown relay (default)
- Alarm relay

### Display Module Location

1. Mount Display Module in full view, easily accessible, and within reach of the operator. Select a flat surface that will properly support the Display Module during all vehicle/equipment operating and environmental conditions (e.g., shock and vibration).

**Note:** The Display Module should never be mounted in an area subject to pressure washing or steam cleaning.

2. Confirm the operator has access to the “PUSH To Activate / Alarm When Lit” and the “DELAY/Reset/Silence” buttons.

3. Select a location suitable for surface mounting (3/16 in. (4.7 mm) maximum thickness), or bracket mounting. For bracket mounting, use the optional CHECKFIRE 110/210 Mounting Bracket and secure with screws or bolts. The mounting surface must be flat to avoid strain on the bracket.
4. Confirm access for proper cable connection, periodic inspection, and maintenance. If surface mounted, access to the underside or rear of the mounting surface is necessary. Review the surrounding area to confirm the location will not interfere with normal vehicle/equipment maintenance or operation.

### NOTICE

The ambient temperature range for the Display Module location must not fall below  $-40^{\circ}\text{F}$  nor exceed  $185^{\circ}\text{F}$  ( $-40^{\circ}\text{C}$  to  $85^{\circ}\text{C}$ ).

**Note:** If plans include an optional pneumatic manual actuator in the operator's compartment, confirm the operator has access to the red strike button on the actuator. For detailed planning/installation guidelines, refer to the appropriate vehicle fire suppression system manual (latest revision).

### CHECKFIRE 210-D Circuit Cables

Plan on routing circuit cables in accessible locations, protected from undue wear, damage, and heat. Cables should not be installed in areas where temperature will exceed  $221^{\circ}\text{F}$  ( $105^{\circ}\text{C}$ ).

Keep cables as far away as possible from equipment electric cables, particularly power cables to and from generators and electric motors; also avoid:

- Antennas and associated cables
- Fire hazard areas
- Areas exposed to mechanical damage
- Proximity to moving parts
- Areas subject to debris accumulation
- Areas exposed to high temperatures (turbo chargers, exhaust equipment, or other equipment)
- Areas requiring access by equipment service and maintenance personnel

Cables must never be routed through or near sharp edges without being properly protected. The Bulkhead Cord Grip fits all cables and provides a cable pass through at a bulkhead.

## SPECIFIC PLANNING INFORMATION (Continued)

### Detection Circuit Cable

Connects input devices to the CHECKFIRE 210-D Interface Control Module (ICM) such as:

- Electric Manual Actuators (EMA)
- Linear Detectors

1. Determine appropriate detection method (Linear Detectors) and placement for specific cable end points.
2. Review Figure 4-1, plan route for the cable from the ICM to the detection component end points (record the end points for cable lengths) and use the following rules:
  - Detection Circuit “h” Cables can only be installed on the main trunk
  - Branch line must end with Detection Circuit Branch Terminator or EMA. The Detection Circuit “h” Cable provides a straight cable connection to Detection Circuit Cables and Linear Detectors
  - Detection Circuit Cable can be used on each end of linear wire as needed.
3. Select appropriate cable lengths for area of installation. Total detection circuit length is calculated with the Linear Detector length. Maximum total length of each detection circuit main trunk including the Linear Detection Cable shall not exceed 750 ft (228.6 m). Maximum length for individual branch lines shall not exceed 250 ft (76 m) each with a maximum quantity of branch circuits not to exceed 6.

### ELECTRIC MANUAL ACTUATOR (EMA)

If used, ensure the EMA actuation is enabled for the appropriate detection circuit on the ICM (for programming details see Section 5 – Installation and Programming). For more information, see EMA Functionality and Programming on page 4-3.

1. Locate EMAs where accessible, preferably in the path of egress and reachable from ground level. If EMA is required in the operator’s compartment for manual actuation, locate within line-of-sight and easy reach.
2. Connect EMA before other detection components on a branch circuit from the main detection circuit.
3. Only one EMA is allowed per branch circuit.

### LINEAR DETECTOR

Linear Detector connects directly to the main Detection Circuit Cable.

- Only install in main detection circuit trunk
  - If used, must be installed after EMAs
  - If last device, must include EOL Device for circuit supervision
1. Where possible, install Linear Detector above the hazard area or around the perimeter of a hazard compartment, preferably within normal airflow, for quick response. Do not allow struts, frame members, or other obstacles to act as heat shields between the hazard area and the detection cable.

## NOTICE

Maximum installed ambient temperature at the Linear Detector location is:

Red: 250 °F (121 °C)

White: 175 °F (79 °C)

2. The minimum bend radius for Linear Detector must not be less than 2 1/2 in. (64 mm). See Figure 4-1.
3. After reviewing the above instructions, select the appropriate length Linear Detector to cover the hazard areas.
4. Whenever possible make end point connections outside the hazard areas.
5. Keep the detector as far away as possible from equipment electric cables, particularly power cables to and from generators and electric motors.




FIGURE 4-1  
LINEAR DETECTOR INSTALLATION  
011793

### Detection Circuit – Remote Actuation

The CHECKFIRE Detection Circuit can be connected to a remote controller, PLC, or other appropriate components for remote activation of the CHECKFIRE 110-D or 210-D Detection System.

Three types of activation are available for installation:

1. DPDT Switch Activation – (Double Pole/Double Throw)
2. SPDT Switch Activation – (Single Pole/Double Throw)
3. Relay Activation

A 1/4 Watt 650 Ohm  $\pm$  5% resistor configuration option will cause the circuit to function similar to an Electric Manual Actuator (EMA). If the resistor is not used, the programmed time delays will be initiated when activated. The resistor is provided by others.

## SPECIFIC PLANNING INFORMATION (Continued)

### Optional Discharge Pressure Switch

Provides pressure switch feedback to the ICM through Detection Circuit #2.

The switch must be on a branch line in detection circuit #2 with an EOL Device completing the main trunk of the Detection Circuit "h" Cable.

**Note:** Pressure switch activates on expellant gas release.

### Display Cable

Connects Display Module to CHECKFIRE 210-D ICM.

- Communicates commands, and system status with ICM
  1. Determine location of display module for specific cable end points.
  2. Select appropriate cable lengths for area of installation. Maximum circuit length is 200 ft (60.96 m).

### Release Circuit Cable

Connects Electric-Pneumatic Actuators to CHECKFIRE 210-D ICM.

- System activates a maximum of 8 Actuators.
- For electrical activation include a Release Circuit Drop Cable for each actuator.
- Release Circuit "h" Cable required for each additional actuator.
- For optional pneumatic actuation refer to appropriate vehicle fire suppression system manual (latest revision):
  1. Determine location of agent tanks, expellant gas cartridge assemblies, and actuators for specific cable end points.
  2. Select appropriate cable lengths for area of installation.

### Release Circuit "h" Cable

The Release Circuit "h" Cable provides a straight cable connection to Release Circuit Cables, and release Circuit Drop Cables. All Release Circuit installation rules apply to the use of the release "h" cables. Review the rules in the *Release Circuit Cables* section page 5-13.

### Relay Circuit Cable

Connects external devices and components to CHECKFIRE 210-D ICM.

- System controls external devices (supplied by others) using two (2) internal, programmable, Form C relays
- Relays can be programmed to provide indication for Alarm or Fault (Relay #1), and Shutdown or Alarm (Relay #2).
  1. Determine location of connection points for external devices.
  2. Select appropriate cable lengths for area of installation.

### Auxiliary Output Circuit Cable

Provides a power source via the CHECKFIRE 210-D ICM for use with external components and devices.

- Auxiliary Output Voltage is only available if operating the CHECKFIRE 210-D System on external power
  1. Determine location of connection points for external devices.
  2. Select appropriate cable lengths for area of installation. Maximum circuit current rating is 1.5A.

### Power Circuit Cables

Connects CHECKFIRE 210-D ICM to 12/24 VDC nominal external power source using the Power Circuit Cable and the Fused Power Circuit Cable (connects to external power supply).

1. Determine location of power source that will provide the current load capabilities. See page 1-1 for current load capabilities.
2. Select appropriate cable lengths for area of installation.

### Label Package

Include a Label Package to identify specific procedures of the system to equipment operators.

### System Layout

Once components are selected and locations are determined, complete a final drawing of the system layout. This drawing should at a minimum include the following:

- Hazard area locations
- Component locations (include external power source)
- Routes for all connecting circuits with cable lengths identified.

Indicate areas where cable must pass-through bulkheads. (Confirm acceptable pass-through locations with vehicle/equipment manufacturer.) The drawing should be as precise as possible to avoid installation problems later.

Compile a list of components to confirm system includes all required parts (review Planning Checklist, page 4-8). The CHECKFIRE System is complete when all necessary components combine to provide automatic fire detection and activation of the fire suppression system for protected areas.

## PLANNING CHECKLIST

(COPY BEFORE USE)

### Components

- CHECKFIRE 210-D Display Module
- Mounting Bracket
- Display Cable
- CHECKFIRE 210-D Interface Control Module
- Detection Circuit Cables, Detection Circuit “h” Cable, EOL Device, and Branch Terminators
- Electric Manual Actuators (EMA) and Brackets
- Linear Detectors
- Release Circuit Cables, and Release Circuit “h” Cable
- Release Circuit Drop Cables
- ▶  Release Circuit Terminator
- PADs
- Electric-Pneumatic Actuators (may be supplied with agent tanks)
- Pneumatic Manual Actuators (optional)
- Relay Circuit Cables
- Auxiliary Output Cables
- Power Circuit Cables and Fused Power Circuit Cable
- Discharge Pressure Switch, if applicable
- Cable Grommets (3-hole, 2-hole, Linear Detector)
- Double-Loop Cable Ties
- Bulkhead Cord Grips
- Alarms and/or Strobes
- Label Package

**Note:** For part numbers, see Section 10 – Appendix, Component Index, page 10-1.

### Programming Options

(Certain options will affect availability of other options)

#### Pressure Switch Feedback (PSF)

- Disabled (default)
- Enabled, uses Detection Circuit #2 for pressure switch input.
  - Enable auto-release activation of PADs

**Note:** Cross-Zone not available

#### Cross-Zone Protection

- Disabled (default)
- Enabled, Detection Circuit #1 and #2 are independent detection and both must detect alarm condition to start time delays.

**Note:** Pressure Switch Feedback not available

#### Detection Circuit #1 (Cross-Zone disabled)

- Independent detection/release (default)
- Detection (Alarm Only)

#### Detection Circuit #2 (Cross-Zone disabled)

- Independent detection/release (default)
- Detection (Alarm Only)

#### Detection Circuit #2 (Pressure Switch Feedback enabled)

- Alarm Only (default)
- Release activation (PADs)

#### Time Delay #1 (Seconds)

- 0
- 5
- 10 (default)
- 15

#### Time Delay #2 (Seconds)

- 0
- 5
- 10 (default)
- 15

#### Time Delay #1 (Restarts)

- 1 (default)
- Unlimited

#### Relay Circuit #1

- Alarm (default)
- Fault

#### Relay Circuit #2

- Shutdown (default)
- Alarm

**NOTES:**

## INSTALLATION

Before installing the CHECKFIRE 210-D Detection and Actuation System, Section 4 – System Planning should be studied in its entirety. In addition, a resulting system layout drawing with information on hazard areas, component locations, and routing of connecting circuits, along with all cable lengths identified, should be available. Review this drawing and become familiar with all applicable steps and instructions before installing any component.

### NOTICE

For ease of installation, the fire suppression system should be installed before the detection and actuation system.

When supporting components from the vehicle/equipment make certain any support device requiring drilling or welding is approved by owner or vehicle/equipment manufacturer.

## MOUNTING INTERFACE CONTROL MODULE (ICM)

Mount on a flat surface that will properly support the ICM during all vehicle/equipment operating and environmental conditions (e.g. shock and vibration). See Figure 5-1.

1. Refer to layout drawing for planned location. Verify the location meets approval of the vehicle/equipment owner and/or vehicle/equipment service manager.
2. Confirm access to the ICM for proper cable connections, periodic inspections, and maintenance. Verify module location and connections will not interfere with vehicle/equipment operation, service, and maintenance.
3. Using the ICM mounting plate as a template (see Figure 5-1), mark and drill 9/32 in. (7 mm) holes in the flat surface (4 places).
4. Secure ICM to mounting surface using appropriate length fasteners (1/4 in. (6 mm) screws or bolts with lock washers and nuts). See Torque Specifications in the Appendix for the Nyloc nuts.



FIGURE 5-1  
ICM SURFACE MOUNTING  
011896

## CABLE CONNECTIVITY

### General Instructions for Routing

1. Follow planned route in the layout drawing and install each circuit starting at the ICM connection and work outward.
2. Completely install one circuit at a time, finishing with the power circuit.
3. All connections shall be supported using Cable Grommets, Rubber Coated P-Clamps, Double Loop Cable Ties, or an industry acceptable method of attachment. See Figure 5-2.
4. All cable assemblies and connectors must be supported appropriately. See Figure 5-3.
5. Use additional supports to ensure cable is not subject to snagging, crushing, and abrasion.

### NOTICE

Cables should not be supported by hydraulic hoses.

6. Allow appropriate slack through areas that are intended to move under normal vehicle/equipment operation.
7. Avoid routing cables in areas where they may be used as handhold or footrests when equipment service is performed or during operation.
8. Cable must never be routed through a hole or near sharp edges without being properly protected.
9. When cables pass through a partition, it is recommended to use a Bulkhead Cord Grip.
10. Double-loop cable ties may also be used to secure cable grommets if necessary.





FIGURE 5-2  
DOUBLE-LOOP CABLE TIE  
009211

**CABLE CONNECTIVITY (Continued)**

**General Instructions for Routing (Continued)**



ITEM	DESCRIPTION	IN.	(mm)
A	DISTANCE BETWEEN CABLE SUPPORTS	10 TO 18	(254 TO 457)
B	FIRST CABLE SUPPORT	5 TO 7	(127 TO 178)
C	STRAIGHT CONDUCTOR FROM BACK OF CONNECTOR	1/2	(13)
D	SINGLE CONDUCTOR BEND RADIUS	3/4	(19)

**FIGURE 5-3**  
**GENERAL FIELD-WIREABLE INSTALLATION**  
 011891/ 011891a

**General Requirements for Cable Assembly**

Review Figures 5-3 and 5-4 for general guidance for all CHECKFIRE 210-D Field Wireable System Cables.

- All unused single conductor wires shall be cut off flush with the jacketed cable and be covered within the shrink tube.
- Use the required Deutsch HDT-48-00 Crimping Tool or equivalent to assemble the solid pins and sockets for the field wireable cables.
- Crimp sockets or pins according to crimping tool instruction
- Insert wire with socket or pin into rear of the connector
  - Push until click is heard or felt.
  - Pull back slightly on wire to confirm proper installation
- Receptacles
  - Once all pins are inserted, use a needle nose pliers to insert wedgelock, pressing firmly until the wedgelock clicks in place.
- Plugs
  - Once all contacts are in place, the wedgelock may be inserted by hand. Press until the wedgelock clicks in place.
- Back shells are required to maintain IP rating.
- Sealing plugs are required on all unused connector positions to maintain the connector IP rating

Note: Per compatibility issues, connector wedgelocks are NOT interchangeable and shall not be mixed.



**FIGURE 5-4**  
**CONNECTOR PARTS FOR INSTALLATION**  
 011894

**DISPLAY CIRCUIT**

The Display Module cable at the CHECKFIRE 210-D ICM is the starting point for the display circuit. See Figure 5-5.


The display circuit is a single circuit providing connection between the ICM and the CHECKFIRE 210-D Display Module for communication of commands and system status.



**FIGURE 5-5**  
**DISPLAY CIRCUIT CONNECTION**  
 011897


**Display Circuit Connector Assembly (Figure 5-6)**

ITEM	DESCRIPTION	IN.	(mm)
A	DISTANCE OF UNPROTECTED CONDUCTORS	2 1/4 TO 4	(57 TO 102)
B	SINGLE CONDUCTOR STRIPPING	1/4 TO 3/8	(6 TO 8)
C	1/16 IN. DRAIN WIRE SHRINK TUBE	1/4 TO 3/8	(6 TO 8)
D	3/4 IN. SHRINK TUBE - SINGLE CONDUCTOR	3/8 TO 1/2	(10 TO 13)



PIN #	COLOR	CRIMP SIZE
1	RED	18 AWG (0.75 mm <sup>2</sup> )
2	BLACK	18 AWG (0.75 mm <sup>2</sup> )
3	DRAIN	20 AWG (0.5 mm <sup>2</sup> )
4	WHITE	20 AWG (0.5 mm <sup>2</sup> )
5	BLUE	20 AWG (0.5 mm <sup>2</sup> )
6	NOT USED	SEALING PLUG

**NOTE:** SHRINK TUBE IS REQUIRED ON THE DRAIN WIRE TO MAINTAIN PROPER IP RATING AT THE CONNECTOR.



**FIGURE 5-6**  
**DISPLAY CIRCUIT CONNECTOR ASSEMBLY**  
 011888b/ 011888

### CHECKFIRE 210-D DISPLAY MODULE

The CHECKFIRE 210-D Display Module may be surface mounted (3/16 in. (4.7 mm) maximum thickness) or bracket mounted. For bracket mounting, use the CHECKFIRE 110/210 Mounting Bracket. Index pins on the display module prevent rotation.

**Note:** The display module should never be mounted in an area subject to pressure washing or steam cleaning.

#### Surface Mounting Instructions

Although recommended, the CHECKFIRE 210-D Display Module does not require a bracket when surface mounting in a flat location. The location must properly support the display module during all vehicle/equipment environmental and operating conditions (e.g., shock and vibration).

1. Refer to layout drawing for planned location and determine a position within operator's reach with the best viewing angle for display module LEDs and easy access to display module buttons.
2. Drill three holes matching the correct diameter and index pin layout for surface mounting, see Figure 5-7.
  - a. Use the foam gasket as a template to carefully mark hole locations. See Figure 5-8.
  - b. After drilling holes, remove burrs and sharp edges.
3. Remove protective backing exposing gasket adhesive then install foam gasket on Display Module.




FIGURE 5-7

SURFACE MOUNTING TEMPLATE (FOAM GASKET)

009203



FIGURE 5-8


INDEX PINS AND THREADED BOSS

009303

4. Carefully feed cables through drilled hole, rubber washer, and enclosure nut.
5. Fit index pins and threaded boss into the drilled holes.
6. Hand-tighten enclosure nut on threaded boss, see Figure 5-9.

#### NOTICE

Only hand-tighten enclosure nut, do not use mechanical force such as a wrench.



TOP VIEW



FIGURE 5-9


SURFACE MOUNT 210-D DISPLAY MODULE

009304d/ 009305d/ 009306d

**CHECKFIRE 210-D DISPLAY MODULE (Continued)**

**Bracket Mounting Instructions**

- ▶ Bracket mounting requires the CHECKFIRE 110/210 Mounting Bracket, see Figure 5-10. The bracket is a two piece, multi-position bracket for securing the Display Module in a variety of configurations. Mount on a flat surface that will properly support the Display Module during all vehicle/equipment operating and environmental conditions (e.g. shock and vibration).



**FIGURE 5-10**  
**CHECKFIRE 110/210 MOUNTING BRACKET**  
 009181

- ▶ 1. Refer to layout drawing for planned location and determine a position within the operator's reach with the best viewing angle for Display Module LEDs and easy access to Display Module buttons. Verify the location meets approval of the vehicle/equipment owner and/or vehicle/equipment service manager. See Figure 5-11 for sample mounting options. Note the positions of the swivel mount and connectors.




**FIGURE 5-11**  
**SAMPLE MOUNTING OPTIONS**  
 009307\_1-2/ 009308\_1-2/ 009309\_1-2/ 009309a-b

**CHECKFIRE 210-D DISPLAY MODULE (Continued)**

**Bracket Mounting Instructions (Continued)**

2. Confirm access to the display module for proper cable connections, periodic inspections, and maintenance. Verify module location and connections will not interfere with vehicle/equipment operation, service, and maintenance.
3. Using the bracket base as a template (see Figure 5-12), mark and drill 9/32 in. (7 mm) holes in the flat surface




**FIGURE 5-12  
BRACKET BASE FRONT VIEW**

009113

4. If needed, mark a 1 5/8 in. (42 mm) dia. circle in the mounting surface, matching center of the 7/8 in. x 1 3/4 in. (22 mm x 44 mm) opening for cables passing through the mounting surface. See Figure 5-12. Drill the marked hole. Remove burrs and sharp edges; protect cables as needed.
5. Secure base to mounting surface using appropriate length fasteners (1/4 in. [6 mm] screws or bolts with lock washers and nuts).
6. Attach display module to swivel mount according to the position determined in Step 1. See Figure 5-13.
  - a. Retrieve enclosure nut and rubber washer for threaded boss from separate bag in the CHECKFIRE 210-D Display Module.
  - b. Carefully feed cables through center hole in Swivel Mount, rubber washer, and enclosure nut.
  - c. Insert index pins into index holes and hand-tighten enclosure nut to threaded boss.

**NOTICE**

Only hand-tighten enclosure nut, do not use mechanical force such as a wrench.



**FIGURE 5-13  
HAND-TIGHTEN ENCLOSURE NUT**

011800-1/011800-2

7. If required, feed cables through opening in bracket base. Reinstall the Swivel Mount to the base according to the position determined in Step 1. Carefully align joint teeth and secure with the swivel joint screws to lock swivel mount in place. Do not over tighten, 20 in.-lb to 25 in.-lb (2.26 N·m to 2.82 N·m) maximum. See Figure 5-14.



**FIGURE 5-14  
MOUNTING BRACKET WITH  
CHECKFIRE 210-D DISPLAY MODULE**

011801

**DETECTION CIRCUIT**


The Detection Circuit #1 and #2 cables at the CHECKFIRE 210-D ICM are starting points for the detection circuits. See Figures 5-15 and 5-16. Each detection circuit consists of a main trunk and branch lines may be added with a Detection Circuit “h” Cable on the main trunk. See Figure 5-17 for sample branch lines.




**FIGURE 5-15**  
**DETECTION CIRCUIT CONNECTIONS**  
 011898

**Detection Circuit Connector Assembly (Figure 5-16)**

ITEM	DESCRIPTION	IN.	(mm)
A	DISTANCE OF UNPROTECTED CONDUCTORS	2 1/4 TO 7	57 TO 178
B	SINGLE CONDUCTOR STRIPPING	1/4 TO 3/8	6 TO 8
C	1/2 IN. SHRINK TUBE - SINGLE CONDUCTOR	3/8 TO 1/2	10 TO 13



POSITION	COLOR	CRIMP SIZE
1	BROWN	18 AWG (0.75 mm <sup>2</sup> )
2	WHITE	18 AWG (0.75 mm <sup>2</sup> )
3	BLUE	18 AWG (0.75 mm <sup>2</sup> )
4	BLACK	18 AWG (0.75 mm <sup>2</sup> )
5	NOT USED	PLUG
6	NOT USED	PLUG




\* BLACK PIN #4 UNDER #5 NOT USED

**FIGURE 5-16**  
**DETECTION CIRCUIT CONNECTOR ASSEMBLY**  
 011887b/ 011887

Install Detection Circuits using the following rules:

1. An Electric Manual Actuator (EMA), if used, must be installed prior to any other detection device with a Detection Circuit “h” Cable. See Figure 5-17.




**FIGURE 5-17**  
**DETECTION CIRCUIT “h” CABLE SAMPLE INSTALLATION**  
 011794

2. Install each EMA on a separate branch (only one device on a branch). See Figure 5-17.

**CAUTION**

Do not terminate any branch with an EOL Device. Use Branch Terminator only.

3. The Linear Detector may be installed anywhere in the main detection circuit trunk after the EMA. The Linear Detector is terminated with an EOL Device or a Field Wireable EOL Resistor. See Figure 5-18.



**FIGURE 5-18**  
**DETECTION CIRCUIT – LINEAR DETECTOR**  
 011795

Review complete installation to verify correctness.

**DETECTION CIRCUIT “h” CABLE**

The Detection Circuit “h” Cable, see Figure 5-19, provides a straight cable connection to detection circuit cables, and Linear Detectors. Use the hole in the over-mold body to mount the cable or other industry acceptable methods of attachment.



**FIGURE 5-19**  
**DETECTION CIRCUIT “h” CABLE**  
 011778

### LINEAR DETECTOR


Install Linear Detector throughout the hazard area by only connecting directly to the main detection circuit trunk.

#### NOTICE

**The minimum bend radius for the Linear Detector must not be less than 2 1/2 in. (64 mm) (see Figure 5-21).**

Keep the following in mind when installing a Linear Detector:

- Make certain Linear Detector routing allows direct exposure to heat resulting from a fire
  - Choose routing locations where heat is likely to travel to or through quickly in the event of a fire
1. Make sure detection circuit cable is completely installed from CHECKFIRE 210-D ICM to hazard area. Start installation of the Linear Detector at the end of the detection circuit cable.
  2. Install Linear Detector above hazard area or around perimeter of a hazard compartment so it can react to escaping heat. Refer to layout drawing. Do not allow struts, frame members, or other obstacles to act as heat shields between hazard and detector cable.
  3. Do **NOT** install Linear Detector within 12 in. (305 mm) of any area that will become extremely hot during operation, such as:
    - Exhaust manifolds
    - Exhaust tubes/mufflers
    - Turbochargers
  4. Secure Linear Detector every 12 in. to 18 in. (305 mm to 454 mm) using a Linear Detector Cable Grommet or equivalent. Protect wire against abrasion and damage. Where it is not possible to use P-Clips, a double-loop cable tie and Linear Detector Cable Grommet is acceptable to provide separation between cable and securing point. Secure more often if necessary. See Figure 5-20.




**FIGURE 5-20**  
**GROMMET AND DOUBLE-LOOP CABLE TIE**  
009213

#### CAUTION

Linear Detector must never be routed through a hole or near sharp edges without being properly protected. Failure to protect the cable from being cut or abraded could cause a fault condition or false alarm condition, potentially leading to a false activation or detection failure.

When a Linear Detector must pass-through a partition it is recommended to use a Bulkhead Cord Grip designed for the appropriate cable.

5. Install an EOL Device at the end of the Linear Detector, if last device to complete the circuit. See Figure 5-21.




**FIGURE 5-21**  
**SAMPLE LINEAR DETECTOR INSTALLATION**  
001793

#### Linear Detector Connector Assembly

When splicing Linear Detectors to Detection Circuit Cables, the white and black single conductors will be used to complete the circuit.

All unused single conductor wires shall be cut off flush with the jacketed cable and be covered within the shrink tube.

The CHECKFIRE In-Line Splice Kit is used to make in-line splices of the Linear Detection Cable. It can also be used to make the transition splice from Detection Circuit Cable to Linear Detection Cable. See Figure 5-22.




**FIGURE 5-22**  
**IN-LINE SPLICE KIT**  
007045a

**LINEAR DETECTOR (Continued)**

**Linear Detector Connector Assembly (Continued)**

To properly make a detection circuit splice, the following steps should be completed:

1. Remove 3/4 in. (20 mm) of the wire outer jacket, exposing the internal clear wrap.
2. Remove 3/4 in. (20 mm) of the wire clear wrap, being careful not to damage the internal heat sensitive conductors.
3. Strip 3/8 in. (10 mm) of heat sensitive insulation from the inner conductors, leaving 3/8 in. (10 mm) of insulation on each. When connecting the Linear Detector Cable to the Detection Circuit Cable, the white and black single conductors will be used to complete the circuit.
4. Loosen the compression nut of the strain relief assembly and slide the assembly over the end of the wire as shown in Figure 5-23. On the same wire end, slide the splice body onto the wire.
5. On the opposite wire, repeat Steps 1-3, then loosen the compression nut on another strain relief assembly and slide that assembly onto the wire.
6. Insert splice block on end of one set of exposed wires. Wires must be inserted far enough into splice block to protrude out the opposite side.
7. Insert other set of exposed detection wire through the opposite side of the splice block, again making certain that they protrude out the opposite side.
8. Tighten screws on splice block.
9. Once splice block assembly is completed on both sets of wire ends, apply Dow Corning 737 or equivalent sealant to strain relief threads going into the splice body.
10. Securely tighten the strain relief into the splice body.  
 Note: Do not tighten compression nut onto wire at this time.
11. Slide splice body assembly near splice block. Fill splice body approximately 3/4 full with Dow Corning 737 or equivalent sealant and pull splice body assembly over splice block so splice block is located approximately half way inside splice body. This operation should result in the splice block being enclosed in the sealant.
12. Fill remainder of splice body cavity with the sealant.
13. Apply Dow Corning 737 or equivalent sealant to the thread on the unattached strain relief lock nut and thread this strain relief assembly unto the splice body.
14. With a wrench on both strain relief locks, simultaneously tighten both ends.
15. Complete assembly operation by securely tightening the strain relief onto the detection wire.



**FIGURE 5-23**  
**IN-LINE SPLICE KIT**  
 007045/ 007045a


**End-of-Line (EOL) Resistor**

An End-of-Line (EOL) Resistor must be installed at the end of the main trunk circuit.

Two options are available, a field wireable EOL Resistor or a Detection Circuit EOL Device (DT Style).

If using the EOL Device (DT Style), the following is required.

1. To make the EOL connection, a 1 ft (300 mm) minimum piece of Detection Circuit Cable must be installed at the end of the Linear Detector.
2. Connect the Detection Circuit Cable to the Linear Detector using the In-Line Splice Kit and follow the splice kit steps to make a connection.
3. On the opposite end of the Detection Circuit Cable, install a 6-pin plug, see Figure 5-24. See the General Requirements for Cable Assembly (Page 5-2) and Detection Circuit Connector Assembly (Figure 5-16) (Page 5-6) to complete this step.
4. Connect an EOL device to the installed 6 pin plug as required.



**FIGURE 5-24**  
**6-PIN PLUG FROM CONNECTOR KIT AND EOL DEVICE**  
 007045a/ 011807

## LINEAR DETECTOR (Continued)

### End-of-Line (EOL) Resistor (Continued)


If using the Field Wireable End-of-Line Resistor the following steps are required.

An End-of-Line (EOL) Resistor must be the final connection on the Trunk Circuit. See Figure 5-25.

Install an EOL resistor assembly to the far end of the detection wire.

To properly attach the EOL Resistor assembly, complete the following steps (see Figure 5-25).

1. Strip 1 in. (25 mm) of outer jacket off the linear detection wire.
2. Strip 1/4 in. (6 mm) of insulation off the two internal wires.
3. Loosen the lock nut on the strain relief connector and slide both lock nut and connector over end of wire.
4. Loosen screws on terminal block, insert bare wires, and securely tighten screws.
5. Apply a small amount of Dow Corning 737 or equivalent sealant on male threads of strain relief connector.
6. Screw EOL cap to strain relief connector.
7. Tighten lock nut onto detection wire.
8. Secure EOL cap to support device.



**FIGURE 5-25**  
**END-OF-LINE RESISTOR ASSEMBLY**  
002774a

### Linear detection wire to detection cable connection

1. Disassemble the splice kit, see Figure 5-26. Make sure the sealing caps are loose. When connecting Linear Wire to Linear Wire swap out the large grommet for the small, sealed grommet.



**FIGURE 5-26**

012102

2. Insert the detection cable through the large grommet and body and push the linear detector wire through the small sealed grommet. The inner piece of the grommet pushes out. See Figure 5-27.


**Note:** Either cable can be inserted into either side of the splice kit. Large and small grommets may be on opposites sides from what is shown.



**FIGURE 5-27**

012103

3. For the detection cable, strip 1 in. to 1 1/4 in. (25 mm to 32 mm) off the detection cable jacket and trim any braided shielding back to the cable jacket. Strip 1/4 in. to 3/8 in. (6 mm to 10 mm) off the black and white conductors and trim the remaining conductors flush with the stripped back cable jacket along with any filler material. For the linear detector, strip 1 in. to 1 1/4 in. (25 mm to 32 mm) off the cable jacket and trim the plastic wrap back to the cable jacket. Strip 1/4 in. to 3/8 in. (6 mm to 10 mm) off each green conductor. See Figure 5-28.



**FIGURE 5-28**

012104

**LINEAR DETECTOR (Continued)**

**Linear detection wire to detection cable connection (Continued)**

- Choose any two sets of terminals (recommended to use terminals labeled N and L), loosen the screws on each side and tighten the screws on the unused terminal. Insert the conductors into the contact carrier and torque screws to 5-7 in.-lbs (0.6 N·m to 0.8 N·m) See Figure 5-29.

**Note:** – The wires should be visible in the hole between the screws.  
 – Either cable can be inserted into either side of the splice kit. Large and small grommets may be on opposite sides from what is shown.



**FIGURE 5-29**  
012105

- Push the contact carrier into the body.
- Tighten each connection one at a time. Tighten the thread adapter to main body and torque to 14 in.-lbs to 16 in.-lbs (1.6 N·m to 1.8 N·m). Torque both sealing caps to 14 in.-lbs to 16 in.-lbs (1.6 N·m to 1.8 N·m). See Figure 5-30.



**FIGURE 5-30**  
012106

**Linear detection wire with End-of-Line (EOL) Resistor**

- Disassemble the splice kit, see Figure 5-31. Swap out the large grommet for the small sealed grommet. Make sure the sealing caps are loose.

**Note:** Large and small grommets may be on opposite sides from what is shown.




**FIGURE 5-31**  
012091

- Push the linear detection wire through the sealed grommet. The inner piece of grommet pushes out. See Figure 5-32.



**FIGURE 5-32**  
012092

- For the linear detector, strip 1 in. to 1 1/4 in. (25 mm to 32 mm) off the cable jacket and trim the plastic wrap back to the cable jacket. Strip 1/4 in. to 3/8 in. (6 mm to 10 mm) off each green conductor. Bend the resistor to fit inside the contacts and trim leads 3/8 in. to 1/2 in. (10 mm to 12 mm) to sit next to contact carrier (see Figure 5-33).



A	1 in. to 1 1/4 in. (20 mm to 25 mm)
B	1/4 in. to 3/8 in. (6 mm to 10 mm)



A	3/8 in. to 1/2 in. (10 mm to 12 mm)
---	-------------------------------------

**FIGURE 5-33**  
012093/ 012089/012090

### LINEAR DETECTOR (Continued)

#### Linear detection wire with End-of-Line (EOL) Resistor (Continued)

- Choose any two sets of terminals (recommended to use terminals labeled N and L), loosen the screws on each side and tighten the screws on the unused terminal. Insert the conductors into the contact carrier and torque screws to 5 in.-lbs to 7 in.-lbs (0.6 N·m to 0.8 N·m). See Figure 5-34.



FIGURE 5-34  
012094

- Push the contact carrier into the body.
- Tighten each connection one at a time. Tighten the thread adapter to the main body and torque to 14 in.-lbs to 16 in.-lbs (1.6 N·m to 1.8 N·m). Torque sealing caps with the linear detector to 14 in.-lbs to 16 in.-lbs (1.6 N·m to 1.8 N·m), and torque the sealing cap without cable to 8 in.-lbs to 10 in.-lbs (0.9 N·m to 1.1 N·m). See Figure 5-35.



FIGURE 5-35  
012095

### ELECTRIC MANUAL ACTUATOR (EMA)

Refer to layout drawing and install Electric Manual Actuator at locations in a path of operator egress and accessible from ground level, when possible. Confirm Detection Circuit branch for the EMA is prior to any detection device in the main detection circuit trunk.

EMA may be surface (1/4 in. (6 mm) maximum thickness) or bracket mounted. For bracket mounting use the EMA Bracket.

#### Surface Mounting Instructions

- Determine the location of the EMA.
- Mark the center of the EMA Mounting hole, and the center of the keyway hole.
- Drill the 1/4 in. (6 mm) keyway hole first followed by the 1 9/16 in. (40 mm) hole second.
- Deburr and smooth edges of the holes. See Figure 5-36.





FIGURE 5-36  
EMA SURFACE MOUNT DIMENSIONS  
011781/ 009216a

- Remove nut and rubber washer from threaded boss and insert boss through drilled hole fitting index nub into slot. Install rubber washer between EMA and EMA bracket. Place plastic nut below EMA and hand tighten. Do not apply mechanical force. See Figure 5-37.

#### NOTICE

Only hand-tighten nut, do not use mechanical force such as a wrench.

**ELECTRIC MANUAL ACTUATOR (EMA) (Continued)**  
**Bracket Mounting Instructions (Continued)**



**FIGURE 5-37**  
**EMA SURFACE MOUNT INSTALLED**  
 011781/011925

**Bracket Mounting Instructions**

1. Install the EMA Bracket by bolting or welding.
  - a. **Bolting:** Using bracket base as a template (see Figure 5-28), mark and drill 7/16 in. (11 mm) holes in flat surface (2 places). Secure bracket with 3/8 in. (9 mm) corrosion resistant bolts of the appropriate length with lock washers and nuts.
  - b. **Welding:** Confirm intended surface is approved for welding. To avoid corrosion, paint welded surfaces after welding is complete and surface temperature is normal.



**FIGURE 5-38**  
**EMA BRACKET MOUNT**  
 011797


2. Once the EMA bracket is securely mounted, remove nut from threaded boss on EMA. Position EMA in bracket with RED strike button (and pull pin) facing in desired direction (fit index nub into desired slot). Install rubber washer and hand-tighten nut on threaded boss.

**Note:** Pull pin may need to be removed and inserted in the opposite direction for proper fit. See Figure 5-39.

**NOTICE**

Only hand-tighten nut, do not use mechanical force such as a wrench.

**Note:** Install visual seal (supplied by others) when instructed in Section 6 – Operational Test and Place in Service.




**FIGURE 5-39**  
**EMA INSTALLED IN BRACKET**  
 011926

**CHECKFIRE 210-D REMOTE ACTIVATION**


Using bulk cabling or removing one end of a made-to-length cable, complete the following steps:

1. Strip wires back to expose the four wires used to make a Detection Circuit Field Wireable Cable
2. Make a connection with the wire from Step 1 to the connector on the Detection Circuit “h” cable on a branch circuit.
3. If installed on a shared detection circuit, the remote activation wire connections must be installed prior to any Detection Circuit Cable.
4. Follow the figure connection for the type of activation required. See Figures 5-40 to 5-42.




**FIGURE 5-40**  
**DPDT SWITCH ACTIVATION**  
 011927 / 009610

**CHECKFIRE 210-D REMOTE ACTIVATION (Continued)**



**FIGURE 5-41**  
**DPST SWITCH ACTIVATION**  
011927/ 009611



**FIGURE 5-42**  
**RELAY ACTIVATION**  
011927/ 009609


**DISCHARGE PRESSURE SWITCH**

Standard installation of the Discharge Pressure Switch is at the agent tank (see Figure 5-43).

**CAUTION**


Locate pressure switch next to agent tank at end of expellant gas line. Failure to comply will cause pressure switch to not function properly.

1. Install pressure switch in expellant gas actuation line next to agent tank inlet port. Make certain to protect switch and connections from potential damage.



**FIGURE 5-43**  
**INSTALLED PRESSURE SWITCH**  
011930

2. The switch installs in a standard 1/4 in. NPT female fitting. Insert the included 1/4 in. tee between expellant gas line hose from actuator and tank inlet port. Use TEFLON tape on the male threads. See Figure 5-44 for proper wrench grip area.



**FIGURE 5-44**  
**PRESSURE SWITCH WRENCH GRIP AREA**  
009231

**CAUTION**

When threading the pressure switch into the expellant gas line tee, DO NOT apply torque directly to the metal switch body. Failure to comply may result in damage to the switch. Tighten ONLY by applying torque to the 1/4 in. NPT male pressure fitting. See Figure 5-44.

**CAUTION**

DO NOT install the pressure switch in the fire hazard area or in any area where the ambient temperature will exceed 175 °F (79 °C). Failure to comply may prevent the pressure switch from functioning properly.

**DISCHARGE PRESSURE SWITCH (Continued)**

**Discharge Pressure Switch Reset**


To reset the pressure switch, press the red reset button located on the back of the switch. An audible click should be heard. See Figures 5-43 and 5-44.

**CAUTION**

The Discharge Pressure Switch must be manually reset **before** resetting the CHECKFIRE system. Failure to reset the switch could result in system activation.

**System Connection**

The Discharge Pressure Switch includes a connector for direct connection to Detection Circuit #2. Use a Detection Circuit “h” Cable to connect the switch on the branch line. Install a Detection Circuit EOL Device to complete Detection Circuit #2. See Figure 5-45.




**FIGURE 5-45**  
**DETECTION CIRCUIT #2 CONNECTION**  
 011931

**RELAY CIRCUIT**

The Relay #1 & #2 Output cable at the CHECKFIRE 210-D ICM is the starting point for the relay circuits, see Figure 5-46. Each circuit provides connection points to contacts for two internal SPDT Form C relays. See Figure 5-47. The relays can be used to activate external notification devices or provide inputs to vehicle/equipment onboard monitoring systems. Connections to vehicle/equipment components are made by others. See Figure 5-47 for the connector assembly information.




**FIGURE 5-46**  
**RELAY CIRCUIT CONNECTION**  
 011899




**FIGURE 5-47**  
**RELAY CIRCUIT CONDUCTORS**  
 009317

**Relay Circuit Connector Assembly (Figure 5-48)**

ITEM	DESCRIPTION	IN.	(mm)
A	DISTANCE OF UNPROTECTED CONDUCTORS	2 1/4 TO 7	(57 TO 178)
B	SINGLE CONDUCTOR STRIPPING	1/4 TO 3/8	(6 TO 8)
C	1/2 IN. SHRINK TUBE - SINGLE CONDUCTOR	3/8 TO 1/2	(10 TO 13)



POSITION	DESIGNATION	COLOR	CRIMP SIZE
1	RLY#1 – NC	BROWN	18 AWG (0.75 mm <sup>2</sup> )
2	RLY#1 – COM	WHITE	18 AWG (0.75 mm <sup>2</sup> )
3	RLY#1 – NO	BLUE	18 AWG (0.75 mm <sup>2</sup> )
4	RLY#2 – NC	BLACK	18 AWG (0.75 mm <sup>2</sup> )
5	RLY#2 – COM	GRAY	18 AWG (0.75 mm <sup>2</sup> )
6	RLY#2 – NO	PINK	18 AWG (0.75 mm <sup>2</sup> )



\* BLACK PIN #4 UNDER #5 GRAY

**FIGURE 5-48**  
**RELAY CIRCUIT CONNECTOR ASSEMBLY**  
 011889b/ 011889

### RELEASE CIRCUIT


The Release Circuit Cable at the CHECKFIRE 210-D ICM is the starting point for the release circuit. See Figure 5-49. The release circuit consists of a main trunk with Release Circuit “h” Cables, and Release Circuit Drop Cables.




**FIGURE 5-49**  
**RELEASE CIRCUIT CONNECTION**  
011900

### Release/Power Circuit Connector Assembly (Figure 5-50)

ITEM	DESCRIPTION	IN.	(mm)
A	DISTANCE OF UNPROTECTED CONDUCTORS	1 1/2 TO 7	(32 TO 178)
B	SINGLE CONDUCTOR STRIPPING	1/4 TO 3/8	(6 TO 8)
C	1/2 IN. SHRINK TUBE - SINGLE CONDUCTOR	3/8 TO 1/2	(10 TO 13)



POSITION	COLOR	CRIMP SIZE
1	RED	16 AWG (1.0 mm <sup>2</sup> )
2	BLACK	16 AWG (1.0 mm <sup>2</sup> )



**FIGURE 5-50**  
**RELEASE/POWER CIRCUIT CONNECTOR ASSEMBLY**  
011890b/ 011890

### NOTICE

If not completed, install the Electric-Pneumatic Actuator, by following instructions in the applicable ANSUL® vehicle fire suppression system manual.

Install the release circuit using the following rules (see Figures 5-51, and 5-52):


1. Use a Release Circuit “h” Cable for each additional actuator. Additional release circuit cable may be used after the Release Circuit “h” Cable if required.
2. Use Release Circuit Drop Cable at end of circuit for connection to the Electric-Pneumatic Actuator.
3. Route and secure Release Circuit Cable following installation instructions under Cable Connectivity, page 5-1.
4. Do not attach Release Circuit Drop Cable to Electric-Pneumatic Actuator at this time. If Release Circuit Drop Cable is connected, the system could be accidentally actuated during installation.

### CAUTION

**Do not** attach any Release Circuit Drop Cable or PAD to any Electric-Pneumatic Actuator until testing is complete.


### Release Circuit Cable

SINGLE TANK – NO RELEASE CIRCUIT “h” CABLE REQUIRED



**FIGURE 5-51**  
**RELEASE CIRCUIT – SINGLE TANK**  
011802

### Release Circuit “h” Cable



**FIGURE 5-52**  
**RELEASE CIRCUIT – TWO TANKS**  
011803

### POWER CIRCUIT CABLE

The Power Circuit Cable at the CHECKFIRE 210-D ICM is the starting point of the external power circuit. See Figures 5-53.

Note: See Release/Power Circuit Connector Assembly in Release Circuit Section, previous page.




**FIGURE 5-53**  
**POWER CIRCUIT CONNECTION**  
011901

Before installation remove fuse and place in a safe place. Install power circuit using the following rules:

1. It is recommended to install power circuit directly to the 12/24 VDC nominal vehicle batteries, if possible. This will provide continuous power for 24 hour system protection.
2. Install black jacketed conductor, labeled “– VEH BATT” to the negative post on battery or 12/24 VDC nominal power source.
3. Install red jacketed, 3A fused conductor, labeled “+ VEH BATT” to the positive post on the battery or 12/24 VDC nominal power source. **Do not install fuse at this time.**
4. Route and secure the Power Circuit Cable following the installation instructions under Cable Connectivity, page 5-1.
5. Do not install fuse until entire system is ready for testing (see Section 6 – Operational Test and Place in Service). When ready, install fuse following required steps (a – e) to help ensure an IP67 connection. See Figure 5-54.

- a. Insert new fuse.
- b. Apply entire contents of supplied Dow Corning 4 (dielectric grease) inside in-line fuse holder cover.
- c. Snap cover in place and press firmly together around outer edges to properly seal.
- d. Wipe off excess grease on outside of in-line fuse holder.
- e. May take up to a minute before green Power LED displays on the Display Module.



**FIGURE 5-54**  
**FUSE INSTALLATION**  
009228

### NOTICE

Anytime fuse cover is opened or fuse is removed, review steps (a-e) to confirm fuse and cover are correctly replaced.

Cover must be completely refilled with Dow Corning #4 or equal (dielectric) grease before closing to maintain IP67 rating. Press cover firmly in place and wipe off excess grease.

**AUXILIARY OUTPUT CABLE**

The Auxiliary Output cable at the CHECKFIRE 210-D ICM is the starting point of the Auxiliary Output Power Circuit, see Figure 5-55.



**FIGURE 5-55**  
**AUXILIARY OUTPUT CIRCUIT CONNECTION**  
011902

Note: See Release/Power Circuit Connector Assembly (Figure 5-50) in Release Circuit section, page 5-13.

The auxiliary output circuit is powered by feedthrough of 12/24 VDC @ 1.5 A nominal provided from primary power supply.


The Circuit is disabled when the CHECKFIRE 210-D System is operating on the secondary power supply.

Connections to equipment components are made by others.

**LABEL PACKAGE**

Attach appropriate labels as needed in the specified locations. See Figures 5-56 to 5-59.

If automatic vehicle/equipment shutdown is part of the CHECKFIRE System, install the Engine Shutdown Label near the operator’s line of vision. Cut out the correct time delay value from the Time Delay Label, remove backing to expose adhesive, and attach to the Engine Shutdown Label in the space provided. See Figure 5-56.



**FIGURE 5-56**  
**LABEL FOR ENGINE SHUTDOWN AND TIME DELAY**  
009174

If automatic vehicle/equipment shutdown is **NOT** part of the CHECKFIRE System, install the Stop Vehicle and Exit Label near the operator’s line of vision. See Figure 5-57.



**FIGURE 5-57**  
**LABEL TO STOP VEHICLE AND EXIT**  
009175

### LABEL PACKAGE (Continued)

As a reminder to service and maintenance personnel, install this CAUTION (Label No. 441207) in the area protected by the Linear Detector. See Figure 5-58.



**FIGURE 5-58**  
**LABEL FOR PROTECTING LINEAR DETECTOR**  
011941-

Install Label No. 440802 next to every Electric Manual Actuator (EMA). See Figure 5-59.



**FIGURE 5-59**  
**INSTRUCTION LABEL FOR EMA**  
009324

### FINAL COMPONENT CONNECTIONS

**Electric activation:** See Section 6 – Operational Test and Place in Service for final electric activation connections.

**Combined electric and pneumatic actuation:** Connect both pneumatic actuator hoses and Release Circuit Drop Cables with installed PADs (see electric actuation instructions in Section 6 – Operational Test and Place in Service).

### PNEUMATIC MANUAL ACTUATION (OPTIONAL)

If layout drawing includes an optional pneumatic manual actuator in the operator's compartment, confirm the operator has access to the red strike button on the actuator. For detailed installation guidelines, refer to the appropriate system manual (latest revision).

### PROGRAMMING

The CHECKFIRE 210-D System may be programmed manually or using a Personal Computer (PC). For manual programming with the ICM and Display Module (internal or external power required) use the Programming Button to turn programming LEDs on or off similar to dip switches (see Table 5-2 and 5-3). Instructions for manually saving the Event History Log are in Table 5-4.

If the Display Module or power is not available, the ICM can be programmed with a PC and the ANSUL® CHECKFIRE 210 Programmer software (see Table 5-5). Programming system options and internal system information including a 4,000+ Event History Log are viewable on one screen.

A list of all circuits and a summary of programming options for each circuit, that can be programmed manually, are provided in Table 5-1.

**Note:** Some programming features are only available via PC Programming. See Table 5-5 for these additional options.

TABLE 5-1: MANUAL ICM PROGRAMMING SUMMARY (See Note 1 below)

LED Identifier	Function Description	STATUS	
		Default Status - LED OFF	Optional Programming
PSF-1	Pressure Switch Feedback	No pressure switch feedback function	Pressure Switch Feedback – Pressure switch communicates to ICM through Detection Circuit #2 (for additional functionality see <i>Optional DET-4</i> ). <b>Note:</b> Pressure Switch Feedback and Cross-Zone Detection can NOT operate together.
DET-2	Cross-Zone Detection	Det. Ckt. #1 and Det. Ckt. #2 operate as independent circuits	Cross-Zone Detection – Requires an alarm condition on both detection circuits #1 and #2 before starting Time Delay #1 (TD1).
DET-3	Detection Circuit #1	Independent detection/release	Alarm Only – Prohibits start of TD1 countdown for any alarm condition on Detection Circuit #1. (Not available when cross-zone detection, DET-2, is enabled.)
DET-4	Detection Circuit #2	Independent detection/release	Alarm Only – Prohibits start of TD1 countdown for any alarm condition on Detection Circuit #2. (Not available when cross-zone detection, DET-2, is enabled.)
DET-4 (Optional) (PSF-1 enabled)	Pressure Switch Feedback - Enabled	System provides release notification, and sends release signal to PADs ( <b>Optional = OFF</b> )	System provides release notification, and does not send release signal to PADs. ( <b>Default = ON when Pressure Switch Feedback is enabled.</b> )
TD1-5 and TD1-6	Time Delay #1	10 second initial time delay period between an alarm condition and Time Delay #2 (TD2).  <b>Sec.</b> <b>TD1-5</b> <b>TD1-6</b> 10    OFF    OFF <b>Note:</b> Cross-Zone requires alarm condition in both detection circuits before start of TD1.	Time Delay #1 (TD1) – Optional delay periods (0, 5 or 15 seconds) between an alarm condition and Time Delay #2 (TD2).  <b>Sec.</b> <b>TD1-5</b> <b>TD1-6</b> 0    ON    ON 5    ON    OFF 15    OFF    ON
TD2-7 and TD2-8	Time Delay #2	10 second time delay period between Time Delay #1 (TD1) and system release.  <b>Sec.</b> <b>TD2-7</b> <b>TD2-8</b> 10    OFF    OFF	Time Delay #2 (TD2) – Optional delay periods (0, 5 or 15 seconds) starting after Time Delay #1 (TD1).  <b>Sec.</b> <b>TD2-7</b> <b>TD2-8</b> 0    ON    ON 5    ON    OFF 15    OFF    ON
TDR-9	Time Delay #1 (TD1) Restarts	1 Restart	Unlimited restarts
RLY-10	Relay #1	Alarm – Relay contacts transfer on an alarm condition. <b>Note:</b> The relay returns to normal if the alarm condition clears.	Fault – Relay contacts transfer on any fault condition. <b>Note:</b> The relay returns to normal if the fault condition clears.
RLY-11	Relay #2	Shutdown: - Relay contacts transfer when TD1 expires. <b>Note:</b> Latching relay only transfers back to normal when system is reset from the Post Release Activated condition.	Alarm – Relay contacts transfer on an alarm condition. <b>Note:</b> The relay returns to normal if the alarm condition clears.

**Note 1:** Detection 1 EMA, Detection 2 EMA, and EMA While In Isolate functionality can only be programmed using the PC programmer.

\* When PSF-1 is enabled, DET-4 “ON” is the default and DET-4 “OFF” is optional.

Review the following tables with instructions on programming options for the CHECKFIRE 210-D System.

**TABLE 5-2: PREPARATION – ICM MANUAL PROGRAMMING MODE**

**Manual Programming with the ICM Programming Button (PB)**

(For programming with a computer see page 5-28.)


When using the Programming Button (PB), the ICM must be connected to the display module to save changes and powered with the internal battery or external power source.

Programming steps are not saved until the display module is reset to Normal.

**Access the Programming Button (PB)**

The Manual Programming Button is located under the ICM Battery Compartment cover

Loosen the four screws of the battery compartment cover and remove to gain access.



011804

**NOTICE**


Using the Isolate Function with the Display Module will only work when the Display Module and the ICM Firmware are at version 2.3 or later.

**Programming Mode**

First confirm the ICM is connected to a display module and power source.

Place the ICM into programming mode by pressing the PB 3 times in 1 second.

All programming indicator lights will remain lit for 1 second to confirm the ICM is in programming mode.




011773

QUICKLY PRESS PB  
 3 X 1 SEC. TO START  
 PROGRAMMING MODE

**IDENTIFY LEDs As:**

		
LED STEADY-ON	LED PULSING	LED OFF

**PROGRAMMING MODE**  
 PSF-1 PULSES  
 1 X 1 SEC.  
 REMAINING LEDs  
 ARE EITHER  
 STEADY-ON OR  
 STEADY OFF  
 (DEFAULT)



009321

TABLE 5-2: PREPARATION – ICM MANUAL PROGRAMMING MODE (Continued)

**Manual Programming with the ICM Programming Button (PB)**


**Battery Life Remaining Feature**

Next, the LED's display the battery life remaining status with the programming indicator lights 1 to 10 to indicate a percentage range for the remaining battery life.


Review the 3 examples defining the percentage values per the number of steady-on LEDs.

**Note:** The internal battery must be replaced when the battery life is less than 25%.


**BATTERY LIFE**  
LEDs 1 TO 10  
STEADY-ON =  
96% TO 100%



**BATTERY LIFE**  
LEDs 1 TO 7  
STEADY-ON =  
70% TO 80%



**BATTERY LIFE**  
LED 1 (PSF-1)  
STEADY-ON =  
10% TO 20%



After the Battery Life Remaining feature is displayed the ICM will show the current ICM programming.

The programmed default status will be shown by all indicator lights being off.

**DEFAULT PROGRAMMING:**  
ALL INDICATOR  
LIGHTS OFF




TABLE 5-2: PREPARATION – ICM MANUAL PROGRAMMING MODE (Continued)

**Manual Programming With The ICM Programming Button (PB) (Continued)**

**Change Selections**

The PSF-1 LED will then pulse 1 time per second indicating PSF-1 is the currently selected option.

To change the selected indicator light, momentarily press the Programming Button (PB) once. The blinking LED will advance to the next Indicator light.

To select the status of the blinking LED, press and hold the programming button longer than 1 second.


**NOTICE**

After 30 seconds of inactivity, Programming Mode automatically times out. Any modifications not saved to the System by a reset to normal on the Display Module will be lost.

PUSH PB ONCE TO ADVANCE TO NEXT LED



EACH PB PUSH ADVANCES TO NEXT LED



PRESS AND HOLD PB TO CHANGE PULSING LED ON OR OFF



STEADY-ON

PULSING 1 X 1 SEC.

PUSH PB ONCE TO ADVANCE AND CONFIRM PREVIOUS LED CHANGED




TABLE 5-3: MANUAL PROGRAMMING OPTIONS

### Pressure Switch Feedback, PSF-1

PSF-1 changes the function of Detection Circuit #2 between an independent detection/release circuit input and pressure switch feedback input.


1. To select this function turn on indicator light PSF-1.
2. Indicator LED's should show the following:
  - PSF-1 is steady-on
  - DET-4 is steady-on



### Cross-Zone Detection, DET-2

Cross-Zone detection requires an alarm event on both Detection Circuits #1 and #2 before CHECKFIRE 210-D System starts Time Delay #1 (TD1) for automatic release.

1. To select this function turn on indicator light DET-2.
2. Indicator LED's should show the following:
  - DET-2 is steady-on




### Alarm Only, Detection Circuit #1, DET-3 (DET-2 must be OFF)

DET-3 changes Detection Circuit #1 between independent detection/release operation and Alarm Only functionality.

The Alarm Only detection programming prohibits the CHECKFIRE 210-D System from entering into automatic release countdown for any alarm condition detected by Detection Circuit #1. The System will continue to show alarm condition indefinitely, and will NOT activate the fire suppression system.

1. To select this function turn on indicator light DET-3.
2. Indicator LED's should show the following:
  - DET-3 is steady-on



**Note:** If cross zone detection is turned on, this function is not available.

### CAUTION

Programming both Detection Circuit #1 and Detection Circuit #2 for Alarm Only functionality will disable all automatic release functions of the CHECKFIRE 210-D System. Manual actuation of the fire suppression system is required and failure to manually activate the system can result in significant property damage or personnel injury.

TABLE 5-3: MANUAL PROGRAMMING OPTIONS (Continued)


**Alarm Only, Detection Circuit #2, DET-4  
(PSF-1 and DET-2 must be OFF)**

DET-4 changes Detection Circuit #2 between independent detection/release operation and Alarm Only functionality.

The Alarm Only detection programming prohibits the CHECKFIRE 210-D System from entering into an automatic release countdown for any alarm condition detected by Detection Circuit #2. The System will continue to show Alarm indication indefinitely, and will NOT activate the suppression system.

1. To select this function turn on indicator light DET-4.
2. Indicator LED's should show the following:  
DET-4 is steady-on

**Note:** If cross zone detection is turned on, this function is not available.



**CAUTION**

Programming both Detection Circuit #1 and Detection Circuit #2 for Alarm Only functionality will disable all automatic release functions of the CHECKFIRE 210-D System. Manual actuation of the fire suppression system is required and failure to manually activate the system can result in significant property damage or personnel injury.

TABLE 5-3: MANUAL PROGRAMMING OPTIONS (Continued)



**Time Delay #1 (TD1) Programming, TD1-5 and TD1-6**

TD1 is the delay period between an alarm condition and TD2.

1. Review system plan to determine value for TD1. Change indicator lights to match the required time delay - see the following table.

Seconds	TD1-5	TD1-6
0	ON	ON
5	ON	OFF
10	OFF	OFF (default)
15	OFF	ON

2. Confirm the correct LED's have been selected.
3. Maximum Combined Time Delays must not exceed 15 seconds. Total allotted time delay, when a time delay restart is utilized, must not exceed 30 seconds.



**CAUTION**

TD1 is the delay period between an alarm condition and equipment shutdown. If using the shutdown relay function, programming TD1 to zero seconds results in immediate equipment shutdown and immediate start of TD2 upon initiation of an alarm condition.

**CAUTION**

Programming both Time Delay #1 and Time Delay #2 to zero seconds results in immediate System activation following an alarm condition. This situation could lead to immediate equipment shutdown (if using the shutdown relay function) or other unforeseen issues which could result in significant property damage or personal injury.

**FM APPROVED TIME DELAY SETTINGS**

TD1 sec	TD2 sec			
	0	5	10	15
0	✓	✓	✓	✓
5	✓	✓	✓	✓
10	✓	✓	✓	—
15	✓	—	—	—

TABLE 5-3: MANUAL PROGRAMMING OPTIONS (Continued)


**Time Delay #2 (TD2) Programming, TD2-7 and TD2-8**

TD2 is the delay period between Time Delay #1 (TD1) and system release.

1. Review system plan to determine value for TD2. Change indicator lights to match the required time delay - see the following table.

Seconds	TD2-7	TD2-8
0	ON	ON
5	ON	OFF
10	OFF	OFF (default)
15	OFF	ON

2. Confirm the correct LED's have been selected.
3. Maximum Combined Time Delays must not exceed 15 seconds. Total allotted time delay, when a time delay restart is utilized, must not exceed 30 seconds.



**CAUTION**

TD2 is the delay period between TD1 and fire suppression release. If using the shutdown relay function, programming TD2 to zero seconds results in immediate fire suppression release at the same time as equipment shutdown.

**CAUTION**

Programming both Time Delay #1 and Time Delay #2 to zero seconds results in immediate System activation following an alarm condition. This situation could lead to immediate equipment shutdown (if using the shutdown relay function) or other unforeseen issues which could result in significant property damage or personal injury.

**FM APPROVED TIME DELAY SETTINGS**

TD1 sec	TD2 sec			
	0	5	10	15
0	✓	✓	✓	✓
5	✓	✓	✓	✓
10	✓	✓	✓	—
15	✓	—	—	—

TABLE 5-3: MANUAL PROGRAMMING OPTIONS (Continued)


**Time Delay Restarts for TD1, TDR-9**

TDR-9 changes the number of times Time Delay 1 can be restarted from the display module.

1. To select this option turn on indicator light TDR-9.
2. Indicator LED's should show the following:
  - TDR-9 is steady-on

**WARNING**

Delay of system operation may allow the fire to intensify, which could result in a more difficult fire to suppress. Programming of unlimited time delays will void FM Approval.




**Relay #1, RLY-10**

RYL-10 changes the function of Internal Relay #1 between an Alarm Condition and a Fault Condition. Alarm functionality responds to an alarm condition. When programmed to the Fault function a fault condition will cause the contacts to transfer. In both cases the relay will return to normal once the alarm/fault condition clears.

The relay is a non-latching relay, and will return to normal once the fault or alarm clears.

1. To select fault function turn on indicator light RYL-10.
2. Push the programming button to move to the next LED and confirm.
  - RLY-10 is steady-on




**Relay #2, Shutdown/Alarm, RLY-11**

RYL-11 changes the function of Internal Relay #2 between a Shutdown Relay and an Alarm Relay. When programmed to the Shutdown functionality the relay contact transfers when TD1 expires. The latching relay will not transfer back to normal until the CHECKFIRE 210-D System is reset from the Post Release Activated condition.

When programmed to the Alarm Relay functionality, the initiation of an alarm condition transfers the relay contact. The relay will return to normal once the alarm condition clears.

1. To select alarm function turn on indicator light RYL-11.
2. Push the programming button to move to the next LED and confirm.
  - RLY-11 is steady-on



**Save Programming**

Once all programming changes have been completed, reset the system at the Display Module to save the changes. Press and hold the “DELAY/Reset/Silence” button for 3 seconds to reset the system.

SAVE PROGRAMMING:

RESET TO NORMAL

PRESS AND HOLD 3 SECONDS

LEDs TEST CYCLE THEN SOUNDER PULSES 3 TIMES



**TABLE 5-4: DOWNLOAD EVENT HISTORY LOG**

The Event History Log of the CHECKFIRE 210-D System can be downloaded as a text file directly to a USB memory device (by others) without connection to a personal computer (PC). The USB memory device may then be plugged into a PC to print or save the file to a different location.

- Allows service personnel to retrieve programming and Event History Log without connecting a PC to ICM.
- Allows service personnel to save a text file which helps verify maintenance and operation of the CHECKFIRE 210-D System.

Communication adapter cable (by others) is required to connect a standard USB memory device to the mini USB port on the ICM. Items needed:

1. Interface Cable: USB A Female receptacle and Mini A plug x 4 in. (102 mm) long.
2. Standard USB memory device.

TABLE 5-4: DOWNLOAD EVENT HISTORY LOG (Continued)

**Accessing and Downloading the Event History Log**

The Programming Button (PB) and programming LEDs are located under the ICM battery compartment cover. The programming button controls the download process and the programming LEDs indicate the start and end of the download.

**Note:** The Event History Log download should be performed at or near normal temperature conditions. Corrupted or incomplete history file data can occur if downloads are attempted at extreme high or low temperatures.

1. Loosen the (4) captive screws and remove cover to gain access to programming button and view LEDs.
2. Connect the USB communication cable and memory device to the mini USB port near the programming LEDs.
3. Push programming button 3 x 1 second to begin the file download. (ICM senses connection with a USB memory device and starts the download.)
4. Programming LEDs pulse briefly to indicate system has initiated the download. Then all LEDs pulse in marquee fashion to indicate the ICM is writing the contents of the Event History Log to the USB memory device.
5. When complete, all LEDs illuminate steady-on for 5 seconds. A text file is saved on the USB memory device with the current date. The text file name will be LOGxxx where the x place holders will be a number (e.g. 0001, 0002) determined by the last number of any previously saved text files on the USB memory device.

**Note:** The writing of the Event History Log can take several seconds to complete and **should not be interrupted**. If the writing is not successful after 30 seconds, the ICM will quickly pulse all LEDs together multiple times indicating an unsuccessful file download.

6. Disconnect cable and USB memory device. Re-install battery cover.







TABLE 5-5: PERSONAL COMPUTER (PC) OPTIONS


**Personal Computer (PC) Programming**

Authorized ANSUL® Distributors with CHECKFIRE 210-D System contracts have access to the ANSUL® CHECKFIRE 210 Programmer software. The same programming options described in the previous table for the ICM have matching programming in the PC software.

Install the latest version of the ANSUL® CHECKFIRE 210 Programmer utility software on a PC to read and write information to the ICM. See Download and Setup instructions at end of page.

**Note:** It is not necessary to install a battery module or provide external power to the CHECKFIRE 210-D ICM when using the PC interface. The PC provides power for system operation through the USB communication cable.

SAME PROGRAMMING OPTIONS AS THE ICM PROGRAMMING BUTTON AND LEDS ICM PROGRAMMING LED IDENTIFIERS



012167

**Connecting the ICM to a PC**

Establish communication between the ICM and a PC using the mini USB serial port under the ICM battery compartment cover.


Connect an Interface cable:

**USB A Male plug and Mini B plug x 10 ft (3 m) long**

- 1) Loosen the four captive screws and remove cover to gain access to the programming button.
- 2) Connect an appropriate USB Communication Cable (specified in bold above) between the mini B USB port on the CHECKFIRE 210-D ICM and a Standard A USB port on your PC.
- 3) Launch the CHECKFIRE 210 Programmer application software on the PC.
- 4) If Serial Port does not auto-populate with an available COM port, select the appropriate COM port from the drop down list at the top left of the application window then click Connect.


**Note:** PC programming should be performed at or near normal temperature conditions. Corrupted or incomplete data can occur if programming is attempted at extreme high or low temperatures.

MINI USB PORT:  
 INSTALL CABLE TO CONNECT WITH PC



011773

SELECT PORT AND CLICK CONNECT



011745

**Download and Setup**

Locate the CHECKFIRE 210 Programmer Setup most current file on the ANSUL® Navigator under Literature: then select your company and the following options:

Select **Product Family:** ANSUL® CHECKFIRE 110/210 Vehicle Det/Actuation Sys

Select **Product Lines:** ANSUL® CHECKFIRE 110/210 Vehicle Det/Actuation Sys

Select **Literature Type:** Software Download

Download the file to your computer. When the file download is complete, open the CHECKFIRE 210 Programmer Setup most current file and follow the instructions in the Programmer Setup Wizard. Close all other applications and click yes to allow the Programmer app to make changes to your computer.

TABLE 5-5: PERSONAL COMPUTER (PC) OPTIONS (Continued)


<b>Reading System Information</b>	SERIAL NUMBER AND FIRMWARE VERSIONS
<p>With proper communications established the software automatically populates system information, including serial numbers, firmware versions, and current programming.</p> <p>At initial System startup, all programming options are programmed to factory defaults.</p> <p><b>Note:</b> If display module is not connected to the ICM, the display module information is shown as “No response.”</p>	 <p>01174a</p>
<b>Programming The System Clock</b>	 <p>011739</p> <p>SYNCHRONIZES ICM CLOCK WITH PC CLOCK</p>
<p><b>Note:</b> Programming the date/time does not affect the history file.</p>	

TABLE 5-5: PERSONAL COMPUTER (PC) OPTIONS (Continued)

### Battery Life Remaining

The ICM monitors the expected lifetime of the internal battery. Click the Read button under Battery Life Remaining section to view remaining battery life percentage.

Internal battery must be replaced when there is a low power indication or battery life remaining is less than 25%.

**Note:** When performing semi-annual maintenance, system tests require system to be tested on both primary and secondary power. If a “test” battery is not used, the secondary battery must be changed semi-annually.


Only click the Reset button for installation of a new/unused battery module. When clicked, the battery life indicator resets to full.

**Note:** When replacing the battery module (e.g., during semi-annual maintenance) the battery life indicator can be reset from the ICM without connecting to a PC. (Section 8 – Recharge, Inspection, and Maintenance also has the following instructions.)

- 1) Replace the battery module with a new/unused unit. Record the replacement date on the inside sticker of the battery compartment cover and on the battery itself.
- 2) Place the CHECKFIRE 210-D System into Isolate Mode. Press and hold the “DELAY/Reset/Silence” button on the CHECKFIRE 210-D Display for approximately 8 seconds (two consecutive resets).
- 3) Press and hold the Programming Button for more than five (5) seconds then release.
- 4) All programming LEDs pulse 3 x 1 second to confirm battery life indicator is reset.
- 5) Cancel Isolate Mode by pressing and hold the “DELAY/Reset/Silence” button on the CHECKFIRE 210-D Display for approximately 8 seconds (two consecutive resets).

### CAUTION

Performing a reset of the battery life indicator without installing a new/unused replacement battery module can result in faulty battery indications and unpredictable CHECKFIRE 210-D System operation.




### Programming Commands

The Read button in the Programming Commands section uploads the current ICM programming for the CHECKFIRE 210-D System. When making changes to the programming, click the Save button to save the change to the ICM.



**TABLE 5-5: PERSONAL COMPUTER (PC) OPTIONS (Continued)**

<b>Modifying Programming Options</b>		FACTORY DEFAULT SETTINGS
<p>Each of the options shown in Table 5-1 – Manual ICM Programming Summary (page 5-17) is programmed using a drop down menu and clicking the desired options. Certain options will be grayed out when others are selected. When options turn red, the programming has not been saved to the ICM.</p>		
<b>Default Programming</b>		
<u>Circuit Option</u>	<u>Function</u>	
1. Pressure Feedback (PSF-1)	Disabled	
2. Cross-Zone Detection (DET-2)	Disabled	
3. Detection Circuit #1 (DET-3)	Release Act.	
4. Detection Circuit #2 (DET-4)	Release Act.	
5. Time Delay #1 (TD1-5 and TD1-6)	10 sec. delay	
6. Time Delay #2 (TD2-7 and TD2-8)	10 sec. delay	
7. Time Delay #1 Restarts (TDR-9)	One restart	
8. Relay #1 (RLY-10)	Alarm	
9. Relay #2 (RLY-11)	Shutdown	
10. Isolate Mode EMA Actuation	Enabled	
11. Detection Circuit #1 EMA	Enabled	
12. Detection Circuit #2 EMA	Enabled	
13. Detection Circuit #1 QIR	Disabled	
14. Detection Circuit #2 QIR	Disabled	

012166

**NOTICE**

Quad Infra Red (QIR) Detection System Programming is only available using a PC for programming.


TABLE 5-5: PERSONAL COMPUTER (PC) OPTIONS (Continued)

**Alternate Programming:**

1. Pressure Switch Feedback – Pressure switch communicates to ICM through Detection Circuit #2.
2. Cross-Zone Detection – Requires an alarm condition on both Detection Circuits #1 and #2 before starting Time Delay #1 (TD1).
3. Det. Ckt. #1 - Alarm Only – Prohibits start of TD1 countdown for any alarm condition on Detection Circuit #1. (Not available when cross-zone detection is enabled.)
4. Det. Ckt. #2 - Alarm Only – Prohibits start of TD1 countdown for any alarm condition on Detection Circuit #2. (Not available when cross-zone detection is enabled.)
  - a. *Alarm Only - System provides release notification, and does not send release signal to PADs (Default when Pressure Switch Feedback is enabled)*
  - b. *Release Activation - System provides release notification, and sends release signal to PADs (Optional when Pressure Switch Feedback is enabled)*
5. Time Delay #1 (TD1) – Optional delay periods (0, 5 or 15 seconds) between an alarm condition and Time Delay #2 (TD2). See FM Approved Time Delay Settings table in right column.
6. Time Delay #2 (TD2) – Optional delay periods (0, 5 or 15 seconds) starting after time delay #1 (TD1).  
**Note: See FM Approved Time Delay Settings table in right column for FM Approved TD2 settings.**
7. Time Delay #1 Restarts - Unlimited restarts.
8. Relay #1 - Fault – Relay contacts transfer on any fault condition.
9. Relay #2 - Alarm – Relay contacts transfer on an alarm condition.
10. Isolate Mode EMA Actuation – Disabled. While the system is in ISOLATE mode, activation of an EMA will not cause activation of the release circuit even if the corresponding detection circuit is programmed to allow EMA activation. Activation of an EMA will cause the corresponding AMBER detection LED to pulse 2 x per second every 10 seconds.
11. Detection Circuit #1 EMA – Disabled. Disables EMA activation on Detection Circuit #1. An EMA signal will cause the Detection 1 AMBER LED to pulse 2 x per second every 10 seconds and will not cause release activation.
12. Detection Circuit #2 EMA – Disabled. Disables EMA activation on Detection Circuit #2. An EMA signal will cause the Detection 2 AMBER LED to pulse 2 x per second every 10 seconds and will not cause release activation.
13. Module with QIRs to be installed on Detection Circuit #1. QIR Alarm will be an alarm and will state Detection Input #1 QIR Alarm in the history log. QIR fault will be a fault and will state Detection Input #1 QIR Fault in the history log. Without being enabled, QIR Alarm will be interpreted as a fault and both a normal QIR condition and QIR Fault will be interpreted as a normal signal.

RED HIGHLIGHTING INDICATES PROGRAMMING NOT SAVED TO ICM

GRAYED OUT DROP DOWN INDICATES OPTION NOT AVAILABLE



012165

**FM APPROVED TIME DELAY SETTINGS**

TD1 sec	TD2 sec			
	0	5	10	15
0	✓	✓	✓	✓
5	✓	✓	✓	✓
10	✓	✓	✓	–
15	✓	–	–	–

TABLE 5-5: PERSONAL COMPUTER (PC) OPTIONS (Continued)

**Alternate Programming (Continued):**

- 14. Detection Circuit #2 QIR – Enabled. Enables Interface Module with QIRs to be installed on Detection Circuit #2. QIR Alarm will be an alarm and will state Detection Input #2 QIR Alarm in the history log. QIR fault will be a fault and will state Detection Input #2 QIR Fault in the history log. Without being enabled, QIR Alarm will be interpreted as a fault and both a normal QIR condition and QIR Fault will be interpreted as a normal signal.

**History Viewer**

The History Viewer section displays upto 4,096 events in the Event History Log and automatically uploads all events when changes are made.

Each event record includes a timestamp with real date and time. When multiple events share the same timestamp duplicate timestamps can be hidden by selecting the Hide Duplicate Timestamps checkbox. Events occurring at the same time are listed underneath a single timestamp.

See page 5-35 for a list of Event History Log messages.

To save the Event History Log as a text file select Save from the drop down list under File on the Menu Bar.

EVENT HISTORY LOG SHOWING CHANGES IN PROGRAMMING

CLICK TO VIEW  
EVENT HISTORY LOG

ID	Timestamp	Description
85	07/11/2022 12:25:16 PM	Alarm Relay Deactivated
84		ISO_EMA=ENABLED, DET1_EMA=ENABLED, DET2_EMA=ENABLED
83		TD2=5, TD1RST=1, R1=ALM, R2=SHDN
82		DET, IND, RLS #1, RLS #2, TD1=10
81		Configuration Has Been Modified
80		ISO_EMA=ENABLED, DET1_EMA=ENABLED, DET2_EMA=ENABLED
79		TD2=10, TD1RST=1, R1=FLT, R2=SHDN
78		DET, IND, RLS #1, RLS #2, TD1=10
77	07/11/2022 12:25:00 PM	Fault Relay Activated
76		ISO_EMA=ENABLED, DET1_EMA=ENABLED, DET2_EMA=ENABLED
75		TD2=10, TD1RST=1, R1=FLT, R2=SHDN
74		DET, IND, RLS #1, RLS #2, TD1=10
73		Configuration Has Been Modified
72		ISO_EMA=ENABLED, DET1_EMA=ENABLED, DET2_EMA=ENABLED
71		TD2=5, TD1RST=1, R1=ALM, R2=SHDN
70		DET, IND, RLS #1, RLS #2, TD1=10
69	07/11/2022 12:20:00 PM	Audible Notification Silenced
68	07/11/2022 12:19:52 PM	Detection Input #2 Open Circuit Fault
67		Detection Input #1 Open Circuit Fault
66	07/11/2022 12:19:51 PM	Release Circuit Open Circuit Fault
65		System Reset
64		Isolate Mode Activated
63		Secondary Power Operation
62	07/11/2022 12:19:47 PM	Detection Input #2 Open Circuit Fault
61		Detection Input #1 Open Circuit Fault
60		Release Circuit Open Circuit Fault
59		System Reset
58		Isolate Mode Deactivated
57		Secondary Power Operation

011740

EVENT HISTORY LOG SHOWING ACTIVATION MESSAGES

ID	Timestamp	Description
50		Secondary Power Operation
49	07/11/2022 11:28:45 AM	Display Fault Cleared
48	07/11/2022 11:24:56 AM	Display Fault
47	06/15/2022 02:33:47 PM	System All Clear
46	06/15/2022 02:33:43 PM	System Reset
45		Isolate Mode Deactivated
44		Primary Power Operation
43	06/15/2022 02:33:40 PM	Audible Notification Silenced
42	06/15/2022 02:33:25 PM	Release Circuit Activated
41	06/15/2022 02:33:20 PM	Shutdown Relay Activated
40		Time Delay #2 Started
39	06/15/2022 02:33:10 PM	Alarm Relay Activated
38		Time Delay #1 Started
37		Detection Input #1 Initiated
36	06/15/2022 02:32:35 PM	Alarm Relay Deactivated
35		Detection Input #1 Initiation Cleared
34	06/15/2022 02:32:25 PM	Alarm Relay Activated
33		Time Delay #1 Started
32		Detection Input #1 Initiated
31	06/15/2022 02:32:22 PM	Detection Input #1 Fault Cleared
30	06/15/2022 02:32:14 PM	Detection Input #1 Open Circuit Fault
29	06/15/2022 02:31:56 PM	Release Circuit Fault Cleared
28	06/15/2022 02:31:10 PM	Release Circuit Open Circuit Fault
27	06/15/2022 02:30:45 PM	System All Clear
26	06/15/2022 02:30:42 PM	System Reset
25		Isolate Mode Deactivated
24		Primary Power Operation
23	06/15/2022 02:30:37 PM	System Reset
22		Isolate Mode Activated

011741

**EVENT HISTORY LOG - PROGRAMMING**

The CHECKFIRE 210-D System records changes made to System Programming in the Event History Log. Each programming change is indicated with the message “Configuration Has Been Modified.” The message includes the programming before and after modification. Two lines of lower ID sequential numbers before the message list the previous configuration; two lines of higher ID sequential numbers after the message report the modified configuration. See Table 5-6 – Event History Log Programming Descriptions to identify the acronyms representing programming options.

85	07/11/2022 12:25:16 PM	Alarm Relay Deactivated	
84		ISO_EMA=ENABLED, DET1_EMA=ENABLED, DET2_EMA=ENABLED	] AFTER SAVING MODIFICATIONS
83		TD2=5, TD1RST=1, R1=ALM, R2=SHDN	
82		DET, IND, RLS #1, RLS #2, TD1=10	
81		Configuration Has Been Modified	
80		ISO_EMA=ENABLED, DET1_EMA=ENABLED, DET2_EMA=ENABLED	] BEFORE SAVING MODIFICATIONS
79		TD2=10, TD1RST=1, R1=FLT, R2=SHDN	
78		DET, IND, RLS #1, RLS #2, TD1=10	

011746

**For Example:** In the sample Event History Log shown above, the System was modified on July 11, 2022 at 12:25 PM. Two changes were made: Detection Circuit #1 was re-programmed to Alarm Only, and Time Delay #1 was re-programmed from a 10 second delay (default) to a 15 second delay. Remaining programming options were unchanged.

**TABLE 5-6: EVENT HISTORY LOG PROGRAMMING DESCRIPTIONS**

Position	Default	Optional Programming	Description
1	DET	PSF	DET Detection Circuit #2 programmed as a detection circuit PSF Programmed for Pressure Switch Feedback.
2	IND	CRZ	IND Detection Circuits #1 & #2 programmed as detection circuits CRZ Programmed for Cross-Zone Detection
3	RLS #1	ALM #1	RLS #1 Detection Circuit #1 programmed for independent detection/release ALM #1 Detection Circuit #1 programmed for Alarm Only indication
4	RLS #2	ALM #2	RLS #2 Detection Circuit #2 programmed for independent detection/release ALM #2 Detection Circuit #2 programmed for Alarm Only indication
5 *	TD1=10	TD1 = (0,5,15)	TD1=10 Time Delay #1 programmed for 10 seconds (default) TD1= xx TD1 programmed for 0, 5, or 15 seconds.
6 *	TD2=10	TD2 = (0,5,15)	TD2=10 Time Delay #2 programmed for 10 seconds (default) TD2= xx TD2 programmed for 0, 5, or 15 seconds.
7	TD1RST=2	TD1RST =INF	TD1RST=2 Time Delay #1 programmed for one restarts TD1RST=INF Time Delay #1 programmed for infinite restarts **
8	R1=ALM	R1 = FLT	R1=ALM Relay #1 programmed for Alarm relay R1=FLT Relay #1 programmed for Fault relay
9	R2=SHDN	R2 = ALM	R2=SHDN Relay #2 programmed for Shutdown relay R2=ALM Relay #2 programmed for Alarm relay
10	ISO_EMA = ENABLED	ISO_EMA = DISABLED	ISO_EMA = ENABLED Enables EMA activation while in ISOLATE mode ISO_EMA = DISABLED Disables all EMA activation while in ISOLATE mode
11	DET1_EMA = ENABLED	DET1_EMA = DISABLED	DET1_EMA = ENABLED Enables EMA activation on Detection circuit #1 DET1_EMA = DISABLED Disables EMA activation on Detection circuit #1
12	DET2_EMA = ENABLED	DET2_EMA = DISABLED	DET2_EMA = ENABLED Enables EMA activation on Detection circuit #2 DET2_EMA = DISABLED Disables EMA activation on Detection circuit #2
13	DET1_QIR = DISABLED	DET1_QIR = ENABLED	"DET1_QIR = DISABLED Disables QIR activation and fault reporting on Detection circuit #1 DET1_QIR = ENABLED Enables QIR activation and fault reporting on Detection circuit #1"
14	DET2_QIR = DISABLED	DET2_QIR = ENABLED	"DET2_QIR = DISABLED Disables QIR activation and fault reporting on Detection circuit #2 DET2_QIR = ENABLED Enables QIR activation and fault reporting on Detection circuit #2"

\* See table on page 5-32 for a list of FM Approved Time Delay settings.  
 \*\* This programming feature voids FM Approval.

**EVENT HISTORY LOG - PROGRAMMING (Continued)**


**TABLE 5-7: EVENT HISTORY MESSAGES**

1.	"System Reset"	27.	"Release Circuit Activated"
2.	"System All Clear"	28.	"Detection Input #1 Electric Manual Activation"
3.	"Audible Notification Silenced"	29.	"Detection Circuit #1 Electric Manual Activation Disabled"
4.	"Audible Notification Silence Expired"	30.	"Detection Input #2 Electric Manual Activation"
5.	"Primary Power Operation"	31.	"Detection Circuit #2 Electric Manual Activation Disabled"
6.	"Primary Power Fault"	32.	"Detection Input #1 Initiated"
7.	"Primary Power Low, Dual Power Operation"	33.	"Detection Input #1 Initiation Cleared"
8.	"Secondary Power Operation"	34.	"Detection Input #2 Initiated"
9.	"Primary Power Operation, Secondary Power Fault"	35.	"Detection Input #2 Initiation Cleared"
10.	"Battery Accumulator Reset"	36.	"PUSH TO ACTIVATE Button Pressed"
11.	"System Powered Down"	37.	"Discharge Confirmed by Pressure Switch"
12.	"Release Circuit Ground Fault"	38.	"Alarm Relay Activated"
13.	"Release Circuit Open Circuit Fault"	39.	"Fault Relay Activated"
14.	"Release Circuit Fault"	40.	"Shutdown Relay Activated"
15.	"Release Circuit Fault Cleared"	41.	"Alarm Relay Deactivated"
16.	"Detection Input #1 Ground Fault"	42.	"Fault Relay Deactivated"
17.	"Detection Input #1 Open Circuit Fault"	43.	"Shutdown Relay Deactivated"
18.	"Detection Input #1 Low Resistance"	44.	"Isolate Mode Activated"
19.	"Detection Input #1 Fault Cleared"	45.	"Isolate Mode Deactivated"
20.	"Detection Input #2 Ground Fault"	46.	"Configuration Has Been Modified"
21.	"Detection Input #2 Open Circuit Fault"	47.	"History Erased"
22.	"Detection Input #2 Low Resistance"	49.	"Display Fault"
23.	"Detection Input #2 Fault Cleared"	50.	"Display Fault Cleared"
24.	"Time Delay #1 Started"	51.	"Firmware Upgrade"
25.	"Time Delay #1 Restarted"	52.	"Self-Diagnostic Routine Failed"
26.	"Time Delay #2 Started"	53.	"Communication Fault"
		54.	Detection Input #1 QIR Alarm
		55.	Detection Input #1 QIR Fault
		56.	Detection Input #2 QIR Alarm
		57.	Detection Input #2 QIR Fault


**EQUIPMENT ID FEATURE**

Adding “Equipment ID” to the CHECKFIRE 210 Programmer:



**STEP 1**




**STEP 4**



**STEP 2**



**STEP 3**



The history log when saved as a .txt file will have a default title using the following format:

<ICM Serial No> <YYYY-MM-DD> <HHMMSS> <Equipment ID>.txt

The above sample file is saved as:

“200-21-44-0-3498 2022-07-11 132956 Heavy Duty Mining Equipment History Log.txt”

**CAUTION**

Before performing any operational tests, protect the fire suppression system from unintentional actuation. Verify Release Circuit Drop Cables are not connected to Electric-Pneumatic Actuators and any pneumatic manual actuators are ring-pinned for safety and actuation cartridges removed.

The following tables are step-by-step instructions to complete testing and place the system in service. If unexpected results occur refer to Section 9 – Troubleshooting.

**TABLE 6-1: PREPARATION – OPERATIONAL TEST**

**Release Circuit**

**CAUTION**

When handling the PAD, always point actuating end away from yourself and others. On electrical initiation, PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and the detaching disk.

Before conducting the OPERATIONAL TEST (see Table 6-3), confirm all installed Release Circuit Drop Cables have a Release Circuit Tester (RCT) or a Release Circuit Test Plug installed.

1. Insert Release Circuit Test Plug in socket of Release Circuit Drop Cables. (If installed remove PAD.)
2. On last Release Circuit Drop Cable insert RCT. (If installed remove PAD.)

Switch on top of RCT must be turned on for testing. LEDs on front indicate status: Ready, Pass, Fail, and replace RCT battery.

After RCT indicates pass or fail, press switch on top to reset the tester.


**Note:** If there is a single Electric-Pneumatic Actuator, connect RCT to Release Circuit Drop Cable. Release Circuit Test Plug is not installed.

**CAUTION**

When performing any operational tests, make certain RCT and Release Circuit Test Plugs, as required, are attached to the release circuit.



IF USING TWO OR MORE DROP CABLES, INSTALL RELEASE CIRCUIT TEST PLUG IN DROPPED SECTION OF CABLES



009288/ 012163/ 011803

TABLE 6-1: PREPARATION – OPERATIONAL TEST (Continued)

**Detection Circuit #1 (and #2)**

Before conducting OPERATIONAL TEST, install the Detection Circuit Tester (DCT).

1. Remove the Detection Circuit EOL Device from the detection circuit.
2. Set DCT to “Normal” condition then install DCT.

**NOTICE**

In applications that do not use the Detection Circuit End of Line (EOL) Device (DT Style) the Detection Circuit Tester can be connected directly to the Detection Circuit Cable at the CHECKFIRE-210 ICM for functional testing.

REMOVE DETECTION  
CIRCUIT EOL DEVICE



SET DCT TO “NORMAL”  
AND INSTALL



**Power Up**

Before conducting the OPERATIONAL TEST, make certain primary power is properly connected to CHECKFIRE 210-D System (see Section 5 – Installation and Programming, page 5-14).

- If 3 amp fuse is not installed for primary power, follow instructions in Section 5 – Installation and Programming, page 5-14 (step 5).
1. Remove battery compartment cover.
  2. Insert battery into battery well; align connector keyways and connect battery pigtail with battery cable on the ICM.

**NOTICE**

It is recommended to use a test battery for test and place in service.

CONFIRM  
CONNECTIONS




TABLE 6-1: PREPARATION – OPERATIONAL TEST (Continued)

**Power Up (Continued)**

- Reset to Normal: Press and hold the “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.
- Power LED is Green steady-on

**NOTICE**

Confirm no other LEDs are pulsing. If fault or alarm conditions are indicated, refer to Section 9 – Troubleshooting to clear all conditions prior to performing the operational test.

**KEY TO DISPLAY MODULE INDICATIONS – IDENTIFY LEDs AS:**

					
LED STEADY-ON (Red or Green)		LED PULSING (Amber, Red or Green)			LED OFF

**RESET TO NORMAL**

- PRESS AND HOLD 3 SECONDS
- LEDs TEST CYCLE THEN SOUNDER PULSES 3 TIMES
- LED IS GREEN STEADY-ON



009290a

TABLE 6-2: ISOLATION FEATURE – OPERATIONAL TEST

The CHECKFIRE 210-D System includes an Isolation Feature for equipment service personnel to help minimize the possibility of a false fire suppression system discharge when service or maintenance takes place on the protected vehicle/equipment (not intended for CHECKFIRE 210-D System maintenance).

**CAUTION**

When placed in isolate mode, the release circuit cannot be initiated by an automatic detection circuit input.

In the event of fire, manual actuation bypasses isolate mode. To operate manually:

- Press “PUSH to Activate/ Alarm When Lit” button

Or

- Pull ring pin and operate RED Strike button on an EMA or a pneumatic manual actuator

**CAUTION**

Before performing any operational tests, protect the fire suppression system from unintentional actuation. Verify Release Circuit Drop Cables are not connected to Electric-Pneumatic Actuators and any pneumatic manual actuators are ring-pinned for safety and/or actuation cartridges removed.

**CAUTION**

When performing any operational testing, make certain the RCT and Release Circuit Test Plugs are attached to the release circuit.

Place the CHECKFIRE 210-D System in isolate mode then confirm the system will not auto release and will manually actuate while in isolate mode.

**Note:** While in isolate mode, service personnel can perform service and maintenance on the vehicle/equipment as needed.

1. Put system in isolate mode by pressing and holding the “DELAY/Reset/Silence” button on the CHECKFIRE 210-D Display Module for approximately 8 seconds (two consecutive resets).

2. The Amber isolate LED and sounder on the Display Module will pulse 2 x 10 seconds.
3. If desired, push the “DELAY/Reset/Silence” button to silence the sounder.

**NOTICE**

Using the Isolate Function with the Display Module will only work when the Display Module and the ICM Firmware are at version 2.3 or later.

**ISOLATE MODE**

AMBER LED AND  
 SOUNDER PULSE  
 2 X 10 SECONDS



TABLE 6-2: ISOLATION FEATURE - OPERATIONAL TEST (Continued)

- Set DCT switch to “Alarm” position. Confirm Red Detection 1 LED, Red “Push to Activate / Alarm When Lit” LED and sounder pulse 1 x 1 second; Amber Isolate LED and sounder pulse 2 x 10 seconds.

**Verify time delays do not start.**

**ALARM CONDITION  
DCT = ALARM**

RED/AMBER LEDs  
AND SOUNDER  
PULSE  
1 X 1 SECOND,  
AMBER LED PULSES  
2 X 10 SECONDS

VERIFY TIME  
DELAYS  
DO NOT START



PUSH RED BUTTON

- After 30 seconds of indication, open the protective guard door and push the “PUSH to Activate / Alarm When Lit” button. Release Activated starts immediately.

**Note:** There is no time delay upon manual activation.

- Release Activated** – The Red “PUSH to Activate / Alarm When Lit” LED, Red Shutdown LED, Red Detection 1 LED, and sounder are steady-on for 10 seconds; Amber Isolate LED pulses 2 x 10 seconds.

**RELEASE  
ACTIVATED**

RED LEDs AND  
SOUNDER  
STEADY-ON FOR 10  
SECONDS, AMBER  
LED PULSES  
2 X 10 SECONDS



- Post Release Activated** – The Red Shutdown LED, Red Detection 1 LED, and sounder pulse 1 x 10 seconds; and Amber Isolate LED and sounder pulse 2 x 10 seconds.

**POST RELEASE  
ACTIVATED**

RED LEDs AND  
SOUNDER PULSE  
1 X 1 SECOND,  
AMBER LED PULSES  
2 X 10 SECONDS



PUSH BUTTON

- Push the “DELAY/Reset/Silence” button to test sounder silence. Sounder silences and LEDs continue.

SOUNDER STOPS



TABLE 6-2: ISOLATION FEATURE - OPERATIONAL TEST (Continued)

<ol style="list-style-type: none"><li>9. Confirm successful release signal (Pass) on RCT.</li><li>10. Reset DCT to “Normal” position.</li><li>11. Reset RCT.</li><li>12. Cancel isolate mode by pressing and holding the “DELAY/Reset/Silence” button on the CHECKFIRE 210-D Display Module for approximately 8 seconds (two consecutive resets).</li></ol>
---

TABLE 6-3: OPERATIONAL TEST

<p>The following tests verify system operation for:</p> <ol style="list-style-type: none"><li>1. Circuit Supervision: Confirm supervisory function of each circuit.</li><li>2. Detection Circuit Input: Receive electrical signal from a detection device on #1 and #2 detection circuits (simulated fire condition).</li><li>3. Time Delay: Verify accuracy of time delay programming.</li><li>4. Electric Manual Activation: Receive electrical signal from an EMA.</li></ol> <p>If noted results are not attained, refer to Section 9 – Troubleshooting for corrective action.</p>	<p style="text-align: center;"><b>CAUTION</b></p> <p>Before performing any operational tests, protect the fire suppression system from unintentional actuation. Verify Release Circuit Drop Cables are not connected to Electric-Pneumatic Actuators and any pneumatic manual actuators are ring-pinned for safety and actuation cartridges removed.</p> <hr/> <p style="text-align: center;"><b>CAUTION</b></p> <p>When performing any operational testing, make certain the RCT and Release Circuit Test Plugs are attached to the release circuit.</p> <hr/>
<p style="text-align: center;"><b>NOTICE</b></p> <p>If the vehicle/equipment is connected to a shutdown device through the pressure switch, verification needs to be made at the pressure switch.</p> <hr/>	
<p style="text-align: center;"><b>NOTICE</b></p> <p>During testing, verify any devices connected to Relay #1 and Relay #2 function as intended.</p> <hr/>	

TABLE 6-3: OPERATIONAL TEST (Continued)

**Detection Circuit #1 (and #2) - Supervision Test**

Confirm DCT is in place of the EOL Device on Detection Circuit #1. Set DCT switch to “Fault” position. The CHECKFIRE 210-D Display Module indicates the following:

1. Amber Detection 1 LED and sounder pulse 1 x 10 seconds.
2. If fault relay is programmed, confirm activation of connected devices.
3. Push the “DELAY/Reset/Silence” button to test sounder silence. Sounder silences and LED continues.
4. Reset the DCT to the “Normal” position.
5. CHECKFIRE 210-D Display Module returns to normal status; Power LED is GREEN steady-on.

**DETECTION 1  
FAULT INDICATION  
(DCT = FAULT)**

AMBER LED AND  
SOUNDER PULSE  
1 X 10 SECONDS



PUSH BUTTON

SOUNDER STOPS



**RESET DCT TO  
NORMAL**

MODULE  
RETURNS TO  
NORMAL STATUS  
  
POWER LED IS  
GREEN STEADY-ON



009290a

**Release Circuit - Supervision Test**

Remove RCT from the Release Circuit. The CHECKFIRE 210-D Display Module indicates the following.

1. Amber Release LED and sounder pulse 1 x 10 seconds.
2. Push the “DELAY/Reset/Silence” button to test sounder silence. Sounder silences and LED continues.
3. Reconnect RCT to release circuit.
4. CHECKFIRE 210-D Display Module returns to normal status; Power LED is GREEN steady-on.

**RELEASE  
FAULT INDICATION  
(RCT REMOVED)**

AMBER LED AND  
SOUNDER PULSE  
1 X 10 SECONDS



PUSH BUTTON

SOUNDER STOPS



**RECONNECT RCT**

MODULE  
RETURNS TO  
NORMAL STATUS  
  
POWER LED IS  
GREEN STEADY-ON



009290a

TABLE 6-3: OPERATIONAL TEST (Continued)

**Primary Power Circuit – Supervision Test**

Disconnect the primary power circuit connection at the CHECKFIRE 210-D ICM Power Circuit receptacle.

1. Power LED pulses AMBER 1 x 3 seconds.
2. Reset to Normal: Press and hold “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.

After reset, Power LED pulses GREEN 1 x 3 seconds confirming primary power loss and operation on secondary power.

**Note:** Operation on secondary power only will void FM Approval.

3. Reconnect primary power circuit at the ICM. The CHECKFIRE 210-D Display Module Power LED is GREEN steady-on.

POWER SUPERVISION (REMOVE POWER CABLE)

AMBER LED PULSES 1 X 3 SECONDS



009290a

POWER SUPERVISION AFTER RESET WITHOUT PRIMARY POWER

GREEN LED PULSES 1 X 3 SECONDS



009290a

RECONNECT PRIMARY POWER

SYSTEM RETURNS TO NORMAL STATUS

POWER LED IS GREEN STEADY-ON



009290a

TABLE 6-3: OPERATIONAL TEST (Continued)

Detection Circuit #1 (and #2): Alarm Condition Test

**CAUTION**

Before beginning this test, verify:

- Release Circuit Test Plugs and RCT are connected in the Release Circuit.
- DCT replaces the EOL Device in Detection Circuit #1.
- Determine the delay periods of TD1 and TD2 from the programming options.

1. Simulate alarm condition by turning switch on DCT to “Alarm” position.
2. If alarm relay is programmed, confirm activation of connected devices.
3. Verify accuracy of time delay:
  - a. The Red “PUSH to Activate / Alarm When Lit” LED, the Red Detection 1 LED, and sounder pulse two times per second until last 5 seconds of the TD1 period.  
 In the last 5 seconds of TD1, the Red LEDs listed above, Red Shutdown LED, and sounder pulse 4 x 1 second for 4 seconds, then only the Red Shutdown LED is steady-on for the last second.
  - b. During TD2 period the pulse rate continues at 4 x 1 second.
4. Release Circuit Activation: Upon expiration of both TD1 and TD2 time delays, the release circuit activates.

**CAUTION**  
VERIFY RCT  
INSTALLED!

**START OF  
DETECTION CIRCUIT  
ALARM CONDITION**

RED LEDs AND  
SOUNDER PULSE  
2 X 1 SECOND UNTIL  
LAST 5 SECONDS  
OF TD1 PULSE 4 X 1  
SECOND.



009290a

5 SECONDS BEFORE  
TD1 END,  
RED LEDs AND  
SOUNDER PULSE  
4 X 1 SECOND FOR  
4 SECONDS  
THEN STEADY-ON  
FOR LAST SECOND.



009290a

DURING TD2 RED  
LEDS AND SOUNDER  
PULSE 4 X 1 SECOND.



009290a

ONLY SHUTDOWN  
LED IS  
STEADY-ON FOR  
LAST SECOND  
OF TD1.



009290a

DURING TD2 RED  
LEDS AND SOUNDER  
PULSE 4 X 1 SECOND.

TABLE 6-3: OPERATIONAL TEST (Continued)

**Detection Circuit #1 (and #2): Alarm Condition Test (Continued)**

5. **Release Activated:** The Red “PUSH to Activate / Alarm When Lit” LED, Red Detection 1 LED, Red Shutdown LED, and sounder remain steady-on for 10 seconds.

**RELEASE ACTIVATED**

RED LEDs AND SOUNDER REMAIN STEADY-ON FOR 10 SECONDS




009290a

6. **Post Release Activated:** The Red Detection 1 LED, Red Shutdown LED, and sounder pulse 1 x 10 seconds.
7. Push the “DELAY/Reset/Silence” button to test sounder silence. Sounder silences and LEDs continue.
8. Confirm RCT displays “PASS.”

**POST RELEASE ACTIVATED**

RED LEDs AND SOUNDER PULSE 1 X 10 SECONDS



009290a

PUSH BUTTON

SOUNDER STOPS

CONFIRM RCT DISPLAYS “PASS”



**Detection Circuit #1 (and #2): Test Time Delay Restart**

1. Reset DCT to “Normal” position.
2. Reset RCT - press reset button.
3. Reset to Normal: Press and hold “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.  
 After reset, Power LED remains GREEN steady-on.

**RETURN TO NORMAL STATUS**

RESET DCT, RCT, AND DISPLAY MODULE

POWER LED IS GREEN STEADY-ON



009290a

TABLE 6-3: OPERATIONAL TEST (Continued)

**Detection Circuit #1 (and #2): Test Time Delay Restart (Continued)**

4. Initiate alarm condition by turning DCT switch to “Alarm.”
5. Before the TD1 time delay period expires, push “DELAY/Reset/Silence” button to restart time delay (3 quick pulses indicate time is restarted). Time delay #1 restarts to full programmed delay period. (Restarts may be limited to 1 restart or repeated indefinitely\* based on optional programming.)

**Note:** Holding button down does not pause the time delay.

**Note:** During TD2 time delay cannot be restarted.

\* Programming unlimited Time Delay Restarts voids FM Approval.

6. Allow System to complete time delay cycles (TD1 and TD2). During Release Activated\* (LEDs and sounder steady-on) push the “DELAY/Reset/Silence” button. Verify:

- a. Time delay will not restart.
- b. Sounder will not silence.

\* Red “PUSH to Activate / Alarm When Lit” LED, Red Shutdown LED, Red Detection 1 LED, and sounder remain steady-on for 10 seconds.

7. Confirm successful release signal (Pass) on RCT.

**TEST TIME DELAY  
DCT = ALARM**

BEFORE END OF TD1, PUSH BUTTON TO RESTART TD1 (MAY PUSH BUTTON MULTIPLE TIMES IF ALLOWED)

3 PULSES INDICATE RESTART



009290a

**COMPLETE TIME DELAYS**

PUSH BUTTON DURING RELEASE ACTIVATED (RED LEDs AND SOUNDER STEADY-ON)

– VERIFY NO RESPONSE TO PUSHING BUTTON

CONFIRM RCT DISPLAYS “PASS”



009290a

8. Return to normal:

- a. Reset DCT to normal position.
- b. Reset RCT - press reset button.
- c. Reset to Normal: Press and hold “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.

After reset, Power LED remains GREEN steady-on.

9. If Detection Circuit #2 is part of the system, repeat Detection Circuit Tests (listed below) using Detection Circuit #2 in place of Detection Circuit #1. Confirm DCT is in place of the EOL device on Detection Circuit #2. All figures with Detection 1 LED indicators will be Detection 2 LED indicators.

Detection Circuit - Supervision Test, page 6-7

Detection Circuit: Alarm Condition Test, page 6-9

Detection Circuit: Test Time Delay Restart, page 6-10

**RETURN TO NORMAL STATUS**

RESET DCT, RCT, AND DISPLAY MODULE

POWER LED IS GREEN STEADY-ON



009290a

TABLE 6-3: OPERATIONAL TEST (Continued)

**Manual Activation Release Circuit Test**  
 – including programmable equipment shutdown

If system is utilizing the equipment shutdown feature through the internal relay, the following steps confirm the proper operation of the shutdown. These steps will require operation of equipment.

**Note:** If needed, contact appropriate personnel for authorization of equipment start up and testing.

1. Start up equipment.
2. Open the protective guard door and push the “PUSH to Activate / Alarm When Lit” button. Release Activated starts immediately.  
 Confirm successful equipment shutdown.  
**Note:** There is no time delay upon manual activation.
3. **Release Activated** – The Red “PUSH to Activate / Alarm When Lit” LED, Red Shutdown LED, and sounder are steady-on for 10 seconds.

4. **Post Release Activated** – The Red Shutdown LED, and sounder pulse 1 x 10 seconds.
5. Push the “DELAY/Reset/Silence” button to test sounder silence. Sounder silences and LEDs continue.
6. Confirm successful release signal (Pass) on RCT.

7. Reset RCT.
8. Reset to Normal: Press and hold “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.  
 After reset, Power LED remains GREEN steady-on.


START EQUIPMENT

OPEN DOOR

PUSH RED BUTTON

RELEASE  
 ACTIVATED

RED LEDs AND  
 SOUNDER  
 REMAIN  
 STEADY-ON FOR  
 10 SECONDS



POST RELEASE  
 ACTIVATED  
 CONTINUES UNTIL  
 MODULE IS RESET

RED LEDs AND  
 SOUNDER PULSE  
 1 X 10 SECONDS

PUSH BUTTON

SOUNDER STOPS

CONFIRM RCT  
 DISPLAYS “PASS”



RETURN TO NORMAL  
 STATUS

RESET RCT AND  
 DISPLAY MODULE

POWER LED IS  
 GREEN STEADY-ON



TABLE 6-3: OPERATIONAL TEST (Continued)

**Electric Manual Actuator (EMA) Test**

**CAUTION**

If the system includes Pneumatic Manual Actuators, test these components separately in accordance with the appropriate system manual (latest revision):

The actuators also have ring pins and red strike buttons. Actuation can cause fire suppression system release.

PULL RING PIN AND STRIKE RED BUTTON



011810

1. Pull ring pin and strike red button to manually operate EMA.

**Note:** There is a two second delay upon manual activation if EMA activation is enabled on the circuit. If EMA activation is disabled, go to step 5.

2. **Release Activated** – The Red “PUSH to Activate / Alarm When Lit” LED, Red Shutdown LED, Red Detection 1 (or Detection 2) LED and sounder are steady-on for 10 seconds.

**RELEASE ACTIVATED**

RED LEDs AND SOUNDER REMAIN STEADY-ON FOR 10 SECONDS

**NOTE:** DETECTION 2 LED WILL PULSE WHEN EMA IS INSTALLED ON DETECTION CIRCUIT #2



009290a

3. **Post Release Activated** – The Red Detection 1 (or Detection 2) LED, Red Shutdown LED, and sounder pulse 1 x 10 seconds.
4. Confirm successful release signal (Pass) on RCT. Proceed to step 6.
5. If EMA activation is disabled, after a two second delay, the Detection 1 (or Detection 2) Amber LED will pulse 2 x per second every 10 seconds. If Relay #1 is programmed to activate on a fault condition, Relay #1 will transfer. No release activation will occur.

**POST RELEASE ACTIVATED**

CONTINUES UNTIL MODULE IS RESET

RED LEDs AND SOUNDER PULSE 1 X 10 SECONDS



009290a

TABLE 6-3: OPERATIONAL TEST (Continued)

**Electric Manual Actuator (EMA) Test (Continued)**

6. Reset EMA by pulling red strike button up to set position, re-install ring pin. Do not reseal at this time.
7. Reset RCT, if applicable.
8. Reset to Normal: Press and hold “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.
9. Repeat Test for each remaining EMA following above steps.

**CAUTION**

If the system includes Pneumatic Manual Actuators, test these components separately in accordance with the appropriate system manual (latest revision):

The actuators also have ring pins and red strike buttons. Actuation can cause fire suppression system release.

RESET EMA:  
PULL RED BUTTON UP,  
INSERT RING PIN



011932

**RETURN TO  
NORMAL STATUS**

RESET RCT, AND  
MODULE

POWER LED IS  
GREEN STEADY-ON



009290a

TABLE 6-4: SECONDARY POWER – OPERATIONAL TEST

**System Test on Secondary Power Only\***

1. Disconnect Primary Power by disconnecting primary power circuit cable from the ICM.
2. Power LED pulses AMBER 1 x 3 seconds.
3. Press and hold “Delay/Reset/Silence” button for 3 seconds - Power LED pulses GREEN 1 x 3 seconds.
4. Complete the following tests (pages 6-9 through 6-16) with system on secondary power:

- Detection Circuit: Alarm Condition Test
- Detection Circuit: Test Time Delay Restart
- Manual Activation Release Circuit Test
- Electric Manual Actuator (EMA) Test

5. Install new/unused battery (if a test battery was not used).

**Note:** Multiple release circuit activations deplete battery life.

**Note:** For above tests the Power LED continues to pulse GREEN 1 x 3 seconds.

**Note:** If battery is low, Power LED pulses AMBER 1 x 10 seconds.

\* OPERATION ON SECONDARY POWER **ONLY**, VOIDS FM APPROVAL.

**SECONDARY POWER TESTING**

GREEN LED PULSES  
1 X 3 SECONDS

REPEAT TESTS  
PAGES 6-9 TO 6-16  
ON **SECONDARY**  
POWER



009290a

TABLE 6-5: PLACING CHECKFIRE 210-D SYSTEM IN SERVICE

1. Disconnect all power. Disconnect primary power circuit connection at the CHECKFIRE 210-D ICM Power cable. Disconnect ICM battery cable from battery pigtail.

DISCONNECT ALL POWER



009290a

2. Confirm all EMAs are in the up / ring-pinned positions and properly re-sealed with a visual seal.

ALL EMAs IN UP/PINNED POSITION AND SEALED



011933

3. Close guard door for “PUSH To Activate / Alarm When Lit” button and install visual seal.

SEAL GUARD DOOR PROTECTING RED BUTTON



009275a

4. Replace DCTs with Detection EOL Devices in the detection circuits or reconnect Detection Circuit Cables.

REPLACE DCT WITH EOL DEVICE IN DETECTION CIRCUITS



011807

5. Remove RCT and/or Release Circuit Test Plugs from Release Circuit Drop Cables.

REMOVE RCT AND RELEASE CIRCUIT TEST PLUGS



011817

**TABLE 6-5: PLACING CHECKFIRE 210-D SYSTEM IN SERVICE (Continued)**

6. Remove actuator cap on top of Electric-Pneumatic Actuator and retain for future use.

**CAUTION**

When handling the PAD, always point actuating end away from yourself and others. On electrical initiation, PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and the detaching disk.




012168

7. Write installation date on PAD, DO NOT cover manufacturing date on label. Install PAD into Release Circuit Drop Cable. Verify o-ring is in place on PAD.

**NOTICE**

The PAD (must be replaced after being in-service for five years.

- a. The in-service date should be recorded in installation and maintenance records and written on the PAD label with permanent marker at the time of installation.
- b. The PAD has a 10 year shelf life when stored in an environmentally stable location. The 5 year in-service life may not extend beyond the 10 year shelf life. (The month and year of manufacture is printed on the label located on the PAD body).




011812/011813

WRITE INSTALL DATE ON PAD LABEL  
MAKE SURE MANUFACTURING DATE IS READABLE



009169

Install all PADs in the Release Circuit Drop Cables.



011806

PAD FIELD INSTALLED IN CABLE

TABLE 6-5: PLACING CHECKFIRE 210-D SYSTEM IN SERVICE (Continued)

8. If needed complete installation of optional Pneumatic Manual Actuators. See Section 5 – Installation and Programming, page 5-16, Pneumatic Manual Actuation (Optional).
9. Re-install Pneumatic Manual Actuator cartridges if previously removed.
10. Reconnect all power as required. Reconnect primary power circuit connection at the CHECKFIRE 210-D ICM power cable. Reconnect ICM battery cable to battery pigtail, secondary power.
  - When replacing the battery module the battery life indicator must be reset using the ICM or connect to a PC with the ANSUL® CHECKFIRE 210 Programmer software.
    - a. Replace the battery module with a new/unused unit. Record the replacement date on the inside sticker of the battery compartment cover and on the battery itself.
    - b. Reset Battery Life Indicator:  
 ICM Instructions:
      - 1) Put system in isolate mode by pressing and holding the “DELAY/Reset/Silence” button on the CHECKFIRE 210-D Display Module for approximately 8 seconds (two consecutive resets).
      - 2) Press and hold the programming button for more than five seconds then release.
      - 3) All programming LEDs pulse 3 times in one second to confirm battery life indicator is reset.
11. Lubricate PAD, Electric-Pneumatic Actuator and Release Circuit Drop Cable o-rings with Dow Corning #4 grease. Attach Release Circuit Drop Cable with installed PAD to Electric-Pneumatic Actuator and hand-tighten the connector. Once the Drop Cable is fully seated, torque to 20 ft-lb to 25 ft-lb (27 N·m to 34 N·m) which may be applied with an appropriate tool. (Keep actuator cap for recharge and maintenance procedures.)
12. Confirm system is clear of faults and alarm conditions.
13. Cancel isolate mode by holding the “DELAY/Reset/Silence” button on the CHECKFIRE 210-D Display Module for approximately 8 seconds (two consecutive resets).
16. Reset to Normal: Press and hold “DELAY/Reset/Silence” button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.
17. Confirm all test results are recorded in a permanent record. See sample on next page. If desired, download the Event History Log, refer to Section 5 – Installation and Programming, pages 5-33 and 5-34. When complete re-install battery cover.


ELECTRONIC ACTIVATION  
 INSTALLATION COMPLETE

IF REMOVED, RE-INSTALL  
 MANUAL ACTUATOR  
 CARTRIDGES

RECONNECT ALL POWER

CONFIRM SYSTEM CLEAR  
 OF FAULTS AND/OR ALARM  
 CONDITIONS

REMOVE SYSTEM FROM  
 ISOLATE MODE



011812

**CAUTION**

FOR ELECTRIC ACTUATION ONLY,  
 1/4 IN. BRASS PLUGS MUST REMAIN  
 IN PLACE OR FIRE SUPPRESSION  
 SYSTEM WILL NOT OPERATE.

**RESET TO NORMAL**

PRESS AND HOLD  
 3 SECONDS

POWER LED IS  
 GREEN STEADY-ON



009290

**CHECKFIRE 210-D Operational Test Checklist**

(COPY BEFORE USE)

Item	Test Date: _____	Yes	No
a) Vehicle Primary Power operation verified		<input type="checkbox"/>	<input type="checkbox"/>
b) Internal Secondary Battery Power operation verified		<input type="checkbox"/>	<input type="checkbox"/>
c) Isolate mode tested and verified		<input type="checkbox"/>	<input type="checkbox"/>
d) Detection Circuit #1 tested (Supervisory and Activation)		<input type="checkbox"/>	<input type="checkbox"/>
e) Detection Circuit #2 tested [if used] (Supervisory and Activation)		<input type="checkbox"/>	<input type="checkbox"/>
f) Time Delays tested (Factory default: TD1 = 10 sec and TD2 = 10 sec) <b>Note:</b> If default 'Time delays' are changed, indicate TD settings below: <b>TD1 in sec.</b> _____ <b>TD2 in sec.</b> _____		<input type="checkbox"/>	<input type="checkbox"/>
g) Time Delay Restart tested (Factory default: 1 restarts) <b>Note:</b> If default 'Restarts' are changed to 'Unlimited', indicate Yes below: <b>Unlimited Yes:</b> <input type="checkbox"/>		<input type="checkbox"/>	<input type="checkbox"/>
h) Release Circuit tested (Supervisory and Activation)		<input type="checkbox"/>	<input type="checkbox"/>
i) Relay function tested (Factory default: Rly 1 – Alarm, Rly 2 – Shutdown) <b>Note:</b> If default 'Relay Settings' are changed, indicate below: <b>RLY 1:</b> _____ <b>RLY 2:</b> _____		<input type="checkbox"/>	<input type="checkbox"/>
j) Manual Actuation at "Push to Activate Button" tested		<input type="checkbox"/>	<input type="checkbox"/>
k) Manual Actuation at Electric Manual Actuators tested		<input type="checkbox"/>	<input type="checkbox"/>
l) Above tests with both Primary (machine) and Secondary (battery) power		<input type="checkbox"/>	<input type="checkbox"/>
m) Install NEW (Unused) Battery [date and sign] – <b>Record Date:</b> _____		<input type="checkbox"/>	<input type="checkbox"/>
n) Reset Battery Life Indicator		<input type="checkbox"/>	<input type="checkbox"/>
o) Install Protracting Actuation Device (PAD) – <b>Record Date:</b> _____		<input type="checkbox"/>	<input type="checkbox"/>
p) All visual seals in place and secure		<input type="checkbox"/>	<input type="checkbox"/>
q) Maintenance tag signed and in place		<input type="checkbox"/>	<input type="checkbox"/>
r) All required Warning and Hazardous Labels in place		<input type="checkbox"/>	<input type="checkbox"/>

**NOTES:**

### IN CASE OF FIRE

Read these instructions and precautions carefully until they are clearly understood. All equipment operators or anyone who has any responsibility for the equipment should understand how to operate the CHECKFIRE 210-D Detection and Actuation System. Every operator should be completely trained in these procedures.

- When the detection circuit alarm sounds, bring the equipment to a safe controlled stop, shut off the engine, and exit

**Note:** Equipment left running may add fuel to the fire or re-ignite the fire with heat or sparks.

- Safely exit and move a safe distance from equipment, and stand by with hand portable extinguisher

### WARNING

In case of fire, evacuate area to lessen risk of injury from flames, heat, hazardous vapors, explosions, or other hazards.

#### Automatic Detection and System Actuation

The CHECKFIRE 210-D Detection and Actuation System includes a thermal detection devices located in each protected area. On detecting an alarm condition, the CHECKFIRE 210-D System starts the time delay cycle; at the end of the cycle an electrical release signal initiates the fire suppression system.

#### Manual System Operation

Bring equipment to a safe stop, shut off engine, and manually actuate system.

Perform one of the following to manually operate the system:

- Open the guard door on CHECKFIRE 210-D Display Module (break visual seal), and push the “PUSH To Activate / Alarm When Lit” button, see Figure 7-1.
- Pull ring pin and strike the red button on an Electric Manual Actuator (EMA), see Figure 7-1.
- If an optional pneumatic actuation system is installed, pull ring pin and strike red button on the pneumatic manual actuator.

Safely exit and move a safe distance from equipment, and stand by with hand portable extinguisher.

### CAUTION

Manual system operation will result in immediate system discharge which may obscure vision. Make certain equipment is stopped safely before manually operating system.

#### Automatic Equipment Shutdown

The CHECKFIRE 210-D System includes programmable relays that may be connected to a shutdown device. If a shutdown device is connected to a CHECKFIRE 210-D relay, make certain all responsible personnel understand shutdown device operation, and when it will operate with reference to a release/discharge condition.

If the “DELAY/Reset/Silence” button (on the Display Module) is pushed and released **before the end of Time Delay #1 (TD1)** (5, 10 or 15 seconds), the time delay restarts the time delay period. This will delay transfer of the shutdown relay and the start of Time Delay #2 (TD2) (0, 5, 10 or 15 seconds), and eventual system activation. This delay can be repeated (using the “DELAY/Reset/Silence” button) if necessary, to safely stop the equipment before the shutdown relay transfers automatically shutting down the equipment and activating the system.

**Note:** Press and hold will not pause the time delay.

### WARNING

Delay of system operation may allow the fire to intensify, which could result in a more difficult fire to suppress.


#### Exit Vehicle/Equipment and Move Safely Away

In the event of a fire, follow all site specific procedures. When no procedures are outlined use the following as a guide.

Bring equipment to a safe controlled stop as soon as possible.

If fire suppression system has not yet operated, manually operate system (refer to Manual System Operation in this section).

Safely exit the vehicle/equipment and move away from the equipment. Stand-by with hand portable fire extinguisher to guard against any fire that may re-ignite after fire suppression system has been discharged. Remain alert until equipment cools and possibility of re-ignition is no longer a threat.




OR



FIGURE 7-1  
IMMEDIATE RELEASE OPTIONS

**CHECKFIRE 210 / 210-D OWNERS' GUIDE**

The CHECKFIRE 210 / 210-D Owners' Guide (see Figure 7-2) is available for download using the QR Code (see Figure 7-3). The code is also on the QR Code Pack Sheet shipped with the 210-D ICM.



**FIGURE 7-2**  
**CHECKFIRE 210 / 210-D OWNERS' GUIDE**  
 012006



[docs.jci.com/ANSUL/CHECKFIRE210-D\\_OwnersGuide](https://docs.jci.com/ANSUL/CHECKFIRE210-D_OwnersGuide)

**FIGURE 7-3**  
**QR CODE – CHECKFIRE 210 / 210-D OWNERS' GUIDE**  
 210-D QR Code

Download the complete guide with the QR Code, print, and place in an easy to reach location for the operator. The guide provides instructions for manual actuation and a review of the automatic system operation.

Complete pages 1 and 2 in the Owners' Guide with the system information as installed (see Figure 7-4). This will help the operator become familiar with the actions required for the specific vehicle if an alarm is activated. The operator should review this system guide regularly before operating the vehicle/equipment.

**Fill-In System Information (as installed)**

**Power:**  Internal Only  Dual (External & Internal)  
 External Power Supply (vehicle battery, power panel, etc.):  
 \_\_\_\_\_

**TD1** (Time Delay 1, seconds):  0  5  10  15  
**TD2** (Time Delay 2, seconds):  0  5  10  15

**Time Delay Restarts:**  1  Unlimited

**Relay #1:**  Alarm  Fault  Not Used  
**Relay #2:**  Shutdown  Alarm  Not Used

Pressure Switch Auxiliary Operation: \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

PAGE 1

**Fill-In System Information (as installed)**

Electric or Pneumatic Manual Actuator Location(s):  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_  
 \_\_\_\_\_

PAGE 2

**FIGURE 7-4**  
**COMPLETE THE SYSTEM INFORMATION**  
 011938/ 011939

## INSPECTION AND MAINTENANCE

To help ensure the CHECKFIRE 210-D Detection and Actuation System will operate as intended, proper inspection and maintenance procedures must be performed at the specified intervals.

### DAILY INSPECTIONS

The vehicle/equipment operator must check the system daily by visually verifying:

- Power LED is Green and steady-on with primary power or pulsing 1 x 3 seconds with secondary power, see Figure 8-1.  
**Note:** Must operate on dual power (primary and secondary) to maintain FM Approval.
- All other LEDs are off (not steady-on or pulsing)
- Sounder is silent
- No apparent damage to any components
- Visual seals in place

If any other conditions exist, contact the local Authorized ANSUL® Distributor or a person who has been trained and authorized by Johnson Controls to perform inspection and maintenance service on the CHECKFIRE 210-D System.

WITH PRIMARY POWER, LED IS GREEN STEADY-ON

WITH SECONDARY POWER, LED IS PULSING GREEN 1 X 3 SECONDS \*

\* MUST OPERATE ON DUAL POWER (PRIMARY AND SECONDARY) TO MAINTAIN FM APPROVAL.



**FIGURE 8-1**  
**NORMAL CONDITION**

009275a

## MAINTENANCE

To help ensure the system will operate as intended, maintenance shall be performed semi-annually or sooner, depending on the operating and/or environmental conditions. Maintenance should be performed by an Authorized ANSUL® Distributor or a person who has been trained and authorized by Johnson Controls to perform maintenance checks.

Visually inspect system to confirm it is adequate for the equipment hazard areas.

If system is displaying faults, go to Section 9 – Troubleshooting prior to continuing Maintenance.

1. Check condition of the CHECKFIRE 210-D Display Module.
  - a. Confirm securely mounted. Verify all fasteners are tight and display module enclosure nut is hand-tight.
  - b. If secured in bracket, check bracket for damage or wear to ratchet teeth.
  - c. Check Display Module for damage or undue wear.
2. Check condition of CHECKFIRE 210-D Interface Control Module (ICM).
  - a. Confirm CHECKFIRE 210-D Mounting Plate is securely mounted and CHECKFIRE ICM is securely affixed to Mounting Plate.
3. Check cable connectivity and integrity.
  - a. Inspect all cables and connections for wear, abrasion or other physical damage.
  - b. Confirm all cables are correctly secured.

**MAINTENANCE (Continued)**

4. Check integrity of each component.
  - a. Confirm Electric Manual Actuator (EMA) is:
    - Securely mounted
    - No damage, wear, or abrasions
    - Red strike button intact
    - Ring pin intact and in place
    - Rubber boot intact
    - Connector secure
    - Visual seal intact
    - Bracket secure
  - b. Confirm Electric-Pneumatic Actuator is:
    - Securely mounted
    - All actuator components appropriately tightened
    - Release Circuit Drop Cable connection tight
    - 1/4 in. brass plugs securely tightened in pneumatic ports OR - if optional pneumatic actuation, 1/4 in. actuation hose fittings securely in place
5. If optional Pneumatic Manual Actuator is part of system refer to appropriate fire suppression system manual for inspection and maintenance instructions (latest revision).
6. If system includes optional pneumatic manual actuators, carefully remove the LT-10-R cartridges from the pneumatic manual actuators, install shipping caps, and set aside in a safe location.
7. Check and perform maintenance on each Electric-Pneumatic Actuator (installed on each agent tank expellant gas cartridge):
  - a. Remove power from system both primary and secondary as applicable.
  - b. If attached, remove Release Circuit Drop Cable from Electric-Pneumatic Actuator.

**CAUTION**

When handling the PAD, always point actuating end away from yourself and others. On electrical initiation, PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and the detaching disk.


- c. Check PAD and maintenance records for installation date of PAD to determine if PAD needs replacement. Refer to Five-Year PAD Replacement instructions, Page 8-4.
- d. Confirm PAD o-ring is in place; if absent, check inside actuator and remove. (New PAD comes with new o-ring.) See Figure 8-2.

**CAUTION**


Failure to remove loose o-ring from inside actuator body can result in improper positioning of the PAD and incorrect system operation.

- e. Examine actuating end of PAD to determine if PAD has actuated.

**Note:** Occasionally the actuating pin will pull back into the PAD. Inspect actuating end where pin extends. If pin is visible, PAD has actuated. See Figure 8-3.
- f. If PAD actuated, remove PAD from the connector and discard. If possible, determine why PAD was actuated. **Do not install new PAD until testing is complete, see Step 9.** Find and discard small brass disk ejected from actuating end of PAD during release.



**FIGURE 8-2**  
**CHECK PAD**  
011806




**FIGURE 8-3**  
**CHECK END OF PAD**  
009243

**MAINTENANCE (Continued)**

8. Electric-Pneumatic Actuator – Unscrew actuators from nitrogen cartridges and install cartridge safety shipping caps and set aside. Inspect all threaded areas for nicks, burrs, and cross-threads.

ELECTRIC-PNEUMATIC ACTUATOR, see Figure 8-4.

- If needed, remove 1/4 in. gas actuation hoses.
- Loosen and slide base of Electric-Pneumatic Actuator sideways to remove from each expellant gas cartridge.
- Disassemble actuator and inspect for damage. Remove puncture pin spring and pull puncture pin out of body being careful not to bend puncture pin. Retain all parts for re-assembly. See Figure 8-4.



**FIGURE 8-4**  
**ELECTRIC-PNEUMATIC ACTUATOR**  
012164

- Inspect and replace all damaged components (o-rings, flat gaskets, etc.).
- Lubricate all o-rings with Dow Corning #4 (or equal) and reinstall.
- Replace flat gasket semi-annually and lubricate.
- Install spring on puncture pin and insert into body. Push down several times to confirm ease of movement.
- Reassemble actuator.
- Install Electric-Pneumatic Actuator cap or drop cable if used. Ensure components are tight for testing the actuation lines.

9. Test system and place into service by completing all steps in Section 6 – Operational Test and Place in Service, prior to proceeding to Step 10.

10. Secondary Power Replacement:

- Secondary power, internal battery must be replaced when battery voltage is less than 3VDC and there is a low power indication (i.e., Power LED pulses Amber 1 x 10 seconds) or battery life remaining is less than 25%. Percent of battery life remaining is listed in the header information of the Event History Log. To save or view the Event History Log review Section 5 – Installation and Programming, Page 5-26, for manual download instructions or Page 5-28 for viewing with the ANSUL® CHECKFIRE 210 Programmer software.

**NOTICE**

If a test battery is not used for maintenance and recharge – replace battery semi-annually.

PC Instructions:

When connected to the ANSUL® CHECKFIRE 210 Programmer software, click the Reset button in the Battery Life Remaining section.

**CAUTION**

Performing a reset of the battery life indicator without installing a new/unused replacement battery module can result in faulty battery indications and unpredictable CHECKFIRE 210-D System operation.

**CAUTION**

Contact your local waste disposal company for information concerning the correct disposal of lithium batteries.

11. For fire suppression system maintenance refer to appropriate fire suppression system manual (latest revision).
12. Confirm all system equipment has been correctly serviced and recharged, and visual seals are in place on all EMAs and CHECKFIRE 210-D Display Module.
13. Record date of maintenance on tag and in permanent record file. Notify operating personnel system is back in service.


## MAINTENANCE (Continued)

### Five-Year PAD Replacement

#### **CAUTION**

When handling the PAD, always point actuating end away from yourself and others. On electrical initiation, PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and the detaching disk.

1. The PAD (Protracting Actuation Device) must be replaced after being in-service for five years.
  - a. The in-service date must be recorded in installation and maintenance records and written on the PAD label with permanent marker at the time of installation. See Figure 8-5.



**FIGURE 8-5**  
**WRITE DATE ON PAD**

009169

- b. The PAD has a 10 year shelf life when stored in an environmentally stable location. The 5 year in-service life may not extend beyond the 10 year shelf life. The month and year of manufacture is printed on the label, see Figure 8-6.



**FIGURE 8-6**  
**PAD MANUFACTURING DATE**

009247

- c. For proper disposal, the PAD must be actuated before discarding. Actuate the PAD in a safe manner consistent with site safety policies.

2. Write installation date on new PADs. DO NOT cover manufacturing date on label. See Figure 8-5. Do not install PADs until testing is complete.
3. To complete re-installation of the Electric-Pneumatic Actuator, follow the instructions in the applicable ANSUL® vehicle fire suppression system manual.
4. Place in service by completing Table 6-5: Placing CHECKFIRE 210-D System in Service, Pages 6-16 to 6-19 (Section 6 – Operational Test and Place in Service).
5. Record date of PAD replacement in a permanent record file. Notify operating personnel the system is back in service.

## RECHARGE

Individuals responsible for recharging, inspecting, and maintaining a CHECKFIRE 210-D System, must hold current ANSUL® Certification from an ANSUL® CHECKFIRE 210-D Training Program.

For continued protection, the CHECKFIRE 210-D System and the fire suppression system must be recharged immediately after activation.

Before performing the recharge steps, inspect the CHECKFIRE 210-D Detection and Actuation System to determine cause of system release.

1. Remove power from system, both primary and secondary.
2. Check all Electric Manual Actuators (EMAs) for evidence of operation and determine if visual seal is intact. For EMAs needing reset or re-sealing complete the following:
  - a. Reset switch to normal position (pull button out)
  - b. Insert ring pin
  - c. Wait to seal until after system test
3. If optional pneumatic actuation is part of the system follow recharge instructions in the appropriate suppression system manual (latest revision).
4. Closely examine all Detection Circuit Cable and Linear Detector for loose connectors and damage (cut, abraded, burnt, blackened, melted, deformed, etc.).
  - a. Inspect all Detection Circuit Cable for damage and replace if there are visible and mechanical signs of damage (brittleness, deformation, discoloration, etc.).

#### **CAUTION**

Failure to replace damaged cable can result in unintended system activation.

- b. If a fire event was the cause of discharge, all Linear Detector cables in the hazard area must be replaced; otherwise, inspect for damage and replace if damaged.
5. Closely examine all Release Circuit Cables for loose connectors and damage (cut, abraded, burnt, blackened, melted, deformed, etc.). Replace cables as needed.

**RECHARGE (Continued)**

6. Check and perform maintenance on each Electric-Pneumatic Actuator (installed on each agent tank expellant gas cartridge).
 

**Note:** If system was electrically operated all of the PADs should be actuated.

  - a. If attached, remove Release Circuit Drop Cable from Electric-Pneumatic Actuator.

**⚠ CAUTION**

When handling the PAD, always point actuating end away from yourself and others. On electrical initiation, PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and/or the detaching disk.

**CAUTION**

The Release Circuit Drop Cable with PAD must be removed from Electric-Pneumatic Actuator to retract actuator puncture pin. An actuated PAD can lock the Electric-Pneumatic Actuator puncture pin in the actuated position until removed from actuator.

- b. Confirm PAD o-ring is in place; if absent, check inside actuator and remove. (New PAD comes with new o-ring.) See Figure 8-7.

**CAUTION**

Failure to remove loose o-ring from inside actuator body can result in improper positioning of the PAD and incorrect system operation.

- c. Examine actuating end of PAD to determine if PAD has actuated.
 


**Note:** Occasionally the actuating pin will pull back into the PAD. Inspect actuating end where pin extends. If pin is visible PAD has actuated. See Figure 8-8.
    - d. If PAD actuated, remove PAD from the connector and discard. See Figure 8-7.

**NOTICE**


**Do not install new PAD until testing is complete, see Step 9.**

Find and discard small brass disk ejected from actuating end of PAD during release.

- e. If PAD has not actuated (system actuated with optional pneumatic manual actuator), refer to Five-Year PAD Replacement instructions, Page 8-4, and replace if needed.



**FIGURE 8-7  
ACTUATED PAD**  
011815




**FIGURE 8-8  
CHECK END OF PAD**  
009243

- f. If needed, remove 1/4 in. gas actuation hoses. Loosen and slide base of Electric-Pneumatic Actuator sideways to remove from each expellant gas cartridge.

**CAUTION**

If Electric-Pneumatic Actuator is difficult to remove puncture pin is not fully retracted. Do not force.

- g. Disassemble and clean the Electric-Pneumatic Actuator by following the instructions in Maintenance, Step No. 8, Page 8-3.



**FIGURE 8-9  
ELECTRIC-PNEUMATIC ACTUATOR  
RETAIN ALL PARTS FOR RE-ASSEMBLY**  
011814/ 011813


## RECHARGE (Continued)

### Step 6 (Continued)

- h. Lubricate all o-rings (puncture pin o-ring, EPA o-ring, PAD o-ring and Release Drop Cable o-rings) and gaskets with Dow Corning #4 (or equal) and reinstall. See Figure 8-9.
7. Recharge the fire suppression system in accordance with the applicable vehicle fire suppression system manual that is installed.
8. After fire suppression system recharge is complete:
  - a. Confirm puncture pin is completely retracted on the Electric-Pneumatic Actuators. See Figure 8-10.
9. Test system and place into service by completing all steps in Section 6 – Operational Test and Place in Service, prior to proceeding to Step 10.
10. Complete steps 1 through 4 in the Maintenance Section.
11. Confirm all system equipment has been correctly serviced and recharged, and visual seals are in place on all EMAs and Display Module.
12. Record date of recharge on tag and in permanent record file. Notify operating personnel system is back in service.

### WARNING

Before attaching Electric-Pneumatic Actuator to expellant gas cartridge, **verify the cartridge is correctly secured and confirm actuator puncture pin is in the completely retracted position.** If puncture pin is not completely retracted the cartridge seal can become damaged or pierced which can result in system actuation or serious personal injury or death.



**FIGURE 8-10**  
**RETRACT ACTUATOR PIN**  
009220

- b. Re-install Electric-Pneumatic Actuators on expellant gas cartridges.

**TROUBLESHOOTING**

The following tables provide information on normal operating and fault condition indications for the CHECKFIRE 210-D Detection and Actuation System. **For detailed circuit testing procedures, refer to Table 9-7 – Specific Circuit Testing Procedures.** When all faults are cleared, confirm proper operation of the entire CHECKFIRE 210-D System by completing Section 6 – Operational Test and Place in Service.

**TABLE 9-1: POWER LED INDICATIONS**

<p><b>Normal Operating Condition – Primary/Secondary Power</b></p>	<p>KEY TO DISPLAY MODULE INDICATIONS – IDENTIFY LEDS AS:</p>  <p>LED STEADY-ON (Red or Green)      LED PULSING (Amber, Red or Green)      LED OFF</p>
<p>Green Power LED is steady-on indicating a normal condition.</p> <p>System is monitoring all circuits and is ready to respond to a fault/alarm condition.</p>	<p><b>NORMAL CONDITION PRIMARY AND SECONDARY SYSTEMS OPERATING FOR DUAL POWER</b></p>  <p>LED IS GREEN STEADY-ON</p> <p>009290a</p>
<p><b>Secondary Power Condition</b></p>	<p><b>SECONDARY POWER ONLY (NOT FM APPROVED)</b></p>  <p>GREEN LED PULSES 1 X 3 SECONDS</p> <p>009290a</p>
<p>Green Power LED pulses 1 x 3 seconds indicating normal operation on secondary power supply only*.</p>	
<p>System is monitoring all circuits and is ready to respond to a fault/alarm condition.</p>	
<p>* Must operate on dual power (primary and secondary) to maintain FM Approval.</p>	

TABLE 9-1: POWER LED INDICATIONS (Continued)

**Primary Power Fault**

Amber Power LED pulsing 1 x 3 seconds, and Sounder pulsing 1 x 10 seconds indicating power from the primary power source dropped below 9.5VDC causing a fault condition. When primary power source drops below an acceptable level system automatically draws power from secondary power source.

- Check Power Circuit Cable and Fused Power Circuit Cable for proper connections and for proper voltage
- Confirm fuse is good and installed correctly (See Section 5 – Installation and Programming, page 5-14 for correct removal and replacement of fuse.)
- Replace cables if unable to clear fault indication

For more information see TABLE 9-7: Specific Circuit Testing Procedures.

**DUAL POWER FAULT**

AMBER LED PULSES  
 1 X 3 SECONDS

SOUNDER PULSES  
 1 X 10 SECONDS



**Secondary Power Fault**

Amber Power LED and Sounder pulsing 1 x 10 seconds indicating power from the Battery Module dropped below acceptable level causing a fault condition.

- Check connection of the Battery Module to the ICM battery cable located under the battery compartment cover
- Check and replace secondary power Battery Module with a new/unused battery module (See Internal Secondary Power Replacement in Section 8 – Inspection, Maintenance and Recharge, page 8-3.)

**PRIMARY/ SECONDARY POWER FAULT**

AMBER LED AND  
 SOUNDER PULSE  
 1 X 10 SECONDS



**TABLE 9-2: RELEASE LED INDICATIONS**

<p><b>AMBER Release LED</b></p>	<p>Amber Release LED and Sounder pulsing 1 x 10 seconds indicating Release Circuit fault.</p>	<p><b>RELEASE CIRCUIT FAULT</b></p>	
<ul style="list-style-type: none"> <li>• Check Release Circuit Cables for an open circuit or a ground fault; replace cables as needed</li> <li>• Check connections</li> <li>• Indicates post release activated when combined with Shutdown LED and/or other LEDs. Check for activated or missing PADs; replace as needed following Section 8 – Recharge, Inspection, and Maintenance, page 8-1, for Recharge instructions.</li> </ul>	<p>AMBER LED AND SOUNDER PULSE 1 X 10 SECONDS</p>	<p><b>POST RELEASE ACTIVATED MODE/ RELEASE CIRCUIT FAULT</b></p>	
<p><b>RED Shutdown LED</b></p>	<p>Red Shutdown LED, and Sounder pulsing 1 x 10 seconds indicating Post Release Activated Mode/Release Circuit Fault.</p>	<p>RED LED AND SOUNDER PULSE 1 X 10 SECONDS</p>	<p>009290a</p>
<p><b>For more information see TABLE 9-7: Specific Circuit Testing Procedures.</b></p>			

TABLE 9-3: DETECTION LED INDICATIONS

**AMBER Detection 1 and/or 2 LED**

Applies to Detection Circuit #1 and/or #2.

Amber Detection Circuit #1 and/or #2 LED and sounder pulsing 1 x 10 seconds indicating Detection Circuit fault.

- Check connections on the indicated circuits
- Check connections for the presence of moisture or debris. Clean with an off-the-shelf electrical contact cleaner.
- Check Detection Circuit Cables for an open circuit or a ground fault; replace cables as needed
- Verify Linear Detector, continuity or ground fault condition. Replace as needed

Pressing the DELAY/SILENCE/RESET button on the Checkfire 210-D Display Module will silence the audible sounder and change the LED blink rate on the corresponding LED as described in the Detection and Release section of the Trouble Shooting Guides. This change will aid in easier troubleshooting in the field.

**DETECTION CIRCUIT FAULT**

AMBER LEDs AND  
 SOUNDER PULSE  
 1 X 10 SECONDS



009290a

**RED Detection 1 and/or 2 LED**

Applies to either Detection Circuit #1 or #2.

Red Detection Circuit #1 and/or #2 LED and Sounder pulsing 1 x 1 second indicating Detection Circuit alarm condition.

- Investigate alarm condition in hazard area
- Check for damaged or activated detectors
- Check for damaged cables
- Check connections on the indicated circuits

**DETECTION CIRCUIT ALARM CONDITION**

RED LEDs AND  
 SOUNDER PULSE  
 1 X 1 SECONDS



009290a

Red Detection Circuit #1 and/or #2 LED and Sounder pulsing 1 x 10 seconds indicating Detection Circuit alarm condition during Post Release Activated Mode. Refer to Section 8 – Recharge, Inspection, and Maintenance, page 8-1, for Recharge instructions.

- Investigate alarm condition in hazard area
- Check for damaged or activated detectors
- Check for damaged cables
- Check connections on the indicated circuits

**DETECTION CIRCUIT ALARM CONDITION - DURING POST RELEASE ACTIVATED MODE**

RED LEDs AND  
 SOUNDER PULSE  
 1 X 10 SECONDS



009290a

For more information see TABLE 9-7: Specific Circuit Testing Procedures.

TABLE 9-4: ISOLATE MODE

**AMBER Isolate LED**

Amber Isolate LED and Sounder pulsing quickly 2 x 10 seconds indicate CHECKFIRE 210-D System is in isolate mode.

Placing the system in isolate mode minimizes occurrence of a false fire suppression system discharge during service or maintenance procedures on the protected vehicle/equipment.

**CAUTION**

When system is in isolate mode, the Release Circuit cannot be initiated by an automatic detection circuit input.

In the event of fire, manual actuation will bypass isolate mode for immediate release. To operate manually:

- Press “PUSH to Activate/ Alarm When Lit” button

**Or**

- Pull ring pin and operate RED Strike button on an EMA (if *Isolate Mode EMA Activation* is programmed for ENABLED) or a pneumatic manual actuator

**Note:** If a fault or alarm condition occurs while in isolate mode the condition will be displayed and the module will remain in isolate mode.

**CAUTION**

If an alarm condition has occurred in isolate mode, do not return the System to normal until cause of detection notification is found and cleared. Switching the Isolate switch to the normal position during an alarm condition results in an immediate start of the Time Delay sequences leading to a release.

**ISOLATE MODE**

AMBER LED AND  
SOUNDER PULSE  
2 X 10 SECONDS



TABLE 9-5: MULTIPLE AMBER LED INDICATIONS

Amber Release, Detection 1 and 2, Power LEDs, and Sounder pulsing quickly 1 x 1 second indicates a loss of communication between Display Module and ICM processor.

1. Remove all power from the system, disconnect primary power and secondary power if used.
2. Reconnect power; if the system still shows the four amber LEDs, replace ICM with a new ICM.

Loss of communications can be confirmed by a review of the Event History Log for the message: Display Fault.

**LOSS OF COMMUNICATION**

AMBER LEDS AND  
SOUNDER PULSE  
1 X 1 SECOND



TABLE 9-6: NO LED INDICATIONS

**All LEDs - No Indication**

- Confirm Display Cable is not damaged and connected to ICM
- Determine if power is available at the ICM by temporarily putting the System into programming mode using the programming button (press 3 x 1 second) under the battery cover. If LEDs illuminate when entering programming mode, the ICM has power (go to next bullet). If the LEDs do not illuminate, then the System does not have power or ICM has an internal hardware fault; complete the following steps:
  1. Check connection of Battery Module to ICM battery cable located under the battery compartment cover.
  2. Replace Battery Module with a new/unused battery module. See Battery Replacement in Section 8 – Recharge, Inspection, and Maintenance, page 8-5.
  3. Check primary power connections, fuse, and cables, if utilized, for damage.
  4. Check primary power supply for proper voltage, if connected.
  5. If proper voltage is verified at the ICM, and Power LED remains off, check display cable connections between display module and ICM.
- If the ICM has power, there is loss of communication between Display Module and ICM
  1. Remove all power from the system, disconnect primary power and secondary power.
  2. Reconnect power; if the system still shows no indication, replace Display Module with a new display module.
  3. If new Display Module still has no LED indication, replace the ICM with a new ICM.



009290a

**For more information see TABLE 9-7: Specific Circuit Testing Procedures.**

TABLE 9-7: SPECIFIC CIRCUIT TESTING PROCEDURES

### General Instructions

If faults are indicated on the CHECKFIRE 210-D Display Module, test the connecting cables and end of circuit devices (EMAs, EOL Device, branch terminators, PADs, etc.), for proper connection to the system.

Before testing specific circuits, confirm completion of a thorough visual inspection. Inspect all cables for damage and replace if there are visible or mechanical signs of damage (brittleness, deformation, discoloration, etc.). Test all connections for loose or disassembled connectors.

**Note:** Remove power from system before replacing components.

**Note:** Once all faults are cleared, confirm proper operation of the entire CHECKFIRE 210-D System by completing Section 6 – Operational Test and Place in Service.

If faults cannot be cleared, test each circuit and cable individually with the following procedures.

**Note:** Specific jurisdictions or customer procedures may require documentation of all components replaced. Keep a record of all changes to the system as required.

### Power Circuit

If Power LED is showing no indication for more than 10 seconds check the connection of the Display Module to the ICM as well as all power connections.

Secondary Power Only\*: If Power LED is pulsing AMBER 1 x 10 seconds and only using secondary power this indicates the Battery Module is below an acceptable level.

- Inspect battery cable on ICM for damage
- Inspect cable and connector sockets on battery for damage/deformation
- Replace with a new/unused battery module

Primary / Dual Power: If Power LED is pulsing AMBER 1 x 3 seconds (dual power) use the following steps to troubleshoot the primary power circuit.

Required Test Equipment:

- New Fuse: (3 amp in-line ATO/ATC blade style automotive fuse)
- Digital Multimeter

1. Disconnect Power Circuit Cable at the ICM. Use the Digital Multimeter to confirm proper voltage is available at the end of the Power Circuit Cable. If voltage on Power Circuit Cable is correct, there is an internal problem and the CHECKFIRE 210-D ICM must be replaced.



TABLE 9-7: SPECIFIC CIRCUIT TESTING PROCEDURES (Continued)


**Power Circuit (Continued)**

2. If voltage on Power Circuit Cable is not correct, use the Digital Multimeter to check for proper voltage at the equipment power source (battery).
  - a. If voltage is correct move to step 3.
  - b. If power source voltage is incorrect or indicates no power, contact equipment service personnel to correct. When voltage is restored reconnect entire power circuit to see if power fault clears. If fault does not clear return to step one.
3. Check fuse in the Fused Power Circuit Cable connected to equipment power source. If needed replace fuse following instructions in Section 5 – Installation and Programming, page 5-14 (step 5).
4. After confirming correct voltage at the power source and a good fuse, disconnect Fused Power Circuit Cable connector from power circuit and check for proper voltage with the Digital Multimeter. If voltage on Fused Power Circuit Cable is correct, the cable is functioning properly. If voltage is incorrect the Fused Power Circuit Cable must be replaced.
5. After confirming correct voltage at end of Fused Power Circuit Cable continue checking the remaining power circuit at each set of connectors for proper voltage from the power source. Replace non-functioning cable with an identical new part.

2. CONFIRM CORRECT VOLTAGE AT POWER SOURCE

3. CHECK FUSE, IF NEEDED REPLACE

**FOLLOW SECTION 5 – INSTALLATION INSTRUCTIONS TO REPLACE FUSE**



4. CONFIRM VOLTAGE AT CONNECTOR

011789

5. CONFIRM VOLTAGE AT EACH SET OF CONNECTORS



011816

6. After replacing non-functioning cable and confirming correct voltage through entire power circuit, reconnect to ICM. Power LED returns to GREEN steady-on.  
  
If all faults are clear, verify proper operation of the CHECKFIRE 210-D System by completing Section 6 – Operational Test and Place in Service.

6. CONFIRM CORRECT VOLTAGE THROUGH ENTIRE CIRCUIT AND RECONNECT

**TABLE 9-7: SPECIFIC CIRCUIT TESTING PROCEDURES (Continued)**

**Release Circuit**

If Release LED is pulsing AMBER indicating a release circuit fault and cannot be cleared check release circuit cable.

**Required Test Equipment** (Confirm test equipment is new and functioning properly)

- Release Circuit Tester
- Release Circuit Terminators
- Release Circuit Test Plugs – one for each PAD

LED Color	Flash rate / 10 sec	Fault condition
Amber	1 x	Open circuit fault
Amber	2 x	Circuit fault
Amber	1 x sec on	Ground fault

Pressing the DELAY/SILENCE/RESET button on the Checkfire 210-D Display Module will silence the audible sounder and change the LED blink rate on the corresponding LED as described in the Detection and Release Sections of the Troubleshooting guides. This change will aid in easier troubleshooting in the field.

1. Power down system.
2. Replace all PADs with Release Circuit Test Plugs.
3. Power up system.
4. If fault clears, there is at least one faulty PAD. Repeat above steps (1 to 3) for each PAD except at step 2 replace 1 Release Circuit Test Plug with a PAD one at a time to determine the faulty PAD.
5. If fault does not clear, disconnect Release Circuit Cable at the ICM release connection. Install Release Circuit Terminator directly to the connection on the ICM.
6. If the Release LED continues to pulse AMBER, reconnect the Release Cable to the ICM release connection.
7. Replace one of the Release Circuit Test Plugs with the Release Circuit tester. Ensure all other Release test plugs remain in place.
8. Turn on the Release Circuit Tester. Wait for the “Ready” light to illuminate.
9. Perform a Push-To-Activate release.
10. If the RCT registers a PASS, there may be a damaged release circuit cable. Replace as needed.
11. If the RCT registers a FAIL, there is an internal failure of the release circuit and the ICM must be replaced.

**⚠ CAUTION**

When handling the PAD, always point actuating end away from yourself and others. On electrical initiation, PAD operates very quickly and a small brass disk forcefully separates from actuating end. Physical injury may occur from contact with the actuating pin and/or the detaching disk.

1. POWER DOWN
2. REPLACE ALL PADs WITH TEST PLUGS
3. POWER UP
4. IF FAULT CLEARS, CHECK FOR FAULTY PAD.



011817

5. IF FAULT DOES NOT CLEAR, INSTALL TERMINATOR; IF FAULT CONTINUES, FOLLOW STEPS 6 TO 11.



011818

RELEASE CIRCUIT CONNECTION, INSTALL TERMINATOR

TABLE 9-7: SPECIFIC CIRCUIT TESTING PROCEDURES (Continued)

**Release Circuit (Continued)**

6. If Release Circuit fault clears, the ICM is functioning properly and the fault is in the cabling or connectors. Re-install complete release circuit to the ICM connection. Reset to Normal: Press and hold "DELAY/Reset/Silence" button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.
7. If Release Circuit fault does not clear, continue testing the release circuit at each set of connectors starting at the next connection point from the ICM. Separate connectors and install Release Circuit Terminator at the end of the cable connected to the ICM. If fault does not clear, replace non-functioning component with an identical new part and retest. If fault clears, part is good; re-install and move to next set of connectors.

**NOTICE**

Be sure to add only one new component (cable, "h" cable, EMA, etc.) at a time to help identify the specific part causing the fault.


8. At a Release Circuit "h" Cable remember to first check the main trunk connector leading to the "h" Cable; then re-connect to check the "h" Cable. Install a Release Circuit Terminator on each side of "h" Cable. If fault clears "h" Cable is good. If fault does not clear replace "h" Cable.

6. IF FAULT CLEARS, RECONNECT AND RESET TO NORMAL

7. IF FAULT CONTINUES, TEST EACH CONNECTION, REPLACE COMPONENTS AS NEEDED

8. AT "h" CABLE, TEST MAIN TRUNK CONNECTION FIRST

8. THEN INSTALL TERMINATORS ON DROP AND MAIN TRUNK CONNECTORS



9. After checking a Release Circuit "h" Cable, continue testing drop line to the end of the Release Circuit Drop Cable.
10. Test Release Circuit Drop Cable using a Release Circuit Test Plug. If the Release Circuit Drop Cable causes a fault, replace it with an identical new part and retest.

9. AFTER "h" CABLE, CONTINUE TESTING DROP

10. IF DROP CABLE CAUSES A FAULT, REPLACE WITH NEW PART AND RETEST




TABLE 9-7: SPECIFIC CIRCUIT TESTING PROCEDURES (Continued)

**Release Circuit (Continued)**

11. After drop line is clear, return to the last connection that was good and continue testing the main trunk and any drop lines in the same manner until release circuit fault is clear.

When all faults are clear, verify proper operation of the CHECKFIRE 210-D System by completing Section 6 – Operational Test and Place in Service.

11. AFTER DROP IS CLEAR,  
CONTINUE TESTING IN  
SAME MANNER UNTIL  
ENTIRE CIRCUIT IS CLEAR

**Detection Circuit #1 and/or #2**

If Detection Circuit #1 LED is pulsing AMBER and cannot be cleared check detection circuit #1 cable. Detection Circuit #2 is checked in a similar manner as the one described below, but should be investigated separately to avoid confusion.


**Required Test Equipment** (Confirm test equipment is new and functioning properly)

- Detection Circuit EOL Device
- Detection Circuit Tester (DCT) - set to "Normal" position
- Detection Circuit Branch Terminator

LED Color	Flash rate / 10 sec	Fault condition
Amber	1 x	Open circuit fault
Amber	2 x	EMA band fault
Amber	3 x	Low resistance fault
Amber	4 x	QIR system fault
Amber	1 x sec on	Ground fault

1. Prior to testing the circuit, place system in isolate mode, press and hold the DELAY/Reset/Silence button on the CHECKFIRE 210-D Display Module for approximately 8 seconds (two consecutive resets).
2. Disconnect Detection Circuit #1 Cable (and #2 if part of system) at the ICM connection. Install EOL Device or DCT on the ICM connection. If Detection Circuit #1 LED continues pulsing AMBER, there is an internal problem and the CHECKFIRE 210-D ICM must be replaced.

1. PLACE SYSTEM IN ISOLATE MODE.



2. INSTALL EOL DEVICE;  
IF FAULT CONTINUES,  
REPLACE ICM

011821

3. If Detection Circuit #1 fault clears, the ICM is functioning properly. Re-install complete Detection Circuit to the ICM Detection Circuit connection.

Reset to Normal: Press and hold "DELAY/Reset/Silence" button for 3 seconds; Green and Red LEDs are steady-on for 1 second; then Amber LEDs are steady-on for 1 second; at end sounder quickly pulses 3 times.

3. IF FAULT CLEARS,  
RECONNECT AND RESET  
TO NORMAL

TABLE 9-7: SPECIFIC CIRCUIT TESTING PROCEDURES (Continued)

**Detection Circuit (Continued)**

4. If Detection Circuit #1 fault does not clear, continue testing the detection circuit at each set of connectors starting at the next connection point from the ICM. Separate connectors and install EOL Device or DCT at the end of the cable connected to the ICM. If fault does not clear, replace non-functioning component with an identical new part and retest. If fault clears part is good; re-install and move to next set of connectors.


4. IF FAULT CONTINUES TEST EACH CONNECTION, REPLACE COMPONENTS AS NEEDED

**NOTICE**

Be sure to add only one new component (cable, "h" cable, EMA, etc.) at a time to help identify the specific part causing the fault.

5. At a Detection Circuit "h" Cable remember to first check the main trunk connector leading to the "h" cable, then re-connect to check the "h" cable. Install a Detection Circuit Branch Terminator on branch side of "h" cable, and the EOL Device or DCT on main trunk side. If fault clears "h" cable is good; if fault does not clear replace "h" cable

5. THEN INSTALL BRANCH TERMINATOR AND, EOL DEVICE (OR DCT) TO TEST "h" CABLE
5. AT "h" CABLE TEST MAIN TRUNK CONNECTION FIRST



6. After checking a Detection Circuit "h" Cable, continue testing components to the end of the branch line.

6. IF FAULT IS CORRECTED IN BRANCH LINE, RECONNECT ENTIRE CIRCUIT;

If a non-functioning component is found and replaced on a branch line, reconnect the complete detection circuit to determine if that is the only fault in the circuit.

IF FAULT OCCURS, CONTINUE TESTING CIRCUIT FROM LAST GOOD CONNECTION UNTIL FAULT CLEARS

If reconnecting the remaining detection circuit causes a fault, return to the last connection that was good and continue testing the main trunk and any branch lines in the same manner until detection circuit fault clears.

Cancel isolate mode by pressing and holding the DELAY/Reset/Silence button on the CHECKFIRE 210-D Display Module for approximately 8 seconds (two consecutive resets).

If all faults are clear, verify proper operation of the CHECKFIRE 210-D System by completing Section 6 – Operational Test and Place in Service.

When Detection Circuit #2 is part of the system, troubleshoot and correct faults on Detection Circuit #2 in a similar manner to those described above.

**COMPONENT INDEX**

Part No.	Description
<b>System Components</b>	
A16381C9PK	CHECKFIRE 210-D Display Module
439564	Mounting Bracket, CHECKFIRE 110/210
A16381C9PL	Interface Control Module (ICM), CHECKFIRE 210-D
439569	Electric-Pneumatic Actuator (EPA)
440352	CHECKFIRE 210 Battery
<b>Display/Communication Circuit</b>	
A16381EW4C	100 ft (30.5 m) Bulk Display/ Communication Circuit Cable Box
A16381EW48	200 ft (61.0 m) Bulk Display/ Communication Circuit Cable Spool
A16381CBC1	2 ft (0.61 m) Display/Communication Circuit Cable
A16381CBC2	3 ft (0.92 m) Display/Communication Circuit Cable
A16381CBC3	5 ft (1.53 m) Display/Communication Circuit Cable
A16381CBC4	10 ft (3.05 m) Display/Communication Circuit Cable
A16381CD2V	20 ft (6.10 m) Display/Communication Circuit Cable
A16381CD2W	30 ft (9.15 m) Display/Communication Circuit Cable
A16381CD30	50 ft. (15.24 m) Display/Communication Circuit Cable
<b>Detection Circuit</b>	
A16381EW49	100 ft (30.5 m) Bulk Detection/Relay Circuit Cable Box
A16381EW45	500 ft (152.4 m) Bulk Detection/Relay Circuit Cable Spool
A16381C9PN	2 ft (0.61 m) Detection Circuit Cable
A16381CB0F	3 ft (0.91 m) Detection Circuit Cable
A16381CB0G	5 ft (1.53 m) Detection Circuit Cable
A16381CB62	10 ft (3.05 m) Detection Circuit Cable
A16381CB63	20 ft (6.10 m) Detection Circuit Cable
A16381CB64	30 ft (9.15 m) Detection Circuit Cable
A16381CB65	50 ft (15.24 m) Detection Circuit Cable
A16381CD32	"h" Cable, Detection Circuit
A16381C9PM	Electric Manual Actuator (EMA)
440537	Electric Manual Actuator Bracket

Part No.	Description
<b>Detection Circuit (Continued)</b>	
426520	End-of-Line Resistor
426461	End-of-Line Resistor (10 Pack)
A16381CB66	EOL (End-of-Line) Device, Detection Circuit
A163828M45	In-Line Splice Kit w/EOL Resistor
A16381CB6Y	Branch Terminator, Detection Circuit
428375	In-Line Splice Kit
A16381TK26	Discharge Pressure Switch
<b>Linear Detectors (Red)</b>	
071230	100 ft (30.5 m) Red Bulk Linear Detection Wire, 356 °F (180 °C)
<b>Linear Detectors (White)</b>	
A16381ULBP	100 ft (30.5 m) White Bulk Linear Detection Wire, 220 °F (105 °C)
<b>Relay Circuit</b>	
A16381EW49	100 ft (30.5 m) Bulk Detection/Relay Circuit Cable Box
A16381EW45	500 ft (152.4 m) Bulk Detection/Relay Circuit Cable Spool
A16381CB9R	2 ft (0.61 m) Relay Circuit Cable
A16381CB9T	5 ft (1.53 m) Relay Circuit Cable
A16381CB9U	10 ft (3.05 m) Relay Circuit Cable
A16381CB9Y	20 ft (6.10 m) Relay Circuit Cable
<b>Release Circuit</b>	
A16381EW4B	100 ft (30.5 m) Bulk Release/Power Circuit Cable Box
A16381EW47	500 ft (152.4 m) Bulk Release/Power Circuit Cable Spool
A16381CB70	2 ft (0.61 m) Release Circuit Cable
A16381CB71	3 ft (0.91 m) Release Circuit Cable
A16381CB72	5 ft (1.53 m) Release Circuit Cable
A16381CB73	10 ft (3.05 m) Release Circuit Cable
A16381CB74	20 ft (6.10 m) Release Circuit Cable
A16381CB7D	30 ft (9.15 m) Release Circuit Cable
A16381CB7E	50 ft (15.24 m) Release Circuit Cable
A16381CD33	"h" Cable, Release Circuit
A16381CB7J	Terminator, Release Circuit
A16381CB7H	38 in. (0.96 m) Release Circuit Drop Cable

**COMPONENT INDEX (Continued)**

Part No.	Description
439448	Protracting Actuation Device (PAD)
<b>Power Circuit</b>	
A16381EW4B	100 ft (30.5 m) Bulk Release/Power Circuit Cable Box
A16381EW47	500 ft (152.4 m) Bulk Release/Power Circuit Cable Spool
A16381CB7K	2 ft (0.61 m) Power Circuit Cable
A13681CB7L	3 ft (0.92 m) Power Circuit Cable
A16381CB7M	5 ft (1.53 m) Power Circuit Cable
A16381CB7P	10 ft (3.05 m) Power Circuit Cable
A16381CB7T	20 ft (6.10 m) Power Circuit Cable
A16381CB8K	30 ft (9.15 m) Power Circuit Cable
A16381CB8M	50 ft (15.24 m) Power Circuit Cable
A16381CB9P	Fused Power Circuit Cable 1.5 ft (0.46 m) (w/Fuse Holder)
<b>Bulk Circuit Connector Kits</b>	
A16381TK21	2-Pin Connector Kit, 1 pack Release/Power Circuits
A16381TK20	2-Pin Connector Kit, 5 packs Release/Power Circuits
A16381TK1Y	6-Pin Connector Kit, 1 pack Display/Detection/Relay Circuits
A16381TK1V	6-Pin Connector Kit, 5 packs Display/Detection/Relay Circuits
<b>Cable Mounting Hardware</b>	
448174	Bulkhead Cord Grip, (Pkg. 50)
440737	Double Loop Cable Tie (Pkg. 50)
447931	2-Hole Grommet (25 Pack)
447928	3-Hole Grommet (25 Pack)

Part No.	Description
447321	Linear Detector Grommet (Pkg. 25)
<b>Testing Devices</b>	
A16381TK27	Detection Circuit Tester
441021	Release Circuit Tester
A13681V3R6	Release Circuit Test Plug
<b>Service Components</b>	
440798	Label Package
440802	In Case of Fire Label
009182	Extreme Temperature Silicone Grease Dow Corning No. 4
439568	Mounting Plate, Interface Control Module (ICM)
440179	O-ring, Interface Control Module (ICM) (Pkg. of 5)
439567	Battery Cover, Interface Control Module (ICM)
440082	Guard Door, Display Module
015999	Visual Seal
440083	Enclosure Nut, Display Module
016047	O-ring #011, PAD
076076	O-ring #016, Release Circuit Drop Cable
016470	Knob - Red
056759	Boot
032342	Ring Pin
000507	Chain
000197	Lead Wire Seal

**TORQUE SPECIFICATIONS**

Component*	Torque Specification		Comments
	in.-lb	(N·m)	
Interface Control Module (ICM)	77	(8.8)	Torque Nylok nut using Torque wrench
Cord Grip Lock Nut	75 to 80	(8.5 to 9.0)	–
Cord Grip Lock Sealing Nut	80 to 85	(9.0 to 9.6)	–
Electric-Pneumatic Actuator (EPA) to Cartridge	38 to 42	(51.5 to 57)	–
Display Module Swivel Joint Screws	20 to 25	(2.26 to 2.82)	–
CHECKFIRE 210-D Display Module Enclosure Nut	20 to 30	(2.26 to 3.39)	–
EMA Nut	20 to 30	(2.26 to 3.39)	–
Drop Cable	20 ft-lb to 25 ft-lb	(27 to 34)	–
Self Locking Seal	None		Break force 12 lb to 14 lb (5.4 kg to 6.4 kg)
Lead Wire Seal	None		Break force 12 lb to 14 lb (5.4 kg to 6.4 kg)

\*Note: Associated component part numbers available in this CHECKFIRE 210-D Manual (latest revision).

**NOTES:**